

DOMINO[®]
Ultimate Sampling System
(USS)

User Guide

Doble Document: 72A-2571-02

Doble Part Number 500-0701

Rev. B, November, 2007

Doble Engineering Company
85 Walnut Street
Watertown, MA 02472 USA
Phone: +1-617-926-4900
Fax: +1-617-926-0528

Visit our Internet site at <http://www.doble.com>

© Doble 2007

No part of this manual may be reproduced in any form or by any means, electronic or mechanical (including photocopying), nor may its contents be communicated to a third party without prior written permission of the copyright holder.

The contents are subject to change without prior notice.

NOTICE

This User Guide covers **all** *DOMINO*® Ultimate Sampling System probes and components.

One or more section(s) may not apply to the product you have.

NOTICE

The first charge of the Indicator requires 6 hours.
DO NOT use the Indicator during the first charging cycle.

This page intentionally left blank

Table of Contents

SECTION 1

INTRODUCTION1

CHAPTER 1

GENERAL INFORMATION3

Safety4

Trademarks5

Feedback5

Recycling/Disposal.....5

De-commissioning and Disposal.....6

Doble Service Center6

Warranty.....7

CHAPTER 2

***DOMINO*[®] USS QUICK START9**

CHAPTER 3

THE *DOMINO*[®] ULTIMATE SAMPLING SYSTEM..... 11

About The *DOMINO*[®] Ultimate Sampling System (USS)..... 12

Types Of *DOMINO*[®] Ultimate Sampling Systems..... 13

CHAPTER 4

THE *DOMINO*[®] USS MOISTURE-IN-OIL SYSTEM 15

About The *DOMINO*[®] USS Moisture-In-Oil System..... 16

Measured Variables 16

General Theory Of Operation 17

System Components..... 20

CHAPTER 5

THE *DOMINO*[®] USS DEWPOINT SYSTEM 21

About The *DOMINO*[®] USS Dewpoint System 22

Measured Variables 22

System Components..... 23

CHAPTER 6

THE *DOMINO*[®] USS COMPLETE SYSTEM 25

About The *DOMINO*[®] USS Complete System 26

Measured Variables 26

System Components	27
SECTION 2	
WORKING WITH THE INDICATOR	29
CHAPTER 7	
INDICATOR QUICK START	31
CHAPTER 8	
ABOUT THE INDICATOR	33
About The Indicator	34
Connections And Controls	35
The Basic Display	36
Using The Keypad	37
The Indicator Menus	38
CHAPTER 9	
CONFIGURING THE INDICATOR	39
Selecting The Interface Language.....	40
Configuring Automatic Power Off	41
Changing The Shortcut Keys.....	42
Setting Button Press Sounds.....	43
Setting Backlight On Button Press	43
Setting The Date And Time	44
Restoring The Factory Settings	45
CHAPTER 10	
WORKING WITH DATA	47
Specifying The Displayed Quantities And Units	48
Specify Data Display Rounding	49
Viewing Data From Two Probes.....	50
Holding And Saving The Data Display	51
Displaying Data Graphically.....	52
Viewing Device Information	53
Setting Alarm Levels.....	54
Using The Analog Output	56
CHAPTER 11	
RECORDING DATA	59
Recording Data.....	60
Stopping Recording	62
Viewing Recorded Data	63
Checking The Memory Status	63
Deleting All Recorded Files	64
Transferring Recorded Data To A PC	64
Monitoring Real time Data On A PC.....	64

CHAPTER 12	
ERROR MESSAGES	65
What To Do With Errors	66
Types Of Error Messages	66
CHAPTER 13	
INDICATOR MAINTENANCE.....	67
Viewing The Battery Level	68
Charging The Battery Pack	69
Replacing The Battery Pack	70
Using Alkaline Batteries	71
SECTION 3	
MAKING MOISTURE-IN-OIL MEASUREMENTS.....	73
CHAPTER 14	
MOISTURE-IN-OIL QUICK START.....	75
CHAPTER 15	
INSTALLING THE MOISTURE-IN-OIL PROBE.....	77
General Installation Considerations	78
Installation On A Drain Valve	82
Direct Installation On A Pressurized Process	85
Ball Valve Installation On A Pressurized Process	89
Unpressurized Installation.....	95
CHAPTER 16	
TAKING MOISTURE-IN-OIL MEASUREMENTS.....	97
CHAPTER 17	
CHANGING MOISTURE-IN-OIL SETTINGS.....	99
About Oil Types.....	100
Changing The Default Oil Type.....	101
Testing New Oil Types	102
Adding New Oil Types.....	103
CHAPTER 18	
CALIBRATING MOISTURE-IN-OIL PROBES	105
General Calibration Information	106
Preparations Before Calibration.....	107
About Temperature Calibration.....	108
Temperature Calibration Procedures.....	109
About Relative Humidity Calibration	112
Relative Humidity Calibration Procedures	113
Viewing The Last Calibration Date.....	117

CHAPTER 19

MAINTAINING MOISTURE-IN-OIL PROBES..... 119

 Changing The Filter And Sensor 120

 Changing The Quick Connect Fitting..... 121

 Cleaning the Moisture-In-Oil Probe 122

SECTION 4

MAKING DEWPOINT MEASUREMENTS..... 123

 CHAPTER 20

DEWPOINT QUICK START 125

 CHAPTER 21

INSTALLING THE DEWPOINT PROBE..... 127

 About the USS Dewpoint Sampling Cell..... 128

 Installation On A Pressurized Process 129

 CHAPTER 22

TAKING DEWPOINT MEASUREMENTS 133

 Taking Dewpoint Measurements 134

 Measuring In Very Dry Environments 136

 CHAPTER 23

CHANGING DEWPOINT SETTINGS 137

 Changing Pressure Settings 138

 Changing Molecular Weight Settings 140

 Changing Auto-Calibration Settings 142

 Changing Sensor Purge Settings 146

 CHAPTER 24

CALIBRATING DEWPOINT PROBES 151

 General Calibration Information..... 151

 CHAPTER 25

MAINTAINING DEWPOINT PROBES 153

 Cleaning Dewpoint Probes 153

SECTION 5

USING DOMINO® CONNECTS..... 155

 CHAPTER 26

USING DOMINO® CONNECTS 157

 About DOMINO® Connects..... 158

 DOMINO® Connects Requirements..... 158

 Installing DOMINO® Connects..... 159

Installing The USB-Serial Adapter	162
Using <i>DOMINO</i> [®] Connects	163
Uninstalling <i>DOMINO</i> [®] Connects.....	165
SECTION 6	
SPECIFICATIONS	167
CHAPTER 27	
TECHNICAL SPECIFICATIONS	169
<i>DOMINO</i> [®] USS System Specifications	170
Indicator Specifications	171
Moisture-In-Oil Probe Specifications.....	173
Dewpoint Probe Specifications	175
CHAPTER 28	
OPTIONS, ACCESSORIES, AND SPARES	179

This page intentionally left blank

SECTION 1

INTRODUCTION

This section contains general information on the *DOMINO*® Ultimate Sampling System, including descriptions of the available system configurations.

Chapters in this section...

- Chapter 1 General Information
- Chapter 2 *DOMINO*® USS Quick Start
- Chapter 3 The *DOMINO*® USS System
- Chapter 4 The *DOMINO*® USS Moisture-In-Oil System
- Chapter 5 The *DOMINO*® USS Dewpoint System
- Chapter 6 The *DOMINO*® USS Complete System

This page intentionally left blank.

CHAPTER 1

GENERAL INFORMATION

This chapter contains general information on the *DOMINO*® USS System including critical safety information.

Topics in this chapter...

Safety

Trademarks

Feedback

Recycling/Disposal

De-commissioning and Disposal

Doble Service Center

Warranty

Safety

Safety should always be the first priority of every user.

Before using this product familiarize yourself with the features and functions of each equipment item.

Before starting any procedure, read through the entire instructions and do not proceed if you have any doubt about their meaning.

Throughout the manual, important safety considerations are highlighted as follows:

WARNING

Warnings alert you to a potential personnel hazard.

If you do not read and follow instructions very carefully at this point, there is a risk of injury or even death.

CAUTION

Cautions warn you of a potential equipment hazard.

If you do not read and follow instructions carefully at this point, the product could be damaged or important data could be lost.

NOTE

Notes highlight important information on using or understanding the product.

TIP

Tips contain important information that can save time and effort when using the product.

Trademarks

DOMINO® is a registered trademark of Doble Engineering.

Envirotemp® is a registered trademark of Cooper Power Systems.

Biotemp® is a registered trademark of ABB Inc.

Microsoft® Windows®, and Windows NT® are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Feedback

The Doble Customer Documentation Team welcomes your comments and suggestions on the quality and usefulness of this publication. If you find errors or have other suggestions for improvement, please indicate the section, chapter, topic, and page number. You can send comments to us by e-mail at:

domino@doble.com

Recycling/Disposal



Recycle all applicable material.




Dispose of batteries and the unit in accordance with all federal, state, and local regulations.

DO NOT dispose of with regular household refuse.

De-commissioning and Disposal

WARNING

Contaminated parts can be detrimental to health and environment. Before beginning to work, and after completing the work, determine whether any of the parts - especially the probe, filter, or sampling cell - have been contaminated during the measurement process and thus may require decontamination.



Adhere to the relevant regulations and take the necessary precautions when handling contaminated parts.

1. Contaminated components, if any, must be decontaminated according to the relevant federal, state, and local regulations.
2. The battery packs and/or alkaline batteries must be removed as described in Replacing The Battery Pack on page 70 and Using Alkaline Batteries on page 71.
3. Dismantled parts must be separated according to the materials and disposed of according to relevant federal, state, and local regulations.

Doble Service Center

Doble Engineering Company
Customer Service Department
85 Walnut Street
Watertown, MA 02472 USA
Phone: +1-617-926-4900
Fax: +1-617-926-0528
Visit our Internet site at <http://www.doble.com>

You can also request customer service from links on our website.

Warranty

Equipment Limited Warranty

Doble Engineering Company (DOBLE) warrants the products that it manufactures to be free from defects in material and workmanship for a period of one year from the date shipped from the factory.

During the one-year warranty period, DOBLE will repair or replace, at its option, any defective products or components thereof at no additional charge, provided that the product or component is returned, shipping prepaid, to DOBLE. The Purchaser is responsible for insuring any product or component so returned and assumes the risk of loss during shipment. All replaced products and components become the property of DOBLE.

THIS LIMITED WARRANTY DOES NOT EXTEND TO ANY PRODUCTS WHICH HAVE BEEN DAMAGED AS A RESULT OF NORMAL WEAR AND TEAR, ACCIDENT, ABUSE, NEGLIGENCE INCLUDING BUT NOT LIMITED TO FAILURE TO SERVICE THE PRODUCT OR OTHERWISE FOLLOW DOBLE'S SERVICE INSTRUCTIONS, MISUSE INCLUDING BUT NOT LIMITED TO UNSUITABLE OR UNAUTHORIZED USE OF THE PRODUCT OR INCORRECT INSTALLATION OR ASSEMBLY OR ERROR IN STORING, MAINTAINING OR IN HANDLING THE PRODUCT OR ANY EQUIPMENT THEREOF, OR AS A RESULT OF MODIFICATION BY ANYONE OTHER THAN DOBLE OR AN AUTHORIZED DOBLE REPRESENTATIVE.

EXCEPT AS EXPRESSLY SET FORTH ABOVE, NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, ARE MADE WITH RESPECT TO THE PRODUCT INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. DOBLE EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED HEREIN. IN THE EVENT THE PRODUCT IS NOT FREE FROM DEFECTS AS WARRANTED ABOVE, THE PURCHASER'S SOLE REMEDY SHALL BE REPAIR OR REPLACEMENT AS PROVIDED ABOVE. DOBLE'S LIABILITY SHALL UNDER NO CIRCUMSTANCES EXCEED THE INVOICE PRICE OF ANY PRODUCT FOR WHICH A WARRANTY CLAIM IS MADE. UNDER NO CIRCUMSTANCES WILL DOBLE BE LIABLE TO THE PURCHASER OR ANY USER FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION, PERSONAL INJURY OR PROPERTY DAMAGE CAUSE BY THE PRODUCT, ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, EXPENSES, LOST PROFITS, LOST SAVINGS, OR OTHER DAMAGES ARISING OUT OF THE USE OF OR INABILITY TO USE THIS PRODUCT.

Software Limited Warranty

THIS SOFTWARE PRODUCT IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THIS SOFTWARE PRODUCT IS WITH PURCHASER SHOULD THE PRODUCT PROVE DEFECTIVE. PURCHASER (AND NOT DOBLE OR AN AUTHORIZED DEALER) ASSUMES THE ENTIRE COST OF ALL NECESSARY SERVICING, REPAIR, OR CORRECTION.

Some states do not allow the exclusion of implied warranties, so the above exclusion may not apply. This warranty gives the purchaser specific legal rights and you may also have other rights which vary from state to state.

DOBLE warrants the disks on which the software product is furnished to be free from defects in materials and workmanship under normal use for a period of one hundred and twenty (120) days from the date of shipment from DOBLE.

Limitations of Remedies

DOBLE's entire liability and Purchaser's exclusive remedy shall be:

1. The replacement of any disks not meeting DOBLE's "Limited Warranty" which are returned to Doble.
2. If DOBLE is unable to deliver replacement disks that are free from defects in materials and workmanship, Purchaser may terminate this agreement. By returning the software product and all copies thereof in any form and affirming compliance with this requirement in writing, DOBLE will refund the purchase price.

IN NO EVENT WILL DOBLE BE LIABLE TO PURCHASER FOR ANY DAMAGES, INCLUDING ANY LOST PROFITS, LOST SAVINGS OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE SUCH SOFTWARE PRODUCT, EVEN IF DOBLE OR AN AUTHORIZED DEALER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY OTHER PARTY.

SOME STATES DO NOT ALLOW THE LIMITATION OR EXCLUSION OF LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY.

CHAPTER 2

DOMINO® USS QUICK START

The *DOMINO*® Ultimate Sampling System enables reliable and high performance moisture-in-oil and dewpoint measurements.

The first time out of the case, follow these steps:

1. Familiarize yourself with the system components.

The *DOMINO*® Ultimate Sampling System consists of a hand held indicator and a probe that is installed on the process. There are a variety of fittings and accessories supplied for each probe type. For more information see Chapter 3, The *DOMINO*® Ultimate Sampling System on page 11.

2. Prepare the Indicator.

The first time you use the Indicator you must charge the internal battery and program the current date and time. For more information see Chapter 7, Indicator Quick Start on page 31.

3. Configure and install the probe and begin to take readings.

Each different probe type requires configuration and installation on the process before taking readings. For more information see:

- Chapter 14, Moisture-In-Oil Quick Start on page 75.
- Chapter 20, Dewpoint Quick Start on page 125.

This page intentionally left blank.

CHAPTER 3

THE *DOMINO*® ULTIMATE SAMPLING SYSTEM

This chapter contains information on the types of *DOMINO*® USS Systems that are available.

Topics in this chapter...

About The *DOMINO*® Ultimate Sampling System (USS)

Types Of *DOMINO*® Ultimate Sampling Systems

About The **DOMINO®** Ultimate Sampling System (USS)

The **DOMINO®** Ultimate Sampling System enables reliable and high performance moisture-in-oil and dewpoint measurements.

The USS system consists of two main components:

- The **DOMINO®** USS Indicator controls the sensor probes and displays and stores the measurement results. The USS Indicator is a portable hand held unit powered by a rechargeable battery and can control up to two probes. It can also be connected to a PC for monitoring and data transfer and can provide a 0 to 1 V analog output.
- A **DOMINO®** USS sensor probe. There are two types of probes:
 - The **DOMINO®** USS Moisture-In-Oil Probe utilizes Doble's advanced **DOMINO®** technology to measure moisture-in-oil concentrations accurately in a measurement range from -40 °C (-40 °F) up to +60 °C (+140 °F.)
 - The **DOMINO®** USS Dewpoint Probe utilizes Doble's advanced **DOMINO®** dewpoint technology to measure dewpoint temperature accurately in a measurement range from -60 °C (-76 °F) up to +20 °C (+68 °F.)

Probes are calibrated at Doble and can be delivered with or without a factory calibration certificate.

Additionally, all **DOMINO®** USS systems contain:

- **DOMINO®** Connects, a Microsoft Windows® environment software program that allows you to use a PC to monitor and configure the Indicator and to download recorded data.
- The necessary adapters to interface the included sensor probe(s) to a wide variety of process vessels including pressurized pipes and transformer drain valves.
- A rugged high-density polyethylene carrying case with a cushioned oil-resistant insert to safely store and transport all components.

Types Of **DOMINO**® Ultimate Sampling Systems

The **DOMINO**® USS comes in three different system configurations:

The **DOMINO® USS Moisture-In-Oil System**

(Doble Part Number 03D-1647-01)

Contains an Indicator and universal AC/DC adapter, one Moisture-In-Oil Probe, **DOMINO**® Connects software and interface cable, printed User Guide, Moisture-In-Oil Quick Start Guide, and adapters to interface the included probe, all in a rugged polyethylene carrying case. For more information see Chapter 4, The **DOMINO**® USS Moisture-In-Oil System on page 15.

The **DOMINO® USS Dewpoint System**

(Doble Part Number 03D-1677-01)

Contains an Indicator and universal AC/DC adapter, one Dewpoint Probe, **DOMINO**® Connects software and interface cable, printed User Guide, and adapters to interface the included probe, all in a rugged polyethylene carrying case. For more information see Chapter 5, The **DOMINO**® USS Dewpoint System on page 21.

The **DOMINO® USS Complete System**

(Doble Part Number 03D-1686-01)

Contains an Indicator and universal AC/DC adapter, two Moisture-In-Oil Probes, one Dewpoint Probe, **DOMINO**® Connects software and interface cable, printed User Guide, Moisture-In-Oil Quick Start Guide, and adapters to interface the included probes, all in a rugged polyethylene carrying case. For more information see Chapter 6, The **DOMINO**® USS Complete System on page 25.

Additionally, all system components and accessories can be ordered separately. For more information see Chapter 28, Options, Accessories, and Spares on page 179.

This page intentionally left blank.

CHAPTER 4

THE *DOMINO*® USS MOISTURE-IN-OIL SYSTEM

This chapter contains information on the *DOMINO*® USS Moisture-In-Oil System.

Topics in this chapter...

About The *DOMINO*® USS Moisture-In-Oil System

Measured Variables

General Theory Of Operation

System Components

About The **DOMINO®** USS Moisture-In-Oil System

The **DOMINO®** USS Moisture-In-Oil system measures moisture-in-oil concentrations accurately in a temperature range from -40 °C (-40 °F) up to +60 °C (+140 °F.) The **DOMINO®** USS Moisture-In-Oil probe incorporates advanced **DOMINO®** technology, which enables reliable and high-performance moisture-in-oil-measurements.

The **DOMINO®** USS Moisture-In-Oil System (Doble Part Number 03D-1647-01) contains an Indicator and universal AC/DC adapter, one Moisture-In-Oil Probe, **DOMINO®** Connects software and interface cable, printed User Guide, Moisture-In-Oil Quick Start Guide, and adapters to interface the included probe, all in a rugged polyethylene carrying case. The case can hold an additional Moisture-In-Oil probe and a Dewpoint Probe, available separately.

CAUTION

Do not store the **DOMINO® USS Moisture-In-Oil Probe in a high humidity environment.**

Storing the **DOMINO®** USS in a high humidity environment will increase the sensor response time.

Measured Variables

The **DOMINO®** USS Moisture-In-Oil system can measure the following:

Symbol	Variable	Units
RS	Relative Saturation	%
T	Temperature	°C/°F
H ₂ O	Mass concentration of water	ppm

General Theory Of Operation

Summary


The *DOMINO*® USS Moisture-In-Oil system determines the moisture content of dielectric liquids (such as in transformers or other electric apparatus or processing equipment.) Such liquids are herein referred to as "oils."

The *DOMINO*® Moisture-In-Oil sensor contains a thin polymer film that is immersed in the sample. That capacitance of this film changes in proportion to the change in relative saturation of water in the oil. Electronics in the Moisture-In-Oil Probe measure the capacitance of the sensor and convert it into a relative saturation reading.

The Moisture-In-Oil Probe also contains a temperature sensor. By using the sample temperature and the programmed characteristics of the particular type of oil, the sensor can calculate the current maximum solubility of water. Knowing both the current relative saturation and the maximum solubility of water, the probe can then calculate the mass concentration of water in the sample.

About the *DOMINO*® Moisture-In-Oil Sensor

The *DOMINO*® Moisture-In-Oil sensor is composed of an upper and lower electrode, a thin film polymer and a support base.



As the oil flows over the sensor, water vapor penetrates the upper electrode and reaches the thin-film polymer.

The amount of water vapor absorbed is dependent on the relative saturation of water in the oil. The polymer used for this application is dispersive, that is, its dielectric constant changes with changing water content.

The capacitance of the polymer, which is the dielectric constant of the material divided by the dielectric constant of vacuum (which is 1), is used to determine the relative saturation (RS) of water in the oil.

NOTE

Because the sensor relies on the movement of water molecules to and from the thin film polymer, oil flow around the sensor greatly facilitates this process. Little or no oil flow around the sensor will give low readings below the true water content.

Relative Saturation

Relative saturation (RS) is the actual concentration of water in the oil (W_c) relative to the maximum amount of water the oil can hold or saturation (S.) This can be expressed as follows:

$$\text{(Equation 1)} \quad RS = W_c / S (100\%)$$

Where: RS is the Relative saturation in %
Wc is in ppm wt./wt.
S is in ppm wt./wt.

Note that the *DOMINO*® moisture-in-oil sensor does not have to use this equation to calculate relative saturation. The relative saturation is measured directly by the sensor itself and the Moisture-In-Oil Probe converts the measurement to a percentage and displays that. However the relationship shown in Equation 1 will prove useful in determining another useful quantity, namely water content.

Water Content

The actual concentration of water in the oil (W_c) can be calculated from the measured relative saturation (RS) if the saturation concentration of the oil (S) are known. This is easily done by rearranging Equation 1 to solve for W_c .

$$\text{(Equation 2)} \quad W_c = RS / S (100\%)$$

Where: W_c is in ppm wt./wt.
RS is the Relative saturation in %
S is in ppm wt./wt.

There are two quantities required to solve Equation 2:

- The relative saturation (RS) is measured directly by the sensor.
- The saturation concentration of the oil (S) has the following logarithmic relationship to the temperature of the oil:

$$\text{(Equation 3)} \quad \text{Log } S_o = (\text{Coefficient A})/K + \text{Coefficient B}$$

Where: S_o is the solubility of water (in ppm)
K is the temperature in Kelvin ($^{\circ}\text{C} + 273$)
Coefficient A = a constant specific to the oil type
Coefficient B = a constant specific to the oil type

There are three quantities required to solve Equation 3:

- The temperature (K) is measured directly by the sensor.
- The two coefficients (Coefficient A and Coefficient B) that are specific to each oil type are experimentally determined and are known for numerous types of oils. The DOMINO® USS Moisture-In-Oil Probe is pre-programmed with the proper coefficients for four common oil types. For more information on the selecting, changing, and determining coefficients for unknown oil types, see Chapter 17, Changing Moisture-In-Oil Settings on page 99.

Once the temperature is measured, and an oil type selected, the actual solubility is calculated. That result is used with the measured relative saturation to solve Equation 2 and display the water content.

System Components

The *DOMINO*® USS Moisture-In-Oil System (Doble Part Number 03D-1647-01) includes the following components in a rugged high-density polyethylene carrying case.



USS Moisture-In-Oil Probe



USS Indicator



Indicator Universal Power Adapter



Protective cap



Plastic wrench



Manual press tool



USS Manifold
(has 2" NPT bushing)



1" NPT to
1/2" NPT bushing



NPT-ISO adapter
(used in pressure applications)



Spare quick connect plug

CHAPTER 5

THE *DOMINO*® USS DEWPOINT SYSTEM

This chapter contains information on
the *DOMINO*® USS Dewpoint System.

Topics in this chapter...

About The *DOMINO*® USS Dewpoint System

Measured Variables

System Components

About The **DOMINO®** USS Dewpoint System

The **DOMINO®** USS Dewpoint system measures dewpoint temperature accurately in a temperature range from -60 °C (-76 °F) up to +20 °C (+68 °F.) The **DOMINO®** USS Dewpoint Probe incorporates advanced **DOMINO®** technology, which enables reliable and high-performance dewpoint measurements.

The **DOMINO®** USS Dewpoint System (Doble Part Number 03D-1677-01) contains an Indicator and universal AC/DC adapter, one Dewpoint Probe, **DOMINO®** Connects software and interface cable, printed User Guide, and adapters to interface the included probe, all in a rugged polyethylene carrying case. The case can hold an additional two Moisture-In-Oil probes.

Measured Variables

The **DOMINO®** USS Dewpoint system can measure the following:

Symbol	Variable	Units
$T_{d/f}$	dewpoint/frost point (See note 1 below)	°C/°F
T_d	dewpoint temperature (See note 2 below)	°C/°F
T	temperature	°C/°F
$T_{d/f}$	dewpoint/frost point in the atmospheric pressure	°C atm/°F atm
T_d	dewpoint in the atmospheric pressure	°C atm/°F atm
RH	relative humidity	%
H ₂ O	humid air /dry air	ppm _v /ppm _w

- Note 1. $T_{d/f}$ shows the dewpoint temperature above the freezing point (0 °C/32 °F) and frost point temperature T_o (dewpoint over ice) below the freezing point. This is considered as the industry standard.
- Note 2. T_d shows the dewpoint over water throughout the entire measurement range.

System Components

The DOMINO® USS Dewpoint System (Doble Part Number 03D-1677-01) includes the following components in a rugged high-density polyethylene carrying case.



USS Dewpoint Probe



Sampling cell
(installed at factory)



USS Indicator



Indicator Universal Power Adapter



NIP08, type D
quick connect adapter
(installed at factory)



Type 3/8" - 1/4"G
adapter



Type 3/8" - 1/2"G
adapter

This page intentionally left blank.

CHAPTER 6

THE *DOMINO*® USS COMPLETE SYSTEM

This chapter contains information on
the *DOMINO*® USS Complete System.

Topics in this chapter...

About The *DOMINO*® USS Complete System

Measured Variables

System Components

About The **DOMINO®** USS Complete System

The **DOMINO®** USS Complete system measures:

- Moisture-in-oil concentrations accurately in a temperature range from -40 °C (-40 °F) up to +60 °C (+140 °F.) The **DOMINO®** USS Moisture-In-Oil probe incorporates advanced **DOMINO®** technology, which enables reliable and high-performance moisture-in-oil measurements.
- Dewpoint temperature accurately in a temperature range from -60 °C (-76 °F) up to +20 °C (+68 °F.) The **DOMINO®** USS Dewpoint Probe incorporates advanced **DOMINO®** technology, which enables reliable and high-performance dewpoint measurements.

The **DOMINO®** USS Complete System (Doble Part Number 03D-1677-01) contains an Indicator and universal AC/DC adapter, two Moisture-In-Oil Probes, one Dewpoint Probe, **DOMINO®** Connects software and interface cable, printed User Guide, Moisture-In-Oil Quick Start Guide, and adapters to interface the included probe(s), all in a rugged polyethylene carrying case.

Measured Variables

For a listing of the variables that can be measured using the included Moisture-In-Oil Probes, see Chapter 4, The **DOMINO®** USS Moisture-In-Oil System on page 15.

For a listing of the variables that can be measured using the included Dewpoint Probe, see Chapter 5, The **DOMINO®** USS Dewpoint System on page 21.

System Components

The *DOMINO*® USS Dewpoint System (Doble Part Number 03D-1677-01) includes the following components in a rugged high-density polyethylene carrying case.



Two (2) USS Moisture-In-Oil Probes



USS Dewpoint Probe



Sampling cell
(installed at factory)



USS Indicator



Indicator Universal Power Adapter



Moisture-In-Oil Probe accessories
(see page 23)



Dewpoint Probe accessories
(see page 27)

This page intentionally left blank.

SECTION 2

WORKING WITH THE INDICATOR

This section contains information on configuring and using the *DOMINO*® USS Indicator.

Chapters in this section...

- Chapter 7 Indicator Quick Start
- Chapter 8 About The Indicator
- Chapter 9 Configuring The Indicator
- Chapter 10 Working With Data
- Chapter 11 Recording Data
- Chapter 12 Error Messages
- Chapter 13 Indicator Maintenance

This page intentionally left blank.

CHAPTER 7

INDICATOR QUICK START

The *DOMINO*® USS Indicator is a portable hand held device used to read and control *DOMINO*® USS probes.

The first time out of the case, follow these steps:

1. **Charge the Indicator.**

For more information see the topic Charging The Battery Pack on page 69.

CAUTION

DO NOT use the Indicator during the first charging cycle. The Indicator CAN be used during subsequent charging cycles.

2. **Press the Power On/Off button to turn on the Indicator.**

You may be automatically prompted to select the user interface language and set the date and time per the steps below.

If a probe is not connected you may be prompted to turn off the Indicator and connect a probe. That is not necessary to perform the steps below.

3. **Select the user interface language.**

The Indicator is shipped with English set as the default user interface language. If that is acceptable you can skip this step. For more information see the topic Selecting The Interface Language on page 40.

4. **Set the date and time.**

As the Indicator is shipped with the battery uncharged it does not have the current time and date stored. Set these values now. For more information see the topic Setting The Date And Time on page 44.

The Indicator is now ready for use.

This page intentionally left blank.

CHAPTER 8

ABOUT THE INDICATOR

This chapter contains general information on the *DOMINO*® USS Indicator.

Topics in this chapter...

About The Indicator

Connections And Controls

The Basic Display

Using The Keypad

The Indicator Menus

About The Indicator

The *DOMINO*® USS Indicator is a portable hand held device used to read and control *DOMINO*® USS probes.

The Indicator has the following features:

Numerical and graphical display of measured variables.

Up to three variables can be displayed at any one time and the user can switch back and forth to a real time graphical display of one of them. For more information see the topic Displaying Data Graphically on page 52.

Data recording capability.

The Indicator can record up to 2700 data points of any measured quantity. For more information see the Chapter 11, Recording Data on page 59.

Analog voltage output signal.

The Indicator can output an analog voltage between 0 to 1 Volt that is proportional to any of the measured variables. For more information see the topic Using The Analog Output on page 56.

Dual probe capability.

The Indicator can read and control two probes simultaneously. For more information see the topic Viewing Data From Two Probes on page 50.

Dual power source capable.

The Indicator is normally powered by a rechargeable NIMH battery pack but can also run off of four AA alkaline batteries. For more information see the topic Chapter 13, Indicator Maintenance on page 67.

Easy PC connectivity.

DOMINO® Connects, a Microsoft Windows® environment software program included with all USS systems, allows you to use a PC to monitor and configure the Indicator and to download recorded data. For more information see the topic Chapter 26, Using *DOMINO*® Connects on page 157.

Connections And Controls


The USS Indicator has the following connections and controls:



If a single probe is used it can be connected to either port.

The Basic Display

When the Indicator is turned on, the quantities currently selected display. The example below is when a Dewpoint Probe is attached.



The following numbers refer to the callouts above.


- 1 The state of the battery.
- 2 The pressure settings (for Dewpoint Probes only.)
- 3 The currently selected quantities. Up to three quantities can be displayed at a time. For more information see the topic Specifying The Displayed Quantities And Units on page 48.
- 4 The **Graphic** shortcut button that changes the display into a curve mode. For more information see the topic Displaying Data Graphically on page 52.
- 5 The **Hold/Sa** shortcut button that holds the display and allows you to save the reading into memory. For more information see the topic Holding And Saving The Data Display on page 51
- 6 The **Record** shortcut button that takes you to the Recording/Viewing menu. For more information see the topic Recording Data on page 60.

NOTE

The **Graphic**, **Hold/Sa** and **Record** shortcut buttons are the factory defaults. You can change them to refer other functions. For more information see the topic Changing The Shortcut Keys on page 42.

Using The Keypad

Use the keypad below the display to operate the Indicator.



POWER ON/OFF
button

Press to turn the Indicator on or off



SHORTCUT
buttons

Press to activate the function shown above the button.



ARROW buttons

Press any of the **ARROW** buttons, then press any of the **SHORTCUT** buttons to open the main MENU.

In the MENU press the **ARROW** buttons to navigate.

The Indicator Menus

The Indicator has several menus that allow you to control how data is collected, managed, displayed, used, and stored.




Main menu



Display menu



Settings menu



Functions menu



Recording/Viewing menu



Environment menu

Display and navigate within these menus as follows:

To open the main menu

press any of the     buttons.
Then press  OPEN within 5 seconds.

Otherwise, the basic display returns.
If this happens, start from step 1 again.

To move up or down in the menus

press either the  or the  button.

To open a selected sub-menu

press 

To return to the previous menu

press 

To return to the main data display

press  EXIT

CHAPTER 9

CONFIGURING THE INDICATOR

This chapter contains information on configuring the *DOMINO*® USS Indicator.

Topics in this chapter...

- Selecting The Interface Language
- Configuring Automatic Power Off
- Changing The Shortcut Keys
- Setting Button Press Sounds
- Setting Backlight On Button Press
- Setting The Date And Time
- Restoring The Factory Settings

Selecting The Interface Language

You can select any of the following languages as an user interface language: English, German, French, Finnish, Spanish or Swedish.

To select the user interface language:

1. Open the MENU: by pressing   OPEN.
2. Select ►Settings, then press .
3. Select ►User interface, then press .
4. Select Language, then press  SET.
5. Select the language you want, then press  SELECT.
6. Press  EXIT to return to the basic display.

If you accidentally select a wrong language, to change the setting:

1. Return to the basic display by pressing right most  key as many times as required.
2. Go to the language selection menu by pressing: , then the middle  key.
3. Press , then press , then press , then press the middle  key.
4. Reselect the language.

Configuring Automatic Power Off

By default, the USS Indicator will turn off the power automatically after 15 minutes of inactivity to conserve the battery. You can leave the inactivity time setting at 15, change it to 60 minutes, or turn off the automatic power off function completely.

To change the automatic power off function setting:

1. Open the MENU: by pressing   OPEN.
2. Select  Settings, then press .
3. Select  User interface, then press .
4. Select Auto power off, then press  SET.
5. Select the choice you want, then press  SELECT.
6. Press  EXIT to return to the basic display.


Changing The Shortcut Keys

By default, the three shortcut keys refer to the functions Graphic, Hold/Save and ►Record. You can change any of the shortcut keys to refer to functions that better suit your needs.

To change any of the shortcut key s functions:

1. Open the MENU: by pressing OPEN.
2. Select ►Settings, then press .
3. Select ►User Interface, then press .
4. Select Program shortcut keys, then press START.
5. Press the shortcut key you want to change, e.g. Hold/Save.
6. If you want to replace Hold/Save with alarm-function (as an example), select Alarm by using arrow buttons (►Functions), press SELECT.
Answer YES to confirm your selection, otherwise answer NO and continue from item 4.
7. Press EXIT to return to the basic display.

The selected key is changed as specified. For example:



Setting Button Press Sounds

To turn on or off the sound effects for the buttons:

1. Open the MENU: by pressing   OPEN.
2. Select ►Settings, then press .
3. Select User interface, then press .
4. To turn OFF or ON sound effect while pressing the buttons, select Key Click and then press  ON/OFF.
5. Press  EXIT to return to the basic display.

Setting Backlight On Button Press

To turn on or off the back light:

1. Open the MENU: by pressing   OPEN.
2. Select ►Settings, then press .
3. Select User interface, then press .
4. To turn OFF and ON backlight while pressing the buttons, select Backlight on key and then press  ON/OFF.
5. Press  EXIT to return to the basic display.

Setting The Date And Time

The current date and time are used in the recorded data files.

By default the time format is based on the 24-hour clock but a 12-hour clock can be used. By default the date format is day.month.year, for example, 25.4.2004. The date format can be changed to month.day.year. or year.month.day.

To set the date or time or change the format of either one:

1. Open the MENU: by pressing   OPEN.
2. Select **►Setting**, then press .
3. Select **►Date and time**, then press .
4. To change the date, select **Date** and press  SET. Change the date by using arrow buttons. To confirm the date, press  OK. The default date presentation format is *year-month-date*, e.g.2002-06-05. If you want to change the format, select **Date format: Y-M-D**, press SET , select either **D.M.Y** or **M/D/Y**, press SELECT .
5. To change the time, select **Time** and press  SET. Change the time by using arrow buttons. To confirm the time, press  OK. The default time presentation format is 24-hour clock. If you want to change the format, select **12-hour clock**, press  ON/OFF.
6. Press  EXIT.

Restoring The Factory Settings

The factory settings can be restored to clear all the changed settings and clear data memory of the Indicator. Note that restoring the factory settings does not affect the probe calibration.

To revert to factory settings:

1. Open the MENU: by pressing   OPEN.
2. Select ►Settings, then press .
3. Select Factory settings, then press  REVERT.
4. Press  YES to confirm the reverting.

The power turns off automatically.

When switching on again, the factory settings are restored.

Anything stored in the data memory is deleted.

You will need to set the language (see page 40) and date and time (see page 44) again.

This page intentionally left blank

CHAPTER 10

WORKING WITH DATA

This chapter contains information on working with the data gathered by the *DOMINO*® USS Indicator.

Topics in this chapter...

Specifying The Displayed Quantities And Units

Specify Data Display Rounding

Viewing Data From Two Probes

Holding And Saving The Data Display

Displaying Data Graphically

Viewing Device Information

Setting Alarm Levels

Selecting And Scaling The Analog Output

Specifying The Displayed Quantities And Units


The Indicator can display up to three measured quantities at a time.

- The quantities that can be displayed for Moisture-In-Oil probes are listed in the topic Measured Variables on page 16.
- The quantities that can be displayed for Dewpoint Probes are listed in the topic Measured Variables on page 22.


The unit of temperature quantities ($T_{d/f}$, T_d , or T) can be selected to be °C or °F. The default is °C.

To select a quantity to display or to specify displayed units:

1. Open the MENU by pressing OPEN.
2. Select Display, then press .



3. Select Quantities and units, then press .



4. In the QUANTITIES AND UNITS screen you can do any of the following:
 - To select a quantity, move on the quantity you want by using the arrow buttons, press SELECT. Only three quantities and units can be visible on the display at one time.

- To change the unit, move on the quantity you want by using the arrow buttons, then press \ominus UNIT (°C or °F.)

NOTE

The units °C atm and °F atm indicate that the dewpoint or frost point is converted from process pressure to atmospheric pressure.

- To hide a quantity, move on the quantity you want to hide by using the arrow buttons, then press \ominus HIDE.
5. To return to the basic display, press \ominus EXIT.
 6. If you want to check environment settings press \ominus YES.
If you do not want to check environment settings press \ominus NO.

Specify Data Display Rounding

You can select a one- or two-decimal display using Rounding.
As a default, rounding is turned off, i.e. a two-decimal display is in use.

To specify rounding:

1. Open the MENU by pressing $\triangleright \ominus$ OPEN.
2. Select the \triangleright Display, then press \triangleright .
3. Select Rounding.
4. To have rounding on (one decimal display), press \ominus ON.
To have rounding off (two decimal display), press \ominus OFF.
5. To return to the basic display, press \ominus EXIT.

NOTE

Rounding does not affect the measurement accuracy. Accuracy is defined separately for the Indicator, Moisture-In-Oil probe, and Dewpoint Probe in Chapter 27, Technical Specifications.

Viewing Data From Two Probes

The USS Indicator can be used with either one or two Moisture-In-Oil or Dewpoint Probes in any combination.

When using two probes (of either the same or different types) the display shows the reading of the port I probe in the upper row(s) and the reading of the port II in the lower row(s.)

Each variable is marked to indicate the port it is being read from:

- Variables measured with Port I are marked with **I**
- Variables measured with Port II are marked with **II**

For example if two dewpoint probes are connected to the Indicator and each is set to display RH, the display will show:



NOTE

Always have the Indicator OFF when connecting or disconnecting probes.

- Connecting a probe when the Indicator is on may interfere the Indicator recognizing the probe.
- Disconnecting a probe when the Indicator is on may cause loss of settings and data.

NOTE

When using two Dewpoint Probes, if you are taking measurements from the same condition, check that the pressure settings of the two probes are the same.

Holding And Saving The Data Display

You can freeze a selected display reading and save it into the memory using the Hold/Save function.

Several readings can be saved. The reading saved first is called data point 1, the second saved reading is called data point 2, and so on. All the individual readings (data points) are stored in the same file marked with . The file will remain in the Indicator memory even when the Indicator is switched off.

To freeze a display reading and save it into memory:

1. Open MENU by pressing   OPEN.
2. Select  Display, then press .
3. Select Hold/Save display.
4. To freeze the display, press  HOLD.
The frozen measurement data is displayed.
5. To save the displayed reading, press  SAVE.
To return to the basic display, press  CANCEL.

You can save several readings with HOLD-SAVE function. The data points are identified on the basis of the saving date and time. All the individual readings (data points) are stored in a same file marked with . The file remains in the Indicator memory even if the Indicator is switched OFF.

6. To view the saved readings, press   Record, then select  View recorded data, then press . Select the file marked with , press . Now you can see the saved data readings.
7. To view the recording timestamps press  TIMES.
8. To return to the basic display, press  EXIT.

Displaying Data Graphically

You can display the data from the last hour graphically. The graphical display shows the curve of the uppermost quantity shown in the basic display.

From the curve, you can examine the data trend and history of the last minutes.

By default the data curve of the last hour is displayed. To see longer graphs, use the data recording function to save the data and then view it as a graph.

To display the data in graphical format:

- Press \ominus GRAPHIC. Or,
- Open the MENU by pressing $\triangleright \ominus$ OPEN. Select \blacktriangleright Display, then press \triangleright . Select Graphic history, then press \ominus SHOW.

When the graphic display is shown you can do any of the following:

To get the statistical info on the graph area (minimum, maximum and mean values)

- Press \ominus INFO.

To get the curve of the NEXT quantity that is displayed in the numerical display:

- Press \ominus NEXT.

To get the curves of ALL quantities that are displayed in the numerical display:

- Press \ominus NEXT until text ALL is shown instead of NEXT.
Then press \ominus ALL.

To zoom in on the curve:

- Press the arrow button \triangle .

To zoom out:

- Press the button ∇ .

To move the curve in horizontal directions:

- Press the buttons \leftarrow \rightarrow .


To return to the basic display:

- If you entered the graphical display through the menu, press \ominus BACK, then press \ominus EXIT.
- If you entered the graphical display through the GRAPHIC shortcut key, just press \ominus BACK.


Viewing Device Information

To view basic information about the Indicator and the attached probe(s):

1. Open the MENU: by pressing \rightarrow \ominus OPEN
2. Select \rightarrow Settings, then press \rightarrow .



3. Select Device information, then press \ominus SHOW.
The first display gives the information on the Doble USS Indicator.



Indicator information

Probe information


4. To get the information on the probe, press \ominus MORE.
5. To return to the basic display, press \ominus OK and the press \ominus EXIT.

Setting Alarm Levels

The *DOMINO*® USS Indicator alarms by beeping and blinking the backlight. The alarm turns on when the measured value is not between the alarm limits (permissible area.) Alarm level(s) can be set for only one quantity at a time.

To set the alarm levels:

1. Open the MENU: by pressing OPEN.
2. Select Functions, then press .
3. Select Alarm, then press .



4. Select Quantity and press SET to choose a quantity.
5. Select quantity, press SELECT. Note that only one quantity can be chosen at a time and only active quantities can be selected. To change the active quantities, go to MENU→ Display→ Quantities and units.
6. Select the first limit, press SET (if the alarm function is ON, take it OFF.) Set the alarm level by using arrow buttons. To select the sign for the alarm level, press +/- button. Press OK to save the setting.

7. Select the second limit, then follow instructions in step 6.

The alarm will go off when the upper limit is exceeded or when lower limit is gone below.

If you have only one limit, e.g. if you want to detect when a measured quantity exceeds a maximum, set the upper limit to that value and the lower limit so low that it never will be reached (for example 0.) For example:

- If you are measuring Relative Saturation and want the alarm to sound when the RS reaches 90%, then set the upper limit to 90% and the lower limit to 0. The USS Indicator will alert when RS rises above 90%.
 - If you are measuring dewpoint and want the alarm to sound when the dewpoint rises above -40 °C, then set the upper limit to -40 °C and the value of the lower limit so low that it will never be reached, for example, to -80 °C. The USS Indicator will alert when the dewpoint rises -40 °C.
8. Select Alarm ON/OFF, press  ON to activate the alarm and return back to the basic display.
 9. A note picture sign  appears on the upper left corner of the display.
 10. When the alarm level is reached, you can stop alarming by pressing  OK. To reactivate the alarm function, answer  YES. To stop the alarm function completely, answer  NO.

NOTE

The alarm is not in function when the device is turned off.
Remember to turn off the automatic power off, see page 41.

Using The Analog Output

You can output one selected quantity as a scaled analog voltage in the range 0 to 1.0V. The output can be scaled in any range of measurements,, i.e. any measured values can be set as the 0 volt and 1.0 volt levels.

NOTE To get analog measurement data, you need the analog output signal cable, Doble Part Number 181-0659.

NOTE Because the analog output signal cable connects to one of the probe ports, you can only use one probe when using the analog output.

To select and scale the analog output:

1. Plug the probe into either Port I or Port II of the Indicator.
2. Install the probe in the measurement position.
3. Turn on the Indicator.
4. Plug the analog output signal cable circular connector to the Indicator base connector. Connect the screw terminal block as follows:

Brown wire: common wire (-)
Yellow-green wire: signal (+)

5. Open the MENU: by pressing OPEN.
6. Select ►Functions, press .
7. Select ►Analog output, press .



8. Select Quantity and press SET to choose a quantity.

9. Select Quantity, press \ominus SELECT.

Only one quantity can be chosen at a time.

Only active quantities can be selected.

To change the quantities, go to MENU→Display→Quantities and units.)

10. To set the value for the 0.0V output signal, select 0.0 V, then press \ominus SET.
(If the analog output is ON, take it OFF) Set the low value by using arrow buttons. Press \ominus +/- button to choose the sign of the value. Press \ominus OK to confirm the setting.
11. To set the value for the 1.0V output signal, select 1.0V, then press \ominus SET.
Set the high value by using arrow buttons. Press \ominus +/- button to choose the sign of the value. Press \ominus OK to confirm the setting.
12. To activate the analog output and return back to the basic display, select Analog output on/off, then press \ominus ON. A wave picture sign \approx appears on the upper left corner of the basic display.
13. To deactivate the analog output function, go to MENU→Functions→Analog output→Analog output on/off and press \ominus OFF.

This page intentionally left blank.

CHAPTER 11

RECORDING DATA

This chapter contains information on recording, saving, and transferring the data gathered by the *DOMINO*® USS Indicator.

Topics in this chapter...

Recording Data

Stopping Recording

Viewing Recorded Data

Checking The Memory Status

Deleting All Recorded Files

Transferring Recorded Data To A PC

Monitoring Real time Data On A PC

TIP

In addition to recording real-time data you can also record individual data points. For more information see the topic Holding And Saving The Data Display on page 51.

Recording Data

You can record the displayed quantities to a file saved in the Indicator's memory.

To start recording:

1. Do one of the following:
 - Press the shortcut \ominus ▶Record. Or,
 - Open the MENU by pressing \triangleright \ominus OPEN, then select ▶Recording/Viewing.
2. Select ▶Record data, then press \triangleright .



3. To change the recording interval, select Interval, then press \ominus SET. Then select the measurement interval with arrow buttons. Then press \ominus SELECT.

Measurement intervals and the maximum recording times are shown in the table below.

Recording interval	Maximum recording time (memory full)		
	1 quantity	2 quantities	3 quantities
1 seconds	45 minutes	22 minutes	15 minutes
5 seconds	3 hours	113 minutes	75 minutes
15 seconds	11 hours	5 hours	3 hours
30 seconds	22 hours	11 hours	7 hours
1 minutes	45 hours	22 hours	15 hours
5 minutes	9 days	4 days	3 days
15 minutes	28 days	14 days	9 days
30 minutes	56 days	28 days	18 days
1 hours	113 days	56 days	37 days
3 hours	339 days	169 days	112 days
12 hours	1359 days	678 days	451 days

4. To set the recording duration, select **Duration**, press  **SET**.
Select a recording duration (1 min, 5 min, 15 min, 30 min, 1 h, 3 h, 12 h, 24 h, 7 d, 30 d, memory full) with the arrow buttons, then press  **SELECT**.
5. To start recording, select **Start/Stop recording**, then press  **START**.

During recording the following symbols appear next to the battery indicator in the upper left corner of the display:



Indicates recording is in progress.



Displays the amount of recorded data in terms of the remaining memory (not the total memory) that is available.

TIP

You can switch the *DOMINO*® USS off during recording to save the battery. A message will appear on the display to inform you that recording will continue undisturbed even when the power is turned off. If the Indicator is switched off during recording, the progress bar is shown on the display every 10 seconds or continuously if the charger is connected.

CAUTION

Do not disconnect the probe when the data recording is on, even if the Indicator is off. This may cause loss of recorded data.

Stopping Recording

To stop recording:

1. Do one of the following:
 - Press the shortcut  ►Record. Or,
 - Open the MENU by pressing   OPEN, then select ►Recording/Viewing.
2. Select ►Record data and press 
3. Select Start/Stop recording and press  STOP.
4. To view the recorded file, press  SHOW.

Viewing Recorded Data

To view recorded data:

1. Open the MENU: by pressing   OPEN .
2. Select ►Recording/Viewing, then press .
3. Select ►View recorded data, then press .
4. Select the file you want to view, then press . The files are identified according to the starting date and time of recording.
5. To go to the graphical view, press  Graph. To view the recording time stamps, press  Times. To return to the recording values, press  Values.
6. To return to the basic display, press  EXIT .

Checking The Memory Status

To check how much free space is remaining in the memory:

1. Open the MENU: by pressing   OPEN .
2. Select ►Recording/Viewing, press .
3. Select Memory status, press  SHOW. The amount of memory in use and the estimated free space is displayed.
4. To return to the basic display, press  OK and  EXIT.

Note that the estimation of the free space is calculated based on the current number of active quantities. If you change the displayed quantities, this will effect the estimation of free space.

Deleting All Recorded Files

To delete all recorded files and clear the data memory:

1. Open the MENU: by pressing   OPEN.
2. Select ►Recording/Viewing, then press .
3. Select Clear data memory, then press  CLEAR.
4. Press  YES to confirm deletion of all recorded data files.
5. To return to the basic display, press  EXIT.

Transferring Recorded Data To A PC

The recorded data can be transferred to a PC by using the *DOMINO*® Connects program. You can examine the recorded data easily in the Microsoft Windows® environment and transfer it to a spreadsheet program (such as Microsoft® Excel) to be modified. For more information see the topic Chapter 26, Using *DOMINO*® Connects on page 157.

DOMINO® Connects is included with the USS Moisture-In-Oil System, the USS Dewpoint System, and the USS Complete System. It can also be ordered separately as Doble Part Number 401-0288.

Monitoring Real time Data On A PC

You can monitor the USS Indicator readings directly with a PC by using the *DOMINO*® Connects program. For more information see the topic Chapter 26, Using *DOMINO*® Connects on page 157.

DOMINO® Connects is included with the USS Moisture-In-Oil System and the USS Dewpoint System. It can also be ordered separately as Doble Part Number 401-0288.

CHAPTER 12

ERROR MESSAGES

This chapter contains information on the various error message that may appear on the *DOMINO*® USS Indicator.

Topics in this chapter...

What To Do With Errors

Types Of Error Messages

What To Do With Errors

If the *DOMINO*® USS Indicator displays an error message:

1. Check that the sensor is connected properly.
2. Remove the probe. If there is condensed water in the probe let it dry.
3. If the error persists, contact the Doble Customer Service Center (see page 6.)

Types Of Error Messages

- Eeprom read/write error
- ADC malfunction
- Operating voltage out of range
- Analog voltage out of range
- Temperature/Humidity sensor open/short circuit
- Temperature sensor current leak
- Temperature/humidity measurement malfunction
- Temperature value out of range
- Relative humidity value out of range
- Sensor not found
- Amplifier chain malfunction

CHAPTER 13

INDICATOR MAINTENANCE

This chapter contains information on servicing the *DOMINO*® USS Indicator.

Topics in this chapter...

- Viewing The Battery Level
- Charging The Battery Pack
- Replacing The Battery Pack
- Using Alkaline Batteries

Viewing The Battery Level

To view the level of charge remaining in the battery:

- Turn on the Indicator.

When the quantities display appears, a symbol in the top left side corner indicates the level of charge in the battery.



The meaning of this symbol is:

-  Full charge
-  Partial charge
-  No charge

Charging The Battery Pack

To charge the battery pack:

1. Ensure the Indicator is turned off.
2. Fit the proper plug insert based upon your location (Australian, European, United Kingdom, or American) to the recharger body.
3. Connect the recharger to a wall socket.
4. Remove the plug from the power inlet at the top of the Indicator and plug the recharger connector into the power inlet.

CAUTION

Do not use the Indicator during the first charging cycle.

The Indicator CAN be used during subsequent charging cycles.

A battery symbol in the corner of the display will start to roll.

The duration of the recharging cycle depends on the charge level of the battery pack with 4 hours being typical.

However, the recommended first charging time is 6 hours.

When the battery symbol stops rolling, the battery pack is fully charged.


5. Disconnect the recharger from the Indicator and from the wall socket.

Replacing The Battery Pack

NOTE

The battery pack is Doble Part Number 903-0083.

To replace the battery pack:



1. Unscrew the back plate of the Indicator and remove the back plate.
2. Lift out the old battery pack.
3. If you are replacing alkaline batteries with a battery pack, remove the metal contact.
4. Detach the black connector by pulling it up carefully by the wires.
5. Connect the black connector of the new battery pack. Make sure the red and black wires are on the upper edge of the connector. Do not push the connector with any conducting material.
6. Fit the battery pack into the Indicator.
7. Fit the back plate back on the Indicator and tighten the screw.
8. Charge the battery pack before use. For more information see the topic Charging The Battery Pack on page 69.




Dispose of batteries and the unit in accordance with all federal, state, and local regulations.

DO NOT dispose of with regular household refuse.

Using Alkaline Batteries

The USS Indicator can also use four standard AA size alkaline batteries.

**To replace the battery pack with alkaline batteries
or change the alkaline batteries:**



1. Unscrew the back plate of the Indicator and remove the back plate.
2. If you are replacing a battery pack, lift out the old battery pack.
If you are replacing existing alkaline batteries, lift out the old batteries.
3. If you are replacing a battery pack,
detach the black connector by pulling it up carefully by the wires.
4. If you are replacing the battery pack, install the metal contact.
5. Fit the new batteries into the Indicator following the diagram in the battery cavity..
6. Fit the back plate back on the Indicator and tighten the screw.



Dispose of batteries and the unit in accordance with all federal, state, and local regulations.

DO NOT dispose of with regular household refuse.

This page intentionally left blank

SECTION 3

MAKING MOISTURE-IN-OIL MEASUREMENTS

This section contains information on making moisture-in-oil (and related) measurements using:

- The *DOMINO*® USS Moisture-In-Oil System (Doble Part Number 03D-1647-01)
- The *DOMINO*® USS Complete System (Doble Part Number 03D-1686-01)
- The *DOMINO*® USS Dewpoint System (Doble Part Number 03D-1677-01) and a USS Moisture-In-Oil Probe(s) (Doble Part Number 03D-1678-01)

Chapters in this section...

- Chapter 14 Moisture-In-Oil Quick Start
- Chapter 15 Installing The Moisture-In-Oil Probe
- Chapter 16 Taking Moisture-In-Oil Measurements
- Chapter 17 Changing Moisture-In-Oil Settings
- Chapter 18 Calibrating Moisture-In-Oil Probes
- Chapter 19 Maintaining Moisture-In-Oil Probes

This page intentionally left blank

CHAPTER 14

MOISTURE-IN-OIL QUICK START

The *DOMINO*® USS Moisture-In-Oil System is a portable, simple to use system that enables reliable and high performance moisture-in-oil measurements.

The first time out of the case, follow these steps:

1. Charge and set up the USS Indicator.

For more information see Chapter 7, Indicator Quick Start on page 31.

2. Configure the Moisture-In-Oil Probe.

For more information see Chapter 17,
Changing Moisture-In-Oil Settings on page 99.

3. Select which measured variables to display.

For more information see the topic
Specifying The Displayed Quantities And Units on page 48.

4. Install the Moisture-In-Oil Probe.

For more information see Chapter 15,
Installing The Moisture-In-Oil Probe on page 77.

5. Take the moisture-in-oil reading.

For more information see Chapter 16,
Taking Moisture-In-Oil Measurements on page 97.

This page intentionally left blank

CHAPTER 15

INSTALLING THE MOISTURE-IN-OIL PROBE

This chapter contains information on several different methods of installing the *DOMINO*® USS Moisture-In-Oil Probe.

Topics in this chapter...

General Installation Considerations

Installation On A Drain Valve

Direct Installation On A Pressurized Process

Ball Valve Installation On A Pressurized Process

Unpressurized Installation

General Installation Considerations

Install In A Location That Gives A True Picture Of The Process

As oil should circulate freely around the sensor; a rapid oil flow is recommended. Install the probe directly into the circulation system and not into the oil reservoir where the oil is stagnant. Below are suggested flow rates:

- A minimum flow rate of 0.6 liters/minute is required for all applications.
- When sampling from a transformer valve, a flow rate of 1 liter/minute has been found to be optimal.
- When sampling from a pipe or pump discharge, flow rates between 11 to 190 liters/minute (3 to 50 gallons/minute) have been found to be optimal.

The USS can withstand flow rates much greater than that listed above, such as those found on high velocity pumps on transformers.

Install In An Area Of Positive Pressure

Install the probe in an area of positive pressure such as:

- the discharge side of a pump such as an oil processor.
Even in transformers where the whole system is under positive pressure, the area at the intake of the pump is at negative pressure so install the probe at the discharge end of the pump.
- a pressurized pipe.
- a drain valve.

Partial or full vacuum will not harm the sensor in any way so the sensor does not have to be removed when negative pressure is applied.

However the sensor will report low results when subjected to negative pressure because a vacuum system, when applied, attempts to remove moisture and gases from not just the oil but from all components that it is exposed to, including the probe sensor.

About The Quick Disconnect Plug Fitting

The Moisture-In-Oil Probe can be easily connected and disconnected using the included quick disconnect plug fitting.



The quick connect plug comes already mounted on the Moisture-In-Oil probe and can mate with:

- The *DOMINO*® USS Manifold assembly (Doble Part Number 03B-1653-01) that is used on a device's drain valve.
- A separate quick connect socket (Doble Part Number 09B-0824-01) that can be installed in various locations.

CAUTION

It is not recommended to use the quick connect fitting for permanent installations on transformers

NOTE

If the quick connect fitting is removed and then replaced it must be replaced at a certain distance away from the end of the probe in order to position the sensor in the correct position for minimal measurement response time. For more information see the topic Changing The Quick Connect Fitting on page 121.

About Direct Connection

The Moisture-In-Oil Probe is especially suitable for measurements in pipe. In these situations the quick connect fitting is removed and just the clasp nut and fitting body are used. The clasp nut and fitting body can be used to mount the probe in either of two ways:

Type of installation	Permanent Mount	Ball Valve
	 A 3D cutaway diagram showing a blue Moisture-In-Oil Probe mounted vertically on a grey T-shaped pipe. The probe's clasp nut is secured to the pipe, and the probe body extends deep into the pipe's interior.	 A 3D cutaway diagram showing a blue Moisture-In-Oil Probe mounted vertically on a grey T-shaped pipe. The probe's clasp nut is secured to the pipe, but the probe body is shorter, ending at a ball valve mechanism on the pipe's exterior.
Depth of insertion into the process	Provides maximum depth of insertion	Provides lesser depth of insertion
Probe removal	Process must be shut down to remove probe	Process does not have to be shut down to remove probe

Pressurized Process Recommendations

Install the sensor head directly in the process through a sampling manifold, a permanently installed fitting body, or a ball valve assembly. Do not use the quick connect fitting method for pressurized applications.

To avoid having to empty the process vessel or shut down the process, use the ball valve installation method.

To prevent loosening of the probe by the action of pressure, tighten the clamp nut and fitting body (if used) very carefully

Pipe Installation Recommendations

Install the sensor head transversely against the direction of the process flow.

Avoid installing into a bend in the pipe.

Treat The Entire Probe With Care

Take care not to damage the probe body

CAUTION

If the probe body is damaged, it will either not go through the fitting body, or the sensor within may be damaged.

Take care not to damage the probe shaft.

CAUTION

If the probe shaft is damaged, it will either not go through the fitting body, be loose in the clasp nut, or leak through the clasp nut seal.

Make sure that the perforated stainless steel filter at the end of the probe is tightly fastened.

CAUTION

If the perforated stainless steel filter is loose or comes off, damage to the sensor, the transformer, or the process being tested may result.

Installation On A Drain Valve

The *DOMINO*® USS Moisture-In-Oil Probe allows the user to measure the water content of mineral oil in a transformer or any other oil filled electrical device directly from the device's drain valve. Simply attach the *DOMINO*® USS Manifold Assembly and allow oil to flow past the *DOMINO*® sensor probe. Accurate readings are obtained in 2 to 3 minutes.

WARNING

Before using this device make absolutely certain there is positive pressure on the transformer. Opening the drain valve of a transformer under negative pressure will allow air to enter the transformer and may result in transformer failure and/or harm to personnel. If there is any doubt, use the procedure listed in ASTM D 923 or IEC 60475 to ascertain the condition.

CAUTION

Do not change the position of the quick connect plug on the oil probe. The quick connect plug is positioned to properly place the sensor element in the oil flow. Changing this position will increase the time it takes the sensor to stabilize and may damage the sensor.

To install and take readings on a drain valve:


1. Clean and prepare the drain valve as normally performed in order to take oil samples for analysis. To do this:
 - a. Take out the drain plug.
 - b. Wipe the inside of the valve with a clean cloth.
 - c. Flush at least one liter of oil through the valve.

If unsure how to perform this procedure consult ASTM D 923 or IEC 60475.


2. Connect the USS Manifold Assembly to the drain valve.

The USS Manifold Assembly has a 2-inch NPT male thread bushing for use on drain valves with 2 inch NPT female threads.

- If the drain valve has a 1 inch NPT female thread, remove the 2-inch NPT reducing bushing from the USS Manifold Assembly and replace it with the supplied 1-inch NPT reducing bushing. Then install the manifold on the drain valve.
- If the drain valve has other size threads, remove the 2-inch NPT reducing bushing from the USS Manifold Assembly and replace it with a reducing bushing that fits the drain valve and has a 1/2 inch NPT female thread to fit the manifold. Then install the manifold on the drain valve.



3. Attach the oil probe by pulling back the sleeve on the quick connect socket on the USS Manifold Assembly and inserting the quick connect plug on the oil probe. Then release the sleeve.



4. Attach a piece of 1/4 inch (6mm) Tygon tubing to the USS Manifold Assembly hose barb. Place the other end in a waste container to capture the oil.

5. Plug the probe cable into either port on the bottom of the *DOMINO*® USS Indicator.
6. Turn on the Indicator. Make sure one of the parameters being displayed is “ppm”. For more information see Chapter 16, Taking Moisture-In-Oil Measurements.
7. Open the drain valve so that oil is flowing past the sensor at a rate of approximately 1 quart or liter per minute.

TIP

Judge the rate with a quart or liter bottle and the second hand on your watch.

8. Continue to allow oil to pass by the sensor until a stable ppm reading is reached. That is the water content of the oil.

TIP

The graphing function on the *DOMINO*® USS Indicator is an ideal way to monitor when the unit reaches a stable reading.

9. Once the water content is determined close the drain valve.

After closing the valve you can disconnect the USS Manifold Assembly to use it elsewhere.

CAUTION

DO NOT open the drain valve with the probe removed from the USS Manifold Assembly. If you do, oil will flow from both the hose barb AND the quick disconnect connector.

Direct Installation On A Pressurized Process

General Guidelines

The probe can be installed directly on a pressurized process or pipe through a permanently installed fitting.

NOTE

One drawback of this type of installation is that to remove the probe the process must be shut down and the fitting must be sealed. If you need to install and remove the sensor without shutting down the process, consider installing the probe to a permanently installed ball valve. For more information see the topic Ball Valve Installation On A Pressurized Process on page 89.

NOTE

The process pressure can be a maximum of 20 bars (290 psi.)

Procedure

To install the Moisture-In-Oil sensor directly:


1. Shut down the process.

NOTE


If you have already gone through this procedure once and a plugged threaded hole for the fitting body exists, remove the plug from the threaded hole and skip to Step 3.

If you have already gone through this procedure once and a plugged fitting body is already installed, remove the plug from the fitting body and skip to Step 4.

2. Prepare a threaded hole for the fitting body as shown.



3. Remove the fitting body from the clasp nut on the probe and install and seal in the threaded hole prepared in step 2.



4. Fit the probe through the fitting body and tighten the clasp nut hand tight. The probe should be able to slide freely through the nut and fitting body.

CAUTION

DO NOT damage the probe body when inserting through the fitting body,. If the probe body is damaged, it will either not go through the fitting body, or the sensor within may be damaged.

- Slide the probe into the measuring position.

CAUTION

The next several steps bleed the air from the system.
To minimize oil loss, perform as quickly as possible.


- Turn the process back on at a reduced pressure.
- Slightly loosen the clasp nut.

The air trapped in the system will escape around the probe shaft.

- When oil starts to leak around the probe shaft, tighten the clasp nut hand tight.

This should stop or greatly reduce the leakage.

- Fully tighten the clasp nut as follows:
 - Mark the fitting body and the clasp nut.
 - Tighten the clasp nut an additional 30°-40°.
 - To avoid over tightening, use the plastic wrench supplied with the probe.
 - If you have torque wrench, tighten the nut to 35±5 Nm (25±4 ft-lbs.)



- probe (13.5 mm (0.53 in) diameter)
- clasp nut (27 mm hex)
- pen
- fitting body (24 mm hex)

NOTE

DO NOT overtighten as you will damage the probe shaft and it may leak.

10. Turn the process pressure fully on.
11. Take the measurement. For more information see Chapter 16, Taking Moisture-In-Oil Measurements.
12. Shut down the process.
13. Completely loosen the clasp nut.
14. Remove the probe.
15. Seal the system in one of the following ways:
 - remove the fitting body and install a plug in the hole.
 - cap the open end of the fitting body.
To do this you can use the blanking plug and nut,
Doble Part Number 230-0226
16. Clean the probe in one of the following ways:
 - slide the clasp nut down the probe shaft.
Use the manual press tool if necessary. Or,
 - wipe the probe with soft cloth.
17. Restart the process.

Ball Valve Installation On A Pressurized Process

General Guidelines

The probe can be installed directly on a pressurized process or pipe through a permanently installed ball valve.

NOTE

One drawback of this type of installation is that the ball valve limits the distance that the sensor can extend into the process fluid. If you need to position the sensor further into the process than a ball valve installation permits, consider installing the probe to a permanently installed fitting. For more information see the topic Direct Installation On A Pressurized Process on page 85 .

NOTE

The process pressure can be a maximum of 20 bars (290 psi.)

Due to the tight sliding fit of the probe shaft in the clasp nut, once the Moisture-In-Oil Probe is installed and the ball valve opened, the probe can be easily inserted and removed from the pressurized process at pressures up to 10 bar (145 psi.)

CAUTION

At higher pressures (but below the sensor's maximum operational pressure of 20 bar (290 psi) the probe shaft to clasp nut seal may leak and the process must be shut down to insert the probe.

In a ball valve installation you can use:

- ball valve, Doble Part Number 230-0172
- a 1/2" NPT ball valve assembly with a ball hole of 14 mm diameter or more.

NOTE


When installing the ball valve:

- In pipe installations, the nominal size of the pipe must be at least 1 inch (2.54 cm) to accommodate the sensor head.
- The ball valve should be installed such that the sensor head is oriented transversely against the direction of the process flow.

Procedure

To install the Moisture-In-Oil sensor to a ball valve:

1. Probe
2. Clasp nut
3. Fitting Body
4. Ball valve
5. Pipe
6. Press tool
7. Groove indicating upper adjustment limit



1. Do one of the following:

- If the ball valve is not yet installed, shutdown the pressurized process or pipe, install the ball valve, close the ball valve, then restart the pressurized process. For more information, see the guidelines at the beginning of this section.

NOTE

You can use any 1/2" NPT ball valve assembly with a ball hole of 14 mm (0.550 inch) diameter or more such as Doble Part Number 230-0172.

- If the ball valve is already installed, go to the next step.

2. Do one of the following:
 - If the process pressure is greater than 10 bars (145 psi) then shut down the process.
 - If the pressure is lower than 10 bars (145 psi) there is no need to shut down the process. Go to the next step.
3. Install the manual press tool on the probe shaft near the probe body.

To do this, remove the socket head cap screws from the press tool, fit the two halves over the probe shaft, and reinstall the screws. Tighten the screws alternately and evenly, taking care not to cross thread the plastic threads in the press tool. Note that the press tool halves will still show a gap between them when fully tightened.

4. Loosen the clasp nut and fitting body and slide them to the end of the probe shaft. There is a groove on the shaft that indicates the end of the clasp nut travel.
5. Install the fitting body tightly to the ball valve.

CAUTION

DO NOT damage the probe body when inserting through the ball valve. If the probe body is damaged, it will either not go through the ball valve, or the sensor within may be damaged.

6. Tighten the clasp nut hand tight.
The probe should be able to slide freely through the nut and fitting body.
7. Open the ball valve.
8. Slide the probe into the measuring position using the manual press tool.

CAUTION

The next several steps bleed the air from the system.
To minimize oil loss, perform as quickly as possible.

9. Do one of the following:

- If you previously shut down the process, turn it back on at a reduced pressure.
- If you did not shut down the process, you may want to reduced the pressure.

10. Slightly loosen the clasp nut.


The air trapped in the system will escape around the probe shaft.

11. When oil starts to leak around the probe shaft, tighten the clasp nut hand tight.

This should stop or greatly reduce the leakage.

12. Fully tighten the clasp nut as follows:

- a. Mark the fitting body and the clasp nut.
- b. Tighten the clasp nut an additional 30°-40°.
 - To avoid over tightening, use the plastic wrench supplied with the probe.
 - If you have torque wrench, tighten the nut to 35±5 Nm (25±4 ft-lbs.)



1. probe (13.5 mm (0.53 in) diameter)
2. clasp nut (27 mm hex)
3. pen
4. fitting body (24 mm hex)

NOTE

DO NOT overtighten as you will damage the probe shaft and it may leak.

13. If the process is not at full pressure, restore full pressure now.

14. Take the measurement. For more information see Chapter 16, Taking Moisture-In-Oil Measurements.

15. Do one of the following:


- If the process pressure is more than 10 bars (145 psi) then shut down the process.
- If the pressure is lower there is no need to shut down the process.

16. Loosen the clasp nut with the plastic wrench approximately 30°-40°.
17. Slide the probe out to expose the groove that indicates the upper probe position using the manual press tool on the probe shaft.
18. Close the ball valve.
19. If the process has been shut down you can turn it back on now.
20. Remove the fitting body from the ball valve.
21. Clean the probe in one of the following ways::
 - slide the clasp nut and fitting body down the probe shaft. Use the manual press tool if necessary. Or,
 - wipe the probe with soft cloth.

Unpressurized Installation

To install the Moisture-In-Oil probe when the sample oil is not under pressure:

1. Loosen the clasp nut and fitting body just enough that they can slide on the probe shaft.
2. Slide the clasp nut and fitting body up the probe shaft.
3. Install the probe into measuring position.
4. Take the measurement. For more information see Chapter 16, Taking Moisture-In-Oil Measurements.
5. After stopping the measurement, clean the shaft. To do this:
 - slide the clasp nut and fitting body down the probe shaft. Use the manual press tool if necessary. Or,
 - wipe the probe with soft cloth.



This page intentionally left blank.

CHAPTER 16

TAKING MOISTURE-IN-OIL MEASUREMENTS

This chapter contains information on taking measurements using the *DOMINO*® USS Moisture-In-Oil Probe.

TIP

If you are using the *DOMINO*® USS Moisture-In-Oil system for the first time see Chapter 14, Moisture-In-Oil Quick Start on page 75.

NOTE

The Moisture-In-Oil probe must be set for the specific oil type you are testing. For more information see Chapter 17, Changing Moisture-In-Oil Settings on page 99.

NOTE

You must set which of the measured variable you want to display. For more information see the topic Specifying The Displayed Quantities And Units on page 48.

CAUTION

Do not use the sensor in heavily chlorinated or fluorinated fluids as this may permanently damage the sensor's polyamide film.

The actual procedure starts on the next page.

To take a Moisture-In-Oil measurement:

1. Connect the Moisture-In-Oil Probe to Indicator.
The Indicator should be off.
2. On the Indicator, press  POWER ON/OFF button.

NOTE

If you turn on the Indicator before connecting the probe, when you do attach the probe it will not be recognized by the Indicator.

3. Install the probe to the measuring position. For more information see Chapter 15, Installing The Moisture-In-Oil Probe starting on page 77
4. The basic display opens. Let the reading stabilize.

CAUTION

If you need to disconnect the probe from the Indicator, first press  POWER ON/OFF button to turn the Indicator OFF.

This ensures that all settings and data are saved properly.

CHAPTER 17

CHANGING MOISTURE-IN-OIL SETTINGS

This chapter contains information on the various settings that are necessary when taking moisture-in-oil measurements.

NOTE

The settings described in this chapter are stored in the *DOMINO*® USS Moisture-In-Oil Probe itself (not in the Indicator) and will be retained if the probe is used with a different Indicator.

Topics in this chapter...

About Oil Types

Changing The Default Oil Type

Testing New Oil Types

Adding New Oil Types

About Oil Types

The *DOMINO*® USS moisture-in-oil probe can be used in most hydrocarbon and silicone bases fluids.

CAUTION

Do not use the sensor in heavily chlorinated or fluorinated fluids as this may permanently damage the sensor's polyamide film.

Different types of transformer oils possess different water solubility characteristics. For maximum accuracy, the *DOMINO*® USS system uses an algorithm to calculate the moisture-in-oil ppm value. This algorithm uses two coefficients that are different for different types of oil. For more information on the calculation see the topic General Theory Of Operation on page 17.

The USS Indicator has been preset to four oil types:

Oil Type	Description	Coefficient A	Coefficient B
1	New and service-aged transformer mineral oil with a neutralization number < 0.18mg KOH/g.	-1567	7.0895
2	Very aged transformer mineral oil with a neutralization number >0.18 mg KOH/g.	-1469	7.1546
3	Silicone transformer oil	-1187	6.2906
4	Natural Ester transformer oil (such as Envirotemp® FR3 and Biotemp®.)	-743	5.5199

The default algorithm is Oil 1.


- If you are testing one of the other oil types listed, select that oil type. For more information see the topic Changing The Default Oil Type on page 101.
- If you are testing an oil type that is not listed you need to know and enter coefficients for that oil type. For more information see the topic Testing New Oil Types on page 102.

Changing The Default Oil Type

To change the default oil type:

1. Open the MENU by pressing \ominus OPEN.
2. Select SETTINGS, then press \triangleright .
3. Select MEASUREMENT SETTINGS, then press \triangleright .

The currently selected oil type and its coefficients display with the first row listing the currently selected oil type highlighted.



4. Press \ominus SET, then select a different oil type by using the up or down arrows.
5. Press \ominus OK.
6. To return to the basic display press \ominus EXIT.

Testing New Oil Types

When testing fluids whose solubility characteristics are different than the four preset oils, different algorithm coefficients that are specific to the oil must be used.

NOTE

If the water solubility characteristics of a specific oil type are unknown, they should be assumed to be significantly different and should be determined experimentally.

When you encounter an oil that does not match one of the four preset oils, contact Doble Engineering.

- Doble has determined algorithm coefficients over 30 for different fluids. These known coefficients are available upon request.
- If algorithm coefficients do not exist, a sample must be sent to Doble for modeling. Doble will experimentally determine the specific coefficients for the oil. In some cases, a fee may be charged for this service.

The determined coefficients of the algorithm for the fluid must then be programmed into the USS Indicator as detailed in the next topic.


Adding New Oil Types

Once a set of new coefficients have been established for a new oil type they must be programmed into the Indicator.

To add new coefficients to the Indicator:

1. Open the MENU by pressing OPEN.
2. Select SETTINGS, then press .
3. Select MEASUREMENT SETTINGS, then press .

The currently selected oil type and its coefficients display with the first row listing the currently selected oil type highlighted.



4. If you want to change the coefficients for a different oil type, press SET, then select a different oil type by using the up or down arrows. Then press OK.
5. Select the A value (A:0.0000), then press SET.
6. Set the value A by using buttons, press OK.
7. Select the B value (B:0.0000), then press SET.
8. Set the value B by using the buttons, press OK.
9. To change the coefficients for other oil types select that oil type per step 4 above and continue with the following steps.
10. To return to the basic display press EXIT.

NOTE

If you change the coefficients for one of the four preset oil types and want to test that oil type again then the coefficients for that oil type must be re-entered.

See the topic About Oil Types earlier in this chapter for the list of default oil types and coefficients.

TIP

Remember to always select the correct oil type before measurements.

CHAPTER 18

CALIBRATING MOISTURE-IN-OIL PROBES

This chapter contains information on calibrating the *DOMINO*® USS Moisture-In-Oil Probe.

Topics in this chapter...

General Calibration Information

Preparations Before Calibration

About Temperature Calibration

Temperature Calibration Procedures

About Relative Humidity Calibration

Relative Humidity Calibration Procedures

Viewing Last Calibration Date

General Calibration Information

What Calibration Is

Calibration is the process of:

1. Placing the probe sensor in a known reference environment.
2. Comparing the reading against the reference value.
3. Adjusting the probe sensor's reading to correspond to the reference value.

NOTE

After this procedure, the previous calibration is no longer valid.

When To Do Calibration

The Doble *DOMINO*® USS moisture-in-oil sensor is fully calibrated when shipped from factory.

The recommended calibration interval is 18 to 24 months.

If at any time there is a reason to believe that device is not within the accuracy specifications, calibration should be done. It is recommended to send the sensor probe to the Doble Customer Service Center. For contact information. See the topic Doble Service Center on page 6.

You can also calibrate the *DOMINO*® USS moisture-in-oil sensor by following the instructions given in this chapter.

What You Can Calibrate

The T (temperature) function is calibrated directly.

The RS (Relative Saturation) function is calibrated directly as relative humidity (RH.)

The H2O (Mass concentration of water) function is not calibrated directly.

NOTE

When calibrating both relative humidity and temperature, make the temperature calibration first.


Preparations Before Calibration

The following steps should be performed before any type of calibration:

1. Clean the sensor. This will:
 - decrease response time.
 - to prevent contamination of the salt bath by a dirty sensor, and hence prevent any change of the reference condition.

For more information see the topic [Cleaning the Moisture-In-Oil Probe](#) on page 122.

2. When using the Doble humidity calibrator, use the calibration adapter, Doble Part Number 03A-1672-01.
3. Take out the screw from the probe handle to expose the calibration button.



NOTE

During calibration mode, Automatic Power Off is disabled.

Do not leave the Indicator and probe unattended as unintended discharge of the battery may result.

About Temperature Calibration

Temperature can be calibrated against a known reference in any of the following ways:

Two-point calibration calibrates the probe sensor at low and high temperature references. The difference between the temperature references must be more than 30 °C. This is the recommended method to yield the most accurate calibration.

One-point calibration calibrates the probe sensor at a single temperature reference. Optimum results are obtained when the selected reference represents the measuring environment.

Calibration to a known good probe calibrates the probe being calibrated to match a second probe. This method should not be used in place of calibration to one (or preferably two) primary standard(s), but it provides a convenient method of roughly calibrating a probe in the field. The accuracy is dependent upon the accuracy of the second probe.

Details and procedures on each of these methods follow.

Temperature Calibration Procedures

Two-Point Calibration

Two-point calibration calibrates the probe sensor at low and high temperature differences. This is the recommended method to yields the most accurate calibration.

To perform a two-point calibration:

1. Prepare the low and high temperature references.
2. Attach the Moisture-In-Oil Probe that is to be calibrated to the Indicator.
3. Turn the Indicator on.
4. Take out the screw from the probe handle to expose the calibration button.

The calibration button is on a circuit board deep within the hole exposed.

5. Gently press the button with a very small screwdriver or the end of an unbent paper clip.

The Indicator screen displays a confirmation message that it is starting calibration mode.

6. Press \ominus OK.

The calibration mode starts and a list of the measured variables is displayed.

7. Select T by using the arrow buttons, then press \ominus SELECT.

The temperature is displayed with the message ADJUSTMENT MODE flashing.

8. Press \ominus ADJUST.

A list of calibration methods is displayed.

9. Select 2-point adjustment, then press \ominus SELECT.

The recommended references are displayed.

10. Press \ominus OK to continue.

11. Place the probe tip in the lower reference temperature.

12. Allow the reading to stabilize.
You can follow the stabilization from the \ominus GRAPH display.
To return to the adjustment screen from the graphical display press \ominus BACK.
13. When the reading is stabilized, press \ominus READY.

A screen displays to allow you to enter the actual reference value.
14. Enter the lower reference temperature value by using the arrow buttons, then press \ominus OK.
15. Place the probe tip in the higher reference temperature.
16. Allow the reading to stabilize.
You can follow the stabilization from the \ominus GRAPH display.
To return to the adjustment screen from the graphical display press \ominus BACK.
17. When the reading is stabilized, press \ominus READY.

A screen displays to allow you to enter the actual reference value.
18. Enter the higher reference temperature value by using the arrow buttons, then press \ominus OK.

A confirmation message is displayed.
19. At this confirmation message you can accept or cancel the calibration:
 - To confirm the calibration, press \ominus YES.

The calibration is saved in the probe and the Last adjustment date is changed to the date currently stored in the Indicator.
Continue with the next step.
 - To cancel the calibration, press \ominus NO, then press \ominus BACK, then press \ominus EXIT.

You will return to the main display

NOTE

If the difference between two references is less than 30 °C, the calibration can not be done. An error message stating that the calibration points are too close is displayed. Press \ominus OK to exit the error message, then press \ominus BACK, then press \ominus EXIT. You will return to the main display

20. Press \ominus BACK, then press \ominus EXIT.

You will return to the main display

21. Replace the screw over the calibration button.

TIP

If your organization has a formal calibration program, you can attach a sticker on the calibration button screw to seal the calibration.

One-Point Calibration

One-point calibration calibrates the probe sensor at a single temperature reference. Optimum results are obtained when the selected reference represents the measuring environment.

To perform a 1-point calibration, prepare the temperature reference and then follow the procedure for a two-point calibration. When prompted for the calibration type, select 1-point adjustment and follow the displayed instructions.

Calibration To A Known Good Probe

This method should not be used in place of calibration to one (or preferably two) primary standard(s), but it provides a convenient method of roughly calibrating a probe in the field. The accuracy is dependent upon the accuracy of the second probe.

To perform a calibration to a known good probe, attach the second probe to the second port on the Indicator and then follow the procedure for a two-point calibration. When prompted for the calibration type, select To same as T (II) and follow the displayed instructions.

About Relative Humidity Calibration

Relative calibration can be calibrated against a known reference in any of the following ways:

Two-point calibration calibrates the probe sensor at low (0% to 11.3%) and high (75% to 97%) humidity references. The difference between the humidity references must be more than 50%. This is the recommended method to yield the most accurate calibration.

One-point calibration calibrates the probe sensor at a single humidity reference. Optimum results are obtained when the selected reference represents the measuring environment.

LiCl-NaCl (Lithium Chloride-Sodium Chloride) automatic calibration is a two-point calibration at reference humidities of 11.3 % (LiCl, Lithium Chloride) and 75 % (NaCl, Sodium Chloride.)

Calibration to a known good probe adjusts the probe being calibrated to match a second probe. This method should not be used in place of calibration to one (or preferably two) primary standard(s), but it provides a convenient method of roughly calibrating a probe in the field. The accuracy is dependent upon the accuracy of the second probe.

Details and procedures on each of these methods follow.

Relative Humidity Calibration Procedures

Two-Point Calibration

Two-point calibration calibrates the probe sensor at low (0% to 11.3%) and high (75% to 97%) humidity references. This is the recommended method to yields the most accurate calibration. Typical references are:

- Low humidity references: 0% (Nitrogen)
or 11.3% (LiCl, Lithium Chloride)
- High humidity references: 75% (NaCl, Sodium Chloride)
or 97% (K₂SO₄, Potassium Sulfate.)

Ensure that the difference between the humidity references is more than 50%.

To perform a two-point calibration, prepare the low and high humidity references and then follow the procedure below.

NOTE

When calibrating both relative humidity and temperature, make the temperature calibration first.

To make a two point temperature calibration:

1. Attach the Moisture-In-Oil Probe that is to be calibrated to the Indicator.
2. Turn the Indicator on.
3. Take out the screw from the probe handle to expose the calibration button.

The calibration button is on a circuit board deep within the hole exposed.

4. Gently press the button with a very small screwdriver or the end of an unbent paper clip.

The Indicator screen displays a confirmation message that it is starting calibration mode.

5. Press  OK.

The calibration mode starts and a list of the measured variables is displayed.

6. Select RH by using the arrow buttons, then press \ominus SELECT.

The relative humidity is displayed with the message ADJUSTMENT MODE flashing.
7. Press \ominus ADJUST.

A list of calibration methods is displayed.
8. Select 2-point adjustment, then press \ominus SELECT.

The recommended references are displayed.
9. Press \ominus OK to continue.
10. Place the probe tip in the lower reference relative humidity.
When using the Doble humidity calibrator, use the calibration adapter, Doble Part Number 03A-1672-01.
11. Allow the reading to stabilize.
You can follow the stabilization from the \ominus GRAPH display.
To return to the calibration screen from the graphical display press \ominus BACK.
12. When the reading is stabilized, press \ominus READY.

A screen displays to allow you to enter the actual reference value.
13. Enter the lower reference relative humidity value by using the arrow buttons, then press \ominus OK.
14. Place the probe tip in the higher reference relative humidity.
When using the Doble humidity calibrator, use the calibration adapter, Doble Part Number 03A-1672-01.
15. Allow the reading to stabilize.
You can follow the stabilization from the \ominus GRAPH display.
To return to the calibration screen from the graphical display press \ominus BACK.
16. When the reading is stabilized, press \ominus READY.

A screen displays to allow you to enter the actual reference value.

17. Enter the higher reference relative humidity value by using the arrow buttons, then press \ominus OK.

A confirmation message is displayed.

18. At this confirmation message you can accept or cancel the calibration:

- To confirm the calibration, press \ominus YES.

The calibration is saved in the probe and the Last adjustment date is changed to the date currently stored in the Indicator.
Continue with the next step.

- To cancel the calibration, press \ominus NO, then press \ominus BACK, then press \ominus EXIT.

You will return to the main display

NOTE

If the difference between two references is less than 50%, the calibration can not be done. An error message stating that the calibration points are too close is displayed. Press \ominus OK to exit the error message, then press \ominus BACK, then press \ominus EXIT. You will return to the main display

19. Press \ominus BACK, then press \ominus EXIT.

You will return to the main display

20. Replace the screw over the calibration button.

TIP

If your organization has a formal calibration program, you can attach a sticker on the calibration button screw to seal the calibration.

LiCl-NaCl Automatic Calibration

LiCl-NaCl (LiCl = Lithium Chloride, NaCl = Sodium Chloride) automatic calibration is a two-point calibration at a low reference humidity of 11.3 % (LiCl, Lithium Chloride) and a high reference humidity of 75 % (NaCl, Sodium Chloride.) You don't have to enter the reference values, the USS Indicator displays the accurate value based on the measured temperature and values stored in the memory of the Indicator.

To perform a LiCl-NaCl automatic calibration, prepare the low and high humidity references and then follow the procedure for a two-point calibration. When prompted for the calibration type, select LiCl-NaCl autom. and follow the displayed instructions.

One-Point Calibration

One-point calibration calibrates the probe sensor at a single humidity reference. Optimum results are obtained when the selected reference represents the measuring environment.

To perform a 1-point calibration, prepare the humidity reference and then follow the procedure for a two-point calibration. When prompted for the calibration type, select 1-point adjustment and follow the displayed instructions.

Calibration To A Known Good Probe

This method should not be used in place of calibration to one (or preferably two) primary standard(s), but it provides a convenient method of roughly calibrating a probe in the field. The accuracy is dependent upon the accuracy of the second probe.

To perform a calibration to a known good probe, attach the second probe to the second port on the Indicator and then follow the procedure for a two-point calibration. When prompted for the calibration type, select To same as RH (II) and follow the displayed instructions.

Viewing The Last Calibration Date

When a calibration is performed the current date (as stored in the Indicator) is stored in the probe. You can view this date in either of two ways:

- Follow the procedure for a two-point calibration.
When prompted for the quantity to calibrate, select **Last adjustment date**, then press \ominus SHOW. Press \ominus OK to exit the date display, then press \ominus EXIT. You will return to the main display.
- You can check this date from the **Device information** screen.
For more information see the topic **Viewing Device Information** on page 53.

This page intentionally left blank.

CHAPTER 19

MAINTAINING MOISTURE-IN-OIL PROBES

This chapter contains information on servicing and cleaning the *DOMINO*® USS Moisture-In-Oil Probe.

Topics in this chapter...


Changing The Filter And Sensor

Changing The Quick Connect Fitting

Cleaning the Moisture-In-Oil Probe

Changing The Filter And Sensor

To change the filter and/or sensor:



1. Unscrew the filter from the probe head.
2. Remove the sensor by pulling it straight out.
Handle the sensor by the plastic socket only.
3. Insert a new sensor, Doble Part Number 212-0617.
4. Perform a relative humidity calibration on the probe. Refer to the topic Relative Humidity Calibration Procedures on page 113 for more information.
5. Screw a new filter, Doble Part Number 230-0209, on the probe head.
Tighten the filter to 5.1 Nm (45 in-lbs.)

Changing The Quick Connect Fitting

The quick connect plug can be changed if it becomes worn or damaged.

NOTE

The quick connect fitting **MUST** be located at a precise distance away from the end of the probe in order to properly position the sensor when used with the USS Manifold.

To change the quick connect fitting:

1. Hold the fitting body and unscrew the quick connect plug.
2. Remove the remaining Teflon tape on the fitting body.
3. Apply a layer of new Teflon tape to the fitting body.
4. Screw on the new quick connect plug (Doble Part Number 09B-0825-01.)
5. Check the distance from the end of the filter to the end of the quick connect plug.



If the distance is not 49 mm (1.94 inches) as shown, then:

- a. Loosen the clasp nut and fitting body.
- b. Position the clasp nut, fitting body, and quick connect plug to achieve the dimension shown.
- c. Tighten the clasp nut hand tight.
- d. Tighten the clasp nut an additional 30°-40° using the plastic wrench

Cleaning the Moisture-In-Oil Probe

NOTE

It is important to clean the probe:

- Before storing the probe.
- Before calibration, as a dirty probe can contaminate the salt bath and change the reference condition.

To clean the Moisture-In-Oil Probe you need a solvent (either heptane, hexane, or pentane liquid) and instrument air.

To clean the Moisture-In-Oil Probe :

1. Blow the probe head (with the filter on) with instrument air to remove the remains of the oil.
2. Immerse the probe head into either heptane, hexane, or pentane liquid and rinse out the oil.

CAUTION

DO NOT use acetone or similar solvents.

3. Blow the probe head with instrument air to dry it completely.
4. If you are going to calibrate the probe, then remove the filter and blow the sensor with instrument air. to dry it completely
5. Examine the sensor. If it is dirty, clean it per steps 3 and 4 above without replacing the filter.

NOTE

The sensor **MUST** be completely dry to prevent oxidation of the sensor. The oxidation of the sensor can cause extended response times or drifting.

6. Reinstall the filter on the probe.

SECTION 4

MAKING DEWPOINT MEASUREMENTS

This section contains information on making dewpoint (and related) measurements using:

- The *DOMINO*® USS Dewpoint System
(Doble Part Number 03D-1677-01)
- The *DOMINO*® USS Complete System
(Doble Part Number 03D-1686-01)
- The *DOMINO*® USS Moisture-In-Oil System
(Doble Part Number 03D-1647-01)
and a USS Dewpoint Probe(s)
(Doble Part Number 03D-1681-01)

Chapters in this section...

- Chapter 20 Dewpoint Quick Start
- Chapter 21 Installing The Dewpoint Probe
- Chapter 22 Taking Dewpoint Measurements
- Chapter 23 Changing Dewpoint Settings
- Chapter 24 Calibrating Dewpoint Probes
- Chapter 25 Maintaining Dewpoint Probes

This page intentionally left blank

CHAPTER 20

DEWPOINT QUICK START

The *DOMINO*® USS Dewpoint System is a portable, simple to use system that enables reliable and high performance dewpoint measurements.

The first time out of the case, follow these steps:

1. Charge and set up the USS Indicator.

For more information see Chapter 7, Indicator Quick Start on page 31.

2. Configure the Dewpoint Probe.

For more information see Chapter 23,
Changing Dewpoint Settings on page 137.

3. Select which measured variables to display.

For more information see the topic
Specifying The Displayed Quantities And Units on page 48.

4. Install the Dewpoint Probe.

For more information see Chapter 21
Installing The Dewpoint Probe, on page 127.

5. Take the dewpoint reading.

For more information see Chapter 22,
Taking Dewpoint Measurements on page 133.

This page intentionally left blank

CHAPTER 21

INSTALLING THE DEWPOINT PROBE

This chapter contains information on several different methods of installing the *DOMINO*® USS Dewpoint Probe.

Topics in this chapter...

About the USS Dewpoint Sampling Cell

Installation On A Pressurized Process


About the USS Dewpoint Sampling Cell

The *DOMINO*® Dewpoint Sampling Cell is used to sample gas from a pressurized process. The cell works as follows:

1. The process pressure forces the sample gas through an adapter into the sampling cell.
2. In the sampling cell the sample gas surrounds the probe sensor.
3. The sample gas exits the sampling cell at the leakage screw.

The leakage screw is used to control the rate of flow of the sample gas over the probe sensor.

The sampling cell is supplied with three different adapters to attach the sampling cell to a variety of process systems.



NOTE

The supplied quick connector adapter is known by several designations including 1/4 inch industrial, NIP08, and Type D.

Use this designation to determine if a specific quick connect socket will accept the supplied connector, or, use one of the sockets available from Doble.

Installation On A Pressurized Process

CAUTION

When measuring the dewpoint of SF₆ (sulfur hexafluoride) gas:

The small amount of SF₆ that is vented through the sampling manifold to the atmosphere may be unacceptable to some companies. If that is the case, **DO NOT** use the supplied sampling manifold. Do one of the following:

- Install the probe directly into the apparatus to be sampled. Be certain that there is an adequate flow of the sample gas over the sintered filter.
- Use a special sampling system that will not release gas to the atmosphere. For additional information contact Doble Engineering.

To connect the **DOMINO®** Dewpoint Probe to a pressurized process:

1. Verify the proper adapter that is necessary to attach to the process is assembled to the sampling cell.

TIP

To maintain the process pressure during the installation or removal of the sampling cell, use the quick connect adapter and a quick connect socket with a shutoff in the body. The Doble quick connect sockets (230-0224 and 230-0225) have this feature.


- If the quick connect fitting assembled to the sampling cell is acceptable, then go on to the next step.

TIP

If you want to use this quick connect fitting but your process will not accept it, you can use either:

- Dewpoint Quick Disconnect Fitting Male Socket
Doble Part Number 230-0224.
- Dewpoint Quick Disconnect Fitting Female Socket,
Doble Part Number 230-0225.

- If the quick connect fitting assembled to the sampling cell is not acceptable, then:
 - a. Remove the quick connect fitting from the sampling cell.
 - b. Select the appropriate fitting.
 - c. Test the fit of the selected fitting and the sampling cell. The two parts must fully engage. then disassemble.
 - d. Apply two layers of 1/2 wide Teflon tape to the threads of the selected fitting.
 - e. Fully assemble the selected fitting to the sampling cell.




CAUTION

When the thread adapters are used, the process pressure has to be shut down or otherwise closed off for the installation or removal of the probe.

2. Assemble the sampling cell and fitting to the Dewpoint Probe.

The Dewpoint Probe is supplied with the sampling cell already assembled. If the sampling cell is not assembled to the probe, assemble it as follows:



- a. Place the supplied sealing washer over the end of probe threads. Note that the rubber inside diameter of the sealing washer will be tight when pushed over the threads.
- b. If it is present, remove yellow plastic protective cap from probe tip to expose the sintered filter.
- c. Loosen the exhaust body (the sintered cylinder that the exhaust screw is in) at least one full turn.

CAUTION

If you do not loosen the exhaust body, then the exhaust screw will score the sintered filter.

- d. Assemble the sampling cell to the probe threads and tighten. Do not use Teflon tape on this connection. Do not turn using the probe handle, but rather grip both the sampling cell and the clasp nut by the flats on each.
- e. Tighten the exhaust body.

3. Make sure that the leakage screw of the sampling cell is open.
To do this, first close the leakage screw , then turn it 1 turn open.
4. If you are not using a quick disconnect with a shutoff socket, then shut down the process or close off the pressure from the process fitting.
5. Connect the sample cell to the process fitting.
 - If you are using a quick disconnect, plug the plug adapter into the quick connect socket.
 - If you are using threaded fittings, attach the fitting on the sampling cell to the process. Use Teflon tape on the fitting threads that go into the process.
6. If you are not using a quick disconnect with a shutoff socket, then turn on the process or open up the pressure to the process fitting.
7. Verify that the installation is correct by checking for leaks.
Do this by closing the leakage screw temporarily and listening for the hiss of the escaping process gas.
8. It is preferable, but not absolutely necessary, to fully ventilate the sampling cell by turning the leakage screw open several turns.
This will allow the sensor to stabilize faster.
9. Adjust the leakage rate to allow a small leakage by closing the leakage screw and then opening it a small amount.
10. You care now ready to take a reading. For more information see the topic Taking Dewpoint Measurements on page 134.

CHAPTER 22

TAKING DEWPOINT MEASUREMENTS

This chapter contains information on taking measurements using the *DOMINO*® USS Dewpoint Probe including special considerations to be taken in very dry environments.

Topics in this chapter...

Taking Dewpoint Measurements

Measuring In Very Dry Environments

Taking Dewpoint Measurements

TIP

If you are using the *DOMINO*® USS Dewpoint system for the first time see Chapter 20, Dewpoint Quick Start on page 125.

NOTE

If you are measuring water content (H₂O):

- The Dewpoint Probe must be set for the pressure of the sample. For more information see the topic Changing Pressure Settings on page 138.
- The Dewpoint Probe must be set for the molecular weight of the sample. For more information see the topic Changing Molecular Weight Settings on page 140.

NOTE

You must set which of the measured variable you want to display. For more information see the topic Specifying The Displayed Quantities And Units on page 48.

NOTE

Make sure that auto-calibration has taken place or in very dry environments perform a manual calibration. For more information see the topic Changing Auto-Calibration Settings on page 142.

NOTE

If you are just starting measuring after the probe has been stored or a sensor purge has not been performed within the last 24 hour, perform a sensor purge. For more information see the topic Changing Sensor Purge Settings on page 146.

The actual procedure starts on the next page.

To take a Dewpoint measurement:

1. Connect the Dewpoint Probe to the Indicator.
The Indicator should be off.
2. On the Indicator, press  POWER ON/OFF button.

NOTE

If you turn on the Indicator before connecting the probe, when you do attach the probe it will not be recognized by the Indicator.

3. Install the probe to the measuring position. For more information see Chapter 21, Installing The Dewpoint Probe starting on page 127.
4. The basic display opens. Let the reading stabilize.

NOTE

When measuring low dewpoints, the stabilization times can be long, for example, one to two hours. Therefore, to ensure the stabilization can be monitored the entire time, turn off the automatic power-off function. For more information see the topic Configuring Automatic Power Off on page 41.

CAUTION

If you need to disconnect the probe from the Indicator, first press  POWER ON/OFF button to turn the Indicator OFF.

This ensures that all settings and data are saved properly.

Measuring In Very Dry Environments

The following recommendations should be taken into account when measuring in very dry environments:

- A clean environment is always best for humidity measurements.
- The number of connections should be minimized to avoid leaks.
- The flow rate must be adequate.
- Dead ends must be avoided as they cannot be flushed easily.
- The tube temperature must never be below the dewpoint of the sample gas. This may lead to condensation and false results.
- The sample tubing should be of as short length as possible. The surface area should be minimized using the narrowest tubing that the flow conditions allow.
- The surface finish of the pipework is important. Polished or electro-polished steel is recommended for best results.
- Hygroscopic materials should be avoided in the sampling lines. Use stainless steel membranes instead of rubber membranes.
- Impermeable materials should be selected to avoid inward diffusion of moisture through the sampling tubes and enclosures. Such impermeable materials are, for example, high-quality stainless steel and metals. Avoid PVC or nylon tubes.

CHAPTER 23

CHANGING DEWPOINT SETTINGS

This chapter contains information on the various settings that are necessary when taking dewpoint measurements.

NOTE

The settings described in this chapter are stored in the *DOMINO*® USS Dewpoint Probe itself (not in the Indicator) and will be retained if the probe is used with a different Indicator.

Topics in this chapter...

Changing Pressure Settings

Changing Molecular Weight Settings

Changing Auto-Calibration Settings

Changing Sensor Purge Settings

Changing Pressure Settings

NOTE


The actual process pressure value must be set to measure water content (H2O.) This value is required to make the ppm calculation.

Either gauge pressure (the difference between the atmospheric pressure and the process pressure) or absolute pressure can be set in units of either bar or psi.

To set the process pressure value:

1. Open the MENU: by pressing $\blacktriangleright \ominus$ OPEN
2. Select \blacktriangleright Environment, then press \blacktriangleright .

The Environment screen will display.



3. To change the type of pressure that is displayed and the units that are used, press \ominus Unit. Each time you press \ominus Unit, the selection will advance to the next type and unit combination as listed below.

P_{barg} : Gauge pressure is given in the unit of bar.

P_{bara} : Absolute process pressure is given in the unit of bar.

P_{psig} : Gauge pressure is given in the unit of psi.

P_{psia} : Absolute pressure is given in the unit of psi.

4. To change the pressure value, press \ominus Set.

The set pressure screen will display.

5. Set the value using the \triangle ∇ \blacktriangleright \blacktriangleleft buttons.
To change the sign of the pressure value, press \ominus +/-.
To save the value, press \ominus OK.
6. To return to the basic display, press \ominus Exit.

Changing Molecular Weight Settings


NOTE

The molecular weight of the sampled gas must be set to measure water content (H₂O.) This value is required to make the ppm calculation.

To set the molecular weight value:

1. Open the MENU: by pressing OPEN
2. Select **►Settings**, then press .

The Settings screen will display.



3. Select **►Measurement Settings**, then press .

The Measurement Settings screen will display.



4. Select ppmw M, then press \ominus Set.
The Set value of ppmw M screen will display.
5. Set the value using the \triangle ∇ \rightarrow \leftarrow buttons.

For...	set the value to...
air	28.96
SF ₆	146.06
nitrogen	28.01
argon	79.90
helium	8.00
vacuum	use the value for air or the value for the predominant gas that was present

6. To change the sign of the pressure value, press \ominus +/-.
7. Press \ominus OK to save the value.
8. To return to the basic display, press \ominus Exit.

Changing Auto-Calibration Settings

Calibration is a procedure in which the probe's dry-end reading is adjusted to correspond to the calibrated values to ensure the best possible accuracy in measurements taken in low dewpoint (dry) environments.

Calibration can be performed automatically (auto-calibration) or initiated manually by the user. By default auto-calibration is turned on.

When it is enabled, auto-calibration will be performed automatically if the dewpoint or temperature changes significantly, typically more than 10 °C. However, if there are no changes in the conditions, the auto-calibration will be performed one hour after the last auto-calibration.

If the correction determined by the auto-calibration reaches a preset, maximum value, or if the auto-calibration correction fails (for example in the case of unstable conditions), a new auto-calibration may take place later if the automatic auto-calibration is turned on.

The auto-calibration is performed **only if** all of the following criteria for the measurement environment are fulfilled:

- The relative humidity must be less than 2 %
- The temperature must be greater than 0 °C and less than 60 °C.
- The humidity environment must be stable. The maximum change in the dewpoint can be 1 °C within 30 seconds.

Calibration can also be started manually, even if the automatic auto-calibration setting is on. Perform the manual calibration to check that auto-calibration has been performed to obtain the most accurate measurement in a very dry environment.

Turning Automatic Auto-Calibration On Or Off

You can change the automatic auto-calibration setting at any time.

To turn automatic auto-calibration on or off:

1. Open the MENU by pressing   OPEN
2. Select Settings, then press .
3. Select Measurement settings, then press .
4. Select  Autom.AutoCal.
5. Select the automatic auto-calibration setting:
 - To turn automatic auto-calibration off, press  Off.
The box next to Autom.AutoCal is cleared.
 - To turn automatic auto-calibration on, press  On.
The box next to Autom.AutoCal is checked.
6. To return to the basic display, press  Exit.

NOTE

If the automatic auto-calibration is turned off, the auto-calibration should be started manually in the following situations:

- when starting measuring after the probe has not been used for a while.
- at least once every hour when measuring.

Performing Manual Auto-Calibration

You can manually initiate the auto-calibration at any time. Perform the manual calibration to check that auto-calibration has been performed to obtain the most accurate measurement in a very dry environment.

NOTE

The manual auto-calibration can be performed even if the automatic auto-calibration setting is on.

To start the auto-calibration manually:

1. Open the MENU by pressing   OPEN
2. Select Functions, then press .
3. Select AutoCal, then press  Start.
4. Press Yes to confirm the selection.


The auto-calibration process will begin.

NOTE


If it is too humid, auto-calibration will not start and a message displays that states that the calibration cannot be made.

Auto-calibration will take about 2 minutes to complete.


During auto-calibration an estimate of the measurement readings may appear on the display. Messages concerning the remaining auto-calibration time are shown periodically.



1. Display during the adjustment period (< 15 seconds)



2. Adjustment period is completed and stabilization period will start.



3. After successful auto-calibration, the corrected readings are shown during the stabilization period.
If the auto-calibration fails, no readings are shown, only lines are displayed.



4. Display during the stabilization period (1 ... 2 minutes).



5. Auto-calibration is completed.

When the auto-calibration is completed, the display returns to the basic display automatically. The stabilization of the temperature reading can take a few minutes.

Changing Sensor Purge Settings

Sensor purge is a procedure in which the sensor is dried to ensure the fastest response time when installing the probe from an ambient to a dry gas. Along with auto-calibration, sensor purge will also ensure the best measurement accuracy and long-term stability.

Sensor purge can be performed automatically (automatic sensor purge) or initiated manually by the user. By default automatic sensor purge is turned on. It is recommended not to turn it off.

When it is enabled, the automatic sensor purge will be performed at an interval specified by the user. The default interval is 24 hours. If there are high chemical concentrations present in the measurement environment that are causing sensor drift, then it may be necessary to perform the sensor purge more often. Note that more frequent sensor purges will reduce battery operation time.

The automatic sensor purge is performed **only if** all of the following criteria for the measurement environment are fulfilled:

- The *DOMINO*® Indicator power is continuously turned on or the Indicator has been left in logging mode (display on or off.)
- The humidity changes significantly or quickly.
- The dewpoint is low enough.

The sensor purge can also be started manually.

Perform a manual sensor purge in the following situations:

- When starting measuring after the probe has been stored.
- If a purge has not been performed within the last 24 hours.
- Before calibration.

TIP

You can also change one of the shortcut keys to refer to start the manual sensor purge. For more information see the topic Changing The Shortcut Keys on page 42.

Turning Automatic Sensor Purge On or Off

You can change the automatic sensor purge setting at any time.

To turn automatic sensor purge on or off:

1. Open the MENU by pressing   OPEN
2. Select Settings, then press .
3. Select Measurement settings, then press .
4. Select  Autom.Purge.
5. Select the automatic sensor purge setting:
 - To turn the automatic sensor purge off, press  Off.
The box next to Autom.Purge is cleared.
 - To turn the automatic sensor purge on, press  On.
The box next to Autom.Purge is checked.
6. To return to the basic display, press  Exit.

Changing Automatic Sensor Purge Interval

You can change the interval at which the automatic sensor purge is performed. The purge interval can be set to between 1 to 48 hours. Note that more frequent sensor purges will reduce battery operation time.

If there are high chemical concentrations present in the measurement environment that are causing sensor drift, then perform the sensor purge more often.

To change the automatic sensor purge interval:

1. Open the MENU by pressing   OPEN.
2. Select Settings, then press .
3. Select Measurement settings, then press .
4. Select Purge interval and press  Set.
5. Set the desired purge interval by using the     buttons. Then press  OK to confirm.
6. To return to the basic display, press  Exit.

Performing Manual Sensor Purge

You can manually initiate the sensor purge at any time.

Perform the manual sensor purge in the following situations:

- When starting measuring after the probe has been stored.
- If a purge has not been performed within the last 24 hours.
- Before calibration.

NOTE

The manual sensor purge can be performed even if the automatic sensor purge setting is on.



To start the sensor purge manually:

1. Open the MENU by pressing OPEN.
2. Select Functions, then press .
3. Select Purge, then press Start.
4. Press Yes to confirm the selection.

The sensor purge process will begin.

The purge will take up to 5 minutes to complete. During the purge:

- there are no readings on the display.
- a message appears on the display every 15 seconds to inform of the time required to complete the purge.
- the purge symbol appears in the upper left corner of the display.



Display during the first minute. Note message.

When the sensor purge is completed, the display returns to the basic display automatically. The stabilization of the temperature reading can take a few minutes.

NOTE

If the dewpoint is low, automatic auto-calibration will take place immediately after the sensor purge. For more information see the topic Changing Auto-Calibration Settings on page 142.

CHAPTER 24

CALIBRATING DEWPOINT PROBES

This chapter contains information on calibrating the *DOMINO*® USS Dewpoint Probe.

General Calibration Information

What Calibration Is

Calibration is the process of placing the probe sensor in a known reference environment and comparing the reading against the reference value.

Adjustment is the process of changing the probe sensor's reading to correspond to the reference value.

NOTE

After the adjustment, the original calibration certificate shipped with the product is no longer valid.

When To Do Calibration

The Doble *DOMINO*® USS dewpoint sensor is fully calibrated when shipped from factory.

The recommended calibration interval is 18 to 24 months.

If at any time there is a reason to believe that device is not within the accuracy specifications, calibration should be done. It is recommended to send the sensor probe to the Doble Customer Service Center. For contact information. See the topic Doble Service Center on page 6.

This page intentionally left blank.

CHAPTER 25

MAINTAINING DEWPOINT PROBES

This chapter contains information on cleaning the *DOMINO*® USS Dewpoint Probe.

Cleaning Dewpoint Probes

To clean the Dewpoint Probe you need a solvent (either heptane, hexane, or pentane liquid) and instrument air.

To clean the Dewpoint Probe:

1. Remove the sintered filter.
2. Blow the sintered filter with instrument air to remove the remains of the oil.
3. Immerse the sintered filter into either heptane, hexane, or pentane liquid and rinse out the oil.

CAUTION

DO NOT use acetone or similar solvents.

4. Blow the sintered filter with instrument air to dry it completely.
5. Examine the sensor. If it is dirty, clean it per steps 3 and 4 above.
6. Reinstall the cleaned sintered filter on the probe.

This page intentionally left blank.

SECTION 5

USING *DOMINO*® CONNECTS

This section contains information on *DOMINO*® Connects, a software application that can monitor, control, and download data from, the USS Indicator.

Chapters in this section...

Chapter 26 Using *DOMINO*® Connects

This page intentionally left blank.

CHAPTER 26

USING *DOMINO*® CONNECTS

This chapter contains information on installing and using *DOMINO*® Connects, the Microsoft Windows® environment software for monitoring and controlling the USS Indicator.

Topics in this chapter...

About *DOMINO*® Connects

DOMINO® Connects Requirements

Installing *DOMINO*® Connects

Installing The USB-Serial Adapter

Using *DOMINO*® Connects

Uninstalling *DOMINO*® Connects

About DOMINO® Connects

DOMINO® Connects is a Microsoft Windows® environment software program that enables you to monitor, control, and download data from the USS Indicator. DOMINO® Connects enables you to:

- Configure most Indicator functions including all data gathering and recording functions.
- View real time data of selected variables in a tabular or graphical format.
- Print tabular data or save it in a number of formats including tab delimited or comma separated values (CSV.)
- Scale, zoom in and out of, and print graphical data.
- Open Indicator data files and view them in tabular or graphical format and save it in a number of formats including tab delimited or comma separated values (CSV.)
- Delete data files from the Indicator's memory.

DOMINO® Connects Requirements

The computer running DOMINO® Connects must meet the following requirements:

Hardware	IBM compatible computer with either: <ul style="list-style-type: none">• A serial port (9 pin sub-D male connector), or,• A USB port (requires optional USB-Serial Adapter, Doble Part Number 401-0302)
Operating system	Windows NT® 4.0, Windows® 2000, Windows® XP, or Windows® Server 2003.

Installing *DOMINO*® Connects

DOMINO® Connects can be installed in either of two ways, from the supplied CD or from a set of floppy disks you can create.

NOTE

Security settings may prevent regular users from installing new software. In case of problems, contact your local system administrator.

Installing *DOMINO*® Connects From CD

To install *DOMINO*® Connects from the supplied CD:

1. Insert the *DOMINO*® Connects CD-ROM into your CD-ROM drive.

The *DOMINO*® Connects setup program will be launched automatically.

If the setup does not start automatically, do one of the following:

- Open My Computer, double-click the CD-ROM drive icon, then double-click the Setup icon in the opened CD-ROM window. Or,
- Click **Start**, then click **Run**. In the **Open** box type D:\setup.exe where D is the drive letter of the computer's CD-ROM drive. Then click **OK**.

The *DOMINO*® Connects setup program will start.

2. Follow the on-screen prompts to complete the installation.

Installing *DOMINO*® Connects From Floppy Disks

If you have to install *DOMINO*® Connects on a computer that has no CR-ROM drive but does have a floppy drive, you can create a set of 3 1/2 inch floppy disks that contain the setup program using the *DOMINO*® Connects Disk Wizard.

To create the installation floppies:

CAUTION

During the following procedure, all existing data on the disks will be erased.

1. Verify that you have two (2) formatted 1.44 MB 3 1/2 inch floppy disks.
2. Label the disks 1 and 2.
3. Insert the first floppy disk in the PC.
4. Insert the *DOMINO*® Connects CD-ROM into your CD-ROM drive.

The *DOMINO*® Connects setup program will be launched automatically.

If the setup does not start automatically, do one of the following:

- Open My Computer, double-click the CD-ROM drive icon, then double-click the Setup icon in the opened CD-ROM window. Or,
- Click **Start**, then click **Run**. In the **Open** box type D:\setup.exe where D is the drive letter of the computer's CD-ROM drive. Then click **OK**.

The *DOMINO*® Connects setup program will start.

5. In the *DOMINO*® Connects Setup Welcome screen, click **Create 3 1/2-inch installation disks**.
6. Follow the instructions given by the Disk Wizard.
7. After the disks are created, click **Cancel** to exit the *DOMINO*® Connects Setup program.

To install *DOMINO*® Connects from the floppy disks:

1. On the PC where you want to install *DOMINO*® Connects, insert the first floppy disk.
2. Do one of the following:
 - Open My Computer, double-click the floppy drive icon, then double-click the **Setup** icon in the opened floppy drive window. Or,
 - Click **Start**, then click **Run**. In the **Open** box type a:\setup.exe, then click **OK**.

The *DOMINO*® Connects setup program will start.

3. Follow the on-screen prompts to complete the installation.

Installing The USB-Serial Adapter

If you are going to connect the Indicator to the USB port on your computer you must use the optional USB-Serial Adapter, Doble Part Number 401-0302. This adapter requires the installation of a Windows device driver.

NOTE

Security settings may prevent regular users from installing new software. In case of problems, contact your local system administrator.

To connect the USB-Serial Adapter:

1. Place the USB-Serial Adapter driver CD in the computer's CD-ROM drive.

The USB-Serial Adapter setup program will be launched automatically.

If the setup does not start automatically, do one of the following:

- Open My Computer, double-click the CD-ROM drive icon, then double-click the autorun icon in the opened CD-ROM window. Or,
- Click **Start**, then click **Run**. In the **Open** box type D:\autorun.exe where D is the drive letter of the computer's CD-ROM drive. Then click **OK**.

The USB-Serial Adapter setup program will start.

2. In the warning screen, select the language.
3. In the product listing screen, select USB 1.1 to RS232 Cable.
4. In the important notice screen, click the Setup.exe icon.
5. In the File Download dialog click **Open**.
6. In the InstallShield program follow the prompts to install the driver.
7. Click  **Exit** to close the installation program.
8. Plug the USB end of the USB-Serial cable into the computer's USB port.

NOTE

In the Add/Remove Programs list the driver will appear as **PL-2303 USB-to-Serial**.

Using *DOMINO*® Connects

CAUTION

The real-time window requires continuous access to the Indicator. If the computer enters the standby (suspend) mode, the real-time window may stop and/or an error message may be shown.

To avoid problems, check that you have disabled automatic system standby (suspend) in the power-saving settings of your computer before starting a real-time window.

NOTE

Because the *DOMINO*® Connects cable connects to one of the probe ports, you can only use one probe when using *DOMINO*® Connects.

To connect the Indicator:

NOTE

If you are going to connect the Indicator to the USB port on your computer first install the optional USB-Serial Adapter, Doble Part Number 401-0302. For more information see the topic Installing The USB-Serial Adapter on page 162.

1. Plug the 9 pin sub-D end of the connector cable into the serial port of the computer (or of the USB-Serial adapter if used.)
2. Plug the circular connector end of the connector cable into either Port I or Port II of the Indicator.

To start *DOMINO*® Connects:

1. Turn on the connected Indicator.
2. Do one of the following:
 - Double-click the  *DOMINO*® Connects desktop icon, or
 - Click the **Start** button, then point to **Programs, *DOMINO* Connects,** then click ***DOMINO* Connects** .

TIP

When you access the Indicator from the PC, on the Indicator display the  icon will display next to the battery indicator.

To get help with *DOMINO*® Connects:

- Press **F1**, or,
- On the **Help** menu, click **Contents and Index**, or,
- Click the **Start** button, then point to **Programs, *DOMINO* Connects,** then click ***DOMINO* Connects Help**.

To close *DOMINO*® Connects:

- On the **File** menu, click **Exit**, or
- Press **Alt-F4**, or
- Click  **Close**.

Uninstalling *DOMINO*® Connects

NOTE

Security settings may prevent regular users from uninstalling new software. In case of problems, contact your local system administrator.

To uninstall the *DOMINO*® Connects program:

1. Open the **Add/Remove Programs** applet in the Windows Control Panel.
2. Select **DOMINO Connects** in the list.
3. Click **Remove**.

This page intentionally left blank.

SECTION 6

SPECIFICATIONS

This section contains specifications for the Ultimate Sampling System and its individual component, and a listing of the available spare and replacement parts.

Chapters in this section...

- Chapter 27 Technical Specifications
- Chapter 28 Options, Accessories, and Spares

This page intentionally left blank.

CHAPTER 27

TECHNICAL SPECIFICATIONS

This chapter contains specifications for the entire *DOMINO*® Ultimate Sampling System and the individual components.

Topics in this chapter...

DOMINO® USS System Specifications

Indicator Specifications

Moisture-In-Oil Probe Specifications

Dewpoint Probe Specifications

DOMINO® USS System Specifications

The following specifications apply to both:

- the DOMINO® USS Indicator and Moisture-In-Oil Probe
- the DOMINO® USS Indicator and Dewpoint Probe

General

Storage humidity range 0...100 %Non Condensing

Storage temperature -40 ... +70 °C (-40 ... +158 °F)

Housing material ABS/PC blend

Electromagnetic compatibility

Complies with IEC/EN 61326-1 Electrical equipment for measurement, control and laboratory use - EMC requirements - Basic immunity test requirements.

Indicator Specifications

The following specifications apply to the *DOMINO*® USS Indicator.

General

Operating temperature range	-10...+ 40 °C (+14 ... +104 °F)
Operating humidity	0...100 %RH , non-condensing
Menu languages	English, Finnish, French, German, Spanish, Swedish
Display	LCD with backlight Graphic trend display of any quantity Character height up to 16mm
Probe inputs	1 or 2
Power supply	Rechargeable NIMH battery pack, or 100-240 V, 47-63 Hz AC, or 4 x AA size alkalines, type IEC LR6
Analog output	0...1 VDC
Output resolution	0.6 mV
Accuracy	0.2 % full scale
Temperature dependence	0.002 %/°C full scale
Minimum load resistor.....	10 kohm to ground
Data interface.....	RS232C (EIA-232)
Data logging capacity	900...2700 real time data points,
Logging interval	1 s to 12 h
Logging duration	1 min ... memory full
Alarm	Audible alarm function
Housing classification.....	IP54
Weight	400 g
Housing material.....	ABS/PC-blend

Battery pack

Operation times in continuous use	48 h typical at +20 °C (68 ° F)
data logging use	up to 30 days
Power consumption during charge	10W max
Charging time.....	4 hours typical 6 hours first charging time

Indicator AC/DC Adapter

Power In	100-240 Vac, 47-63 Hz, 400 mA
Power Out	15 Vdc, 1A
Power In connector	selectable
Power Out connector.....	Coaxial, center +, outer -

Dimensional

Dimensions in mm (inches)



Moisture-In-Oil Probe Specifications

The following specifications apply to the *DOMINO*® USS Moisture-In-Oil Probe.

General

Humidity sensor.....	<i>DOMINO</i> ® Moisture-In-Oil Sensor
Temperature sensor.....	Pt100 IEC751 1/3 class B
Operating temperature range for electronics ..	-40...+60 °C, -40...+140 °F
Operation pressure range	0...20 bar (0 to 290 psi)
Standard sensor protection.....	Stainless steel grid
Housing classification.....	IP65 (NEMA 4)
Housing material.....	ABS/ PC blend
Probe material.....	Stainless steel (AIS316L)
Probe cable length	1.9 m
Extension cable.....	10 m
Probe head diameter	12 mm (0.47 inch)
Weight (incl. cap and press tool).....	520 g

Measured variables - Relative Saturation


Measurement range	0...100% (@-40...+60 °C/ -40...+140 °F)
Accuracy (including nonlinearity and repeatability)	
When calibrated against salt solutions (ASTM E104-85):	
between 0...90%.....	±2.0%
between 90...100%.....	±3.0%
When calibrated against high-quality, certified humidity standards:	
between 0...90%.....	±1.0%
between 90...100%.....	±2.0%
Response time (90%) at +20 °C (filter on) ...	10 min at oil flow of 0.6L/minute
Humidity sensor.....	<i>DOMINO</i> ® Moisture-In-Oil Sensor

Measured variables - Temperature

Measurement range -40...+100°C (-40...+212°F)
Typical accuracy at +20 °C (+68 °F) ±0.1 °C (±0.18°F)
Typical temp dependence of electronics ± 0.005°C/°C (±0.003°F/°F)
Temperature sensor Pt 100 RTD 1/3 Class B IEC 751

Dimensional

Dimensions in mm (inches)



Dewpoint Probe Specifications


The following specifications apply to the *DOMINO*® USS Dewpoint Probe.

Probe General

Sensor	<i>DOMINO</i> ® Dewpoint Sensor capacitive type
Probe material (wetted parts).....	Stainless steel (AISI 316L)
Sensor protection	Sintered filter, (AISI 316L)
Mechanical connection	G1/2" ISO2281 thread with bonded seal ring (U-seal)
Housing classification.....	IP65 (NEMA4)
Storage temperature	-40 ... +70 °C
Storage humidity.....	0 ... 100 % RH non-condensing
Weight	350 g

Measured Variables - Dewpoint Temperature

Measurement range.....	-60 °C (-76 °F) up to +20 °C (+68 °F)
Accuracy (see graph below)	± 2 °C (± 3.6 °F)



Dewpoint range for ± 2 °C. Accuracy for pressure converted dewpoint
(dewpoint measured in pressure, calculated to 1 atm dewpoint value)
..... -80 ... +20 °C (-112 ... 68 °F)
Response time: 63 % (90 %) at flow rate 0.2 m/s, 1 bar absolute pressure, +20 °C
0 \rightarrow -60 °C T_d (32 \rightarrow 76 °F T_d) 50 s (340 s)
-60 \rightarrow 0 °C T_d (-76 \rightarrow 32 °F T_d) 10 s (20 s)

Measured Variables - Temperature

Measurement range -10 °C (14 °F) to 60 °C (140 °F)
Accuracy at +20 °C ± 0.2 °C
Typical temperature dependence
of electronics ± 0.005 °C/°C
Temperature sensor Pt100 IEC751 1/3 class B

Measured Variables - PPM (ppm_v or ppm_w)

Measurement range (typical) 10 ... 20000 ppm
Accuracy at +20 °C (+68 °F)
< 40 ppm $\pm (0.5 \text{ ppm} + 25.4 \% \text{ of reading})$
> 40 ppm $\pm (7.3 \text{ ppm} + 8.3 \% \text{ of reading})$

Measurement Environment



Temperature -10 ... +60 °C (+14 ... +140 °F)
Pressure 0 ... 20 bar_a (0 ... 290 psi_a)
Sample flow rate No effect on the dewpoint accuracy

Sampling Cell

Inlet/outlet thread.....	ISO G 3/8"/G 1/4"
Quick connector included.....	Type D/NIP08/1/2 inch industrial
Thread adapters included.....	ISO G 3/8" to G 1/4" (female) and ISO G 3/8" to G 1/2" (male)
Leak screw	Screwdriver operated
Pressure limit	1 MPa, 10 bar _g , 145 psi _g
Material.....	Stainless steel AISI316
Weight	300 g

Dimensional

Dimensions in mm (inches)



This page intentionally left blank.

CHAPTER 28

OPTIONS, ACCESSORIES, AND SPARES

This chapter contains information on options, accessories, and spares that are available for the *DOMINO*® USS Systems.

MOI Probe accessories

Description	Doble Part No.
Stainless steel filter	230-0209
Soft yellow plastic protective cap	230-0216
Hard white plastic threaded protective cap	230-0217
Manual press tool	230-0211
Plastic clasp nut wrench	230-0218
Calibration adapter	09A-0831-01
<i>DOMINO</i> ® USS Manifold	03B-1653-01
1/2" NPT Female - 1" NPT Male Hex Bushing	230-0171
1" NPT Female - 2" NPT Male Hex Bushing	230-0170
Quick Disconnect Fitting Male Socket	09B-0824-01
Quick Disconnect Fitting Plug	09B-0825-01
Fitting body (M22 - 1/2 NPT)	230-0226
Fitting body (M22 - R1/2 ISO 7/1)	230-0181
ISO 7/1 Female - 1/2 NPT Male Adapter	230-0220
Blanking plug and nut	230-0221
Ball valve, stainless steel, 1/2 inch FNPT - 1/2 inch FNPT	230-0172
Nipple, stainless steel, 1/2 MNPT-1/2-14 BSP/ISO	09B-0761-01

DP Probe accessories

Description	Doble Part No.
Soft yellow plastic protective cap	230-0216
Sampling cell	230-0208
Sintered filter	230-0222
Bonded seal ring	230-0223
DP Quick Disconnect Fitting Male Socket	230-0224
DP Quick Disconnect Fitting Female Socket	230-0225

Indicator AC-Adapters

Description	Doble Part No.
Universal input AC/DC adapter with Australian, European, United Kingdom, and American plug inserts.	220-1381
Universal input AC/DC adapter with Australian plug insert.	220-1416
Universal input AC/DC adapter with European plug insert.	220-1417
Universal input AC/DC adapter with United Kingdom plug insert.	220-1418
Universal input AC/DC adapter with American plug insert.	220-1419
Rechargeable battery	903-0083

Cables

Description	Doble Part No.
Probe Extension Cable. Length 10 meters (32 ft 9 inches)	181-0658
Analog Output Signal Cable. Length 1 meter (3 ft 3 inches)	181-0659

Documentation

Description	Doble Part No.
<i>DOMINO</i> USS User Guide (English)	500-0591
<i>DOMINO</i> USS User Guide (Spanish)	500-0701
<i>DOMINO</i> USS Moisture-In-Oil Quick Start Guide	500-0592

Software

Description	Doble Part No.
<i>DOMINO</i> Connects software interface kit. Includes software CD and 1 meter (3 ft 3 inches) Indicator To PC cable.	401-0288
USB-Serial Adapter	401-0302

Others

Description	Doble Part No.
Small Doble Screwdriver	09B-0696-01

System Components

Description	Doble Part No.
USS Indicator. Includes rechargeable battery (903-0083) and Universal input AC/DC adapter with Australian, European, United Kingdom, and American plug inserts (220-1381)	401-0287
USS Moisture-In-Oil Probe. Includes quick disconnect male plug and set of probe accessories including manual press tool, hex wrench, protective cap, and plastic wrench	03D-1678-01
USS Dewpoint Probe. Includes assembled sampling cell and set of adapters.	03D-1681-01

This page intentionally left blank.