



## HVA28 | HVA34-1 | HVA45 and corresponding TD models HVA68TD

High Voltage test system






## Table of Contents

<b>1</b>	<b>Introduction</b>	<b>5</b>
1.1	Regarding this document	5
1.2	Designated use	6
1.3	Operator qualifications	7
1.4	Legal considerations	7
1.5	Technical support	7
<b>2</b>	<b>Safety instructions</b>	<b>8</b>
2.1	Safety rules for HV testing	8
2.2	Safe equipment setup	8
<b>3</b>	<b>About the smartVLF® series</b>	<b>9</b>
3.1	Key applications	9
3.2	Product features	9
3.3	Technical specifications	11
3.4	Expanding to further measurement capabilities	11
<b>4</b>	<b>Setup &amp; operating the smartVLF® series</b>	<b>12</b>
4.1	Device interface	12
4.2	Test set settings	17
<b>5</b>	<b>Application</b>	<b>23</b>
5.1	HVA68TD test lead	24
5.2	VLF Withstand Test & DC Test	26
5.3	TD Diagnostics & Monitored Withstand Test	28
5.4	TD Diagnostics & Monitored Withstand Test and Guard on Near End	30
5.5	TD Diagnostics & Monitored Withstand Test and Guard on Near and Far End	32
5.6	Sheath Test	34
5.7	Vacuum Bottle Test	36
<b>6</b>	<b>Test procedure</b>	<b>38</b>
6.1	Test modes overview	38
6.2	Manual mode overview	39
6.2.1	Setting report details for a manual test mode	40
6.2.2	Characteristics of different output modes	41
6.2.3	Manual test parameters	43
6.2.4	Running a manual test	45
6.2.5	Test summary - test successful	47
6.2.6	Test summary - test failed	47
6.3	Running an auto test - overview	48
6.3.1	Running an auto test - last used sequence	49
6.3.2	Running an auto test - select a sequence from the list	51
6.4	Creating an auto test sequence - overview	53
6.4.1	Configuring a new auto test sequence	54
6.4.2	Modifying an existing auto test sequence	58
6.5	Interrupting a test	61
6.6	Discharge status	62
<b>7</b>	<b>Reporting</b>	<b>63</b>
7.1	Report types	63
7.2	Report parameters	64
7.3	Test report examples	68
7.4	Report management	70
<b>8</b>	<b>Disconnection procedure</b>	<b>76</b>
<b>9</b>	<b>PC software</b>	<b>78</b>
<b>10</b>	<b>Additional information</b>	<b>79</b>
10.1	Storage	79
10.2	Apparatus care	79
10.3	Behavior at different unexpected conditions	79
10.4	Disposal	80

## Abbreviations and Glossary

List of terms used in the smartVLF® user manual, sorted alphabetically:

Term	Meaning
<b>APL</b>	Arc Pre-Location If the test results in an arc, this function can pre-locate arcs in the DUT's insulation while testing. The APL function is only available on the HVA68TD and constantly monitors for arcing during operation.
<b>Arc</b>	Self-maintained gas conduction for which most of the charge carriers are electrons supplied by primary-electron emission. (Source: IEC)
<b>Auto frequency</b>	Mode that automatically selects a frequency as close as possible to 0.1 Hz depending on the connected load.
<b>DUT</b>	Device Under Test
<b>HV</b>	High Voltage
<b>MWT</b>	Monitored Withstand Test
<b>Propagation velocity</b>	Speed at which an electrical signal can propagate through the cable given in [m/μs] or [ft/μs]. The propagation speed depends mainly on the used insulation material of the cable.
<b>RMS value</b>	Root mean square voltage of sine wave voltages. $V_{rms} = V_{max} / \sqrt{2}$
	
<b>Sample</b>	Applies to Tan Delta measurements only and defines test duration. Each valid measurement value is one sample. In general, you get one sample per period (0.10 Hz → 10 s is one period).
<b>SCF</b>	Signal Confidence Factor Each arc creates a unique signal from which the APL calculates the distance to the arc. The SCF is a measure of how accurately the APL can calculate the distance from this signal. On the device, APL requires at least a SCF higher than 2 to pre-locate arcs. A SCF higher than 4 can be considered as high confidence and provides meaningful results.
<b>Sequence</b>	Test consisting of up to 15 test steps.
<b>TD</b>	Tangent Delta / Tan Delta
<b>to short</b>	Forcing the electric potential differences between two or more conductive parts to be equal to or close to zero (infinite current flows in a short circuit).
<b>to trip</b>	to stop, if an arc occurs
<b>VLF</b>	Very low frequency 0.1 to 0.01 Hz range
<b>Withstand Test</b>	Test in which a voltage of a predetermined magnitude is applied for a predetermined time duration.

# 1 Introduction

## Purpose

This user manual provides information on the proper and safe use of the HVA test set, a member of the smartVLF® series. It contains important safety rules for working with this product and gets you familiar with operating this product. Following the instructions in this document will help you to prevent danger, repair costs, and avoid possible down time due to incorrect operation.

## 1.1 Regarding this document

This user manual applies to the corresponding VLF high voltage test sets: HVA28, HVA28TD, HVA34-1, HVA34TD-1, HVA45, HVA45TD and HVA68TD.

### Safety first



#### NOTICE

While working with the HVA test set, it is essential to always keep this document at hand. Proceed with the measurement only if all safety precautions, applicable normative and relevant safety regulations are obeyed.

### Documentation conventions

Safety colors and safety signs mentioned in this document are used in accordance with the International Organization for Standardization technical standard ISO 3864-2; symbol definitions in accordance with ISO 17724. All safety signs and their referents are used in accordance with ISO 7010.

### Hazard Severity Panels

Hazard severity panels mentioned in this document are used in accordance with the International Organization for Standardization technical standard ISO 3864-2. They are rectangular in shape and contain the following elements: the general warning sign, the hazard severity panel color and the signal word (which is however optional). Signal words appear in upper case and bold fonts.

- **High level of risk**

Red background with a white contrast color and a warning sign.

Danger label: Indicates a hazardous situation that, if not avoided, will result in death or serious injury.

- **Medium level of risk**

Orange background with a black contrast color and a warning sign.

Warning label: Indicates a hazardous situation that, if not avoided, could result in death or serious injury.

- **Low level of risk**

Yellow background with a black contrast color and a warning sign.

Caution label: Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

### Signal Word Definitions

#### DANGER

Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

#### WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

#### CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

#### NOTICE

Indicates information considered important but not hazard related.

## Safety signs and their referents



Warning sign  
 Hazard: Electricity  
 Human behavior intended: Taking care to avoid coming into contact with electricity.



Prohibition sign  
 Hazard: Risk to people specified by the supplementary sign.  
 Human behavior intended: Not doing an action specified by the supplementary sign.



Mandatory action sign  
 Hazard: Risk to people not following the mandatory action specified by the supplementary sign.  
 Human behavior intended: Carrying out mandatory action specified by supplementary sign.

## 1.2 Designated use

HVA test sets of the smartVLF® series are designed to perform routine and diagnostic high voltage insulation testing of various types of highly capacitive loads during manufacturing, commissioning, and maintenance. The various, partly automated, tests can be defined and parametrized via the user interface at the device's front panel or via an externally connected PC or laptop.

### Appropriate devices under test (DUTs)

#### Cables:

- Extruded cables (e.g. XLPE)
- Laminated cables (e.g. PILC)
- Insulated cables
- Cable jackets/sheaths

#### Other capacitive loads:

- Generators
- Switchgear
- Transformers
- Rotating machines
- Insulators
- Bushings



### NOTICE

Other devices:  
 Before proceeding, contact HV Diagnostics to validate appropriate use.

### Appropriate high voltage tests

- VLF withstand test
- VLF Tan Delta test (for devices with integrated Tan Delta diagnostics capabilities)
- Monitored withstand test (for devices with integrated Tan Delta diagnostics capabilities)
- DC test
- Vacuum bottle test
- Sheath test
- Jacket / Sheath fault location

### Further measurement possibilities

- Capacitance
- Resistance
- Dielectric breakdown voltage
- RMS current
- Applied voltage
- Tan Delta (for devices with integrated Tan Delta diagnostics capabilities)
- Distance to the arc (applies to test sets with APL functionality only)



## NOTICE

Should the HVA test set not seem to function properly, do not use it anymore and contact HV Diagnostics Technical Support right away (see Chapter 1.5 Technical Support for contacts). Only qualified experts at the HV Diagnostics Repair Center may open the device for inspection, maintenance and repair work.

### 1.3 Operator qualifications

Working on high voltage assets can be extremely dangerous. Only personnel qualified, skilled, and authorized in electrical engineering are allowed to operate this HVA test set and its accessories! Proof of necessary qualifications for working in the high voltage domain as well as obeying relevant local safety regulations is mandatory.

Before approaching the work, clearly establish all responsibilities.

The supervising operator is responsible for the safety requirements during the whole measurement.

### 1.4 Legal considerations

#### Compliance statement

The device is designated in the following statements as “test set”, “product”, “device”, “equipment”, or “apparatus”.

All appropriate high voltage tests, listed in the chapter 1.2 Designated use, comply with following guides or standards:

- VLF withstand tests with IEEE 400.2; standards DIN VDE 0276-620 (CENELEC HD 620 S2), DIN VDE 0276-621 (CENELEC HD 621 S1);
- AC and sheath testing with IEC 60502-2 / IEC 60229.

They are all implemented in the device software.

#### Declaration of conformity (EU)

The equipment adheres to the guidelines of the council of the European Community for meeting the requirements of the member states regarding one or a combination of the following directives: Electromagnetic compatibility (EMC) directive; Low voltage directive (LVD); RoHS directive.

#### Declaration of conformity (UK)

The equipment adheres to the regulations of the UK government for meeting the requirements regarding one or a combination of the following regulations:

- Electromagnetic Compatibility (EMC) Regulation
- Electrical Equipment Regulation (Safety)
- Regulation for Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment

#### FCC compliance (USA)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. If this equipment does cause harmful interference to radio or television reception, contact HV Diagnostics Technical Support.

#### Copyright

© 2024 HV Diagnostics Inc.

All rights reserved.

No part of this publication may be reproduced, transmitted, stored, or translated in hard copy or electronic form without the written consent of HV Diagnostics Inc.

### 1.5 Technical support

HV Diagnostics Technical Support provides you with following services regarding the HV Diagnostics products.

- Technical support
- Technical information on repairs
- Basic applications assistance
- Product trainings
- Support at measurement for training purposes

You can reach us at [service@hvdiagnostics.com](mailto:service@hvdiagnostics.com) or under T +1 678-445-2555.

## 2 Safety instructions

In this chapter, the most important safety instructions for the use of the HVA test set are summarized. Respect all safety information contained in here! If you do not understand any of the safety instructions, contact HV Diagnostics Technical Support before proceeding (see previous page for contacts).

Before carrying out any high voltage test with an HVA test set, read these safety instructions in their entirety.



### NOTICE

Do not operate the HVA test set without understanding the safety information! HVA test set is meant for specific applications only. Use it in a safe manner and working condition only.

### 2.1 Safety rules for HV testing



#### CAUTION

It is mandatory to obey the five safety rules in the following order at all times!

1. Switch out Device Under Test
2. Secure against re-energizing
3. Discharge and prove dead
4. Ground and short circuit
5. Cover or close off nearby live parts

You may proceed with the measurement using this HVA test set only if all safety precautions, applicable normative and relevant local safety regulations are obeyed.



#### WARNING

Please study the equipment setup for the specific HVA test set in order to set up the equipment in a safe manner!

Establish secure grounding via connection **1**. Follow the "Safe equipment setup" instructions in the chapter 2.2 below to do that in a safe and proper manner.



#### DANGER

##### Electric Shock Hazard!

NEVER assume that equipment is safe to handle without using the necessary safety equipment and grounding procedures.

### 2.2 Safe equipment setup

Prior to starting the measurement, please refer to the equipment setup for the specific HVA test set and the five safety rules mentioned above under "Caution".

When dismantling, secure the appliance against being switched on again by pressing the "Emergency OFF" button. Lock the system with the key switch. Remove and stow the key away to prevent unauthorized people from accessing it.

## 3 About the smartVLF® series

### 3.1 Key applications

For the devices with integrated Tan Delta diagnostics capabilities the TD test results of the device under test can be easily measured, recorded and displayed on the screen of the test set. The test results can be easily stored via USB flash drive, Bluetooth synchronization or internal memory.

Matching PC software HVD ControlCenter is included in the scope of delivery. With this PC software the test results can be easily stored on a PC or laptop for analysis, trending or quality control. This enables the cable engineer to now make TD testing a routine maintenance test. Additional benefits include:

#### Cable testing

All test sets of the smartVLF® series are designed to perform high voltage insulation testing of various types of highly capacitive loads with pure sinusoidal, square or DC output voltage. Appropriate devices under test are cables (extruded, laminated, in other way insulated) or other highly capacitive loads (see Chapter 1.2 Designated use).

#### Cable diagnostics

HVA28TD, HVA34TD-1, HVA45TD and HVA68TD are VLF test units with integrated Tan Delta measuring system. Such a test set provides a high voltage Tan Delta measuring system suitable for testing medium voltage electrical insulation systems such as cables, capacitors, switchgear, transformers, rotating machines, insulators and bushings. Tan Delta testing enables the cable test engineer to detect insulation defects before the cable fails in service.

#### Cable fault pre-location

VLF withstand tests are used to detect weaknesses in the cable insulation. While a healthy cable will pass the voltage withstand test unharmed, a cable with pre-damaged insulation will break down during this test, resulting in an arc. The HVA68TD test set is equipped with the Arc Pre-Location function (APL). When a breakdown occurs during testing, the APL function calculates the distance to the arc position. This helps to save time and cost in the subsequent cable fault location process. Please consider that the APL function is a pre-location method and cannot replace a full cable fault location process.

### 3.2 Product features

To assure that the workplace is safe and that operators can fulfil their responsibilities with ease, the HVA provides the following features:

	Feature	Purpose	Advantage
Testing	<b>Built-in memory</b>	<ul style="list-style-type: none"> <li>To save test sequences</li> <li>To save test reports</li> </ul>	Facilitates documentation and subsequent test repetition
	<b>Comprehensive reporting</b>	To document your measurement results automatically	Saves the user an extra step
	<b>Fully automatic test sequences</b>	To test according to IEEE or other standards	<ul style="list-style-type: none"> <li>Facilitates complex testing</li> <li>Facilitates test repetition</li> </ul>
	<b>Integrated TD</b>	Proven, simple and reliable test method for obtaining diagnostics values from the insulation of the DUT (HV cable)	<ul style="list-style-type: none"> <li>Enables the user to do MWT tests</li> <li>Makes TD test to a routine maintenance test (Remark: Possible with symmetrical sine only.)</li> </ul>
	<b>Load-independent output</b>	To display true symmetrical sine and square waveforms	Facilitates testing
	<b>Optimized frequency selection / automatic load measurement</b>	<ul style="list-style-type: none"> <li>To test capacitive loads</li> <li>No equipment exchange needed</li> <li>No changes in settings necessary</li> </ul>	<ul style="list-style-type: none"> <li>Facilitates testing</li> <li>Limits number of connections to the DUT</li> </ul>
	<b>Real time display</b>	To instantly indicate output voltage	Facilitates testing
	<b>Unlimited operation (Duty cycle)</b>	Operating time is within the specifications	Continuous operation

	Feature	Purpose	Advantage
Safety	<b>Discharge status indication</b>	The red LED <sup>71</sup> flashes if the measured voltage at the output is higher than 100 V	Improves safety during normal disconnection procedures
	<b>Fully integrated discharge and transient circuit</b>	<ul style="list-style-type: none"> <li>To ground the DUT after testing as it avoids self-recharging of the DUT</li> <li>To protect the device from transient over-voltages</li> </ul>	<ul style="list-style-type: none"> <li>Improves safety</li> <li>Protects the test set</li> </ul>
	<b>Initial load balance at reduced voltages</b>	To check automatically for shorts or grounds, during load measurement, before test initiation	Improves safety
	<b>Instrument lock - key switch</b>	To prevent unauthorized use	Locks the device and protects the operator as well as the device itself
	<b>Local and optionally available remote Emergency OFF switches</b>	To shut down operations in emergency situation	Improves safety
	<b>Return voltage indication</b>	To monitor external high voltage greater than 100 V (AC)	Improves safety
Smart benefits	<b>APL*</b>	<ul style="list-style-type: none"> <li>Pre-locates arcs in the DUT's insulation</li> <li>Returns distance values if an arc occurred</li> </ul>	<ul style="list-style-type: none"> <li>Monitors constantly for arcing during operation</li> <li>Pre-location adds additional value to traditional VLF testing</li> <li>Saves time and costs in the subsequent cable fault location process</li> </ul>
	<b>Arc management</b>	<ul style="list-style-type: none"> <li>To provide short-circuit protection</li> <li>To allow fault conditioning</li> </ul>	It is up to the user, if the fault should be conditioned or the system trips / test stops.
	<b>Bluetooth</b>	<ul style="list-style-type: none"> <li>To send test reports</li> <li>To upload test sequences</li> </ul>	<ul style="list-style-type: none"> <li>Facilitates documentation</li> <li>Facilitates test repetition</li> </ul>
	<b>Dual Discharge Device (DDD)</b>	Unique feature of HVA test sets. Two independent discharge devices - one electronic and one mechanical	Enhanced safety for the user in regard to the device
	<b>Hinged lid*</b>	Provides additional storage surface and space during the measurement.	<ul style="list-style-type: none"> <li>Practical platform for placing the notebook during work</li> <li>180° rotatable</li> </ul>
	<b>IP67** (with closed lid)</b>	<ul style="list-style-type: none"> <li>To avoid damage during transport/storage</li> <li>No additional transport boxes necessary</li> </ul>	Watertight and very rugged case that protects instrument and improves functionality
	<b>Maintenance-free design</b>	To avoid moving parts and need for lubrication	<ul style="list-style-type: none"> <li>Reduces maintenance</li> <li>Improves instrument durability &amp; reliability</li> </ul>
	<b>Multi-purpose HV test lead*</b>	Depending on the test purpose, the adapters can be easily exchanged	A single HV test lead with two DUT adapters for VLF withstand test, TD diagnostics and PD diagnostics
	<b>Portable and lightweight</b>	Lightest and most powerful devices in their voltage range	Widely applicable for field use and on-site testing
<b>USB flash drive</b>	<ul style="list-style-type: none"> <li>To store and share unlimited number of test reports</li> <li>To upload test sequences</li> </ul>	<ul style="list-style-type: none"> <li>Facilitates documentation</li> <li>Facilitates test repetition</li> </ul>	

\* only available for the HVA68TD test set

\*\* applies only to HVA28, HVA34-1, HVA45 test sets and their corresponding TD derivatives

### 3.3 Technical specifications

Test Set	Output voltage	Output load	Weight
<b>HVA28 &amp; HVA28TD</b> 	max. 29 kV <sub>peak</sub> , 21 kV <sub>rms</sub>	0.5 μF @ 0.1 Hz @ 20 kV <sub>rms</sub>	14 kg / 31 lbs.
<b>HVA34-1 &amp; HVA34TD-1</b> 	max. 34 kV <sub>peak</sub> , 24 kV <sub>rms</sub>	1.5 μF @ 0.1 Hz @ 24 kV <sub>rms</sub>	39 kg / 86 lbs.
<b>HVA45 &amp; HVA45TD</b> 	max. 45 kV <sub>peak</sub> , 32.3 kV <sub>rms</sub> +4 kV option: max. 49 kV <sub>peak</sub> , 34.6 kV <sub>rms</sub>	0.9 μF @ 0.1 Hz @ 32.3 kV <sub>rms</sub>	39 kg / 86 lbs.
<b>HVA68TD</b> 	max. 68 kV <sub>peak</sub> , 48 kV <sub>rms</sub>	2.0 μF @ 0.1 Hz @ 44 kV <sub>rms</sub>	63 kg / 139 lbs.

For more detailed information on the devices, please go to <https://www.hvdiagnostics.com/cable-diagnostics>.

### 3.4 Expanding to further measurement capabilities

All smartVLF® systems can be operated in combination with our external PD and PDTD diagnostic systems in order to expand their diagnostics capabilities on partial discharge evaluation. We offer the widest range of solutions on the market, from portable and modular PD instruments up to trailer-mounted systems for all voltage ranges of our HV test sets. For more information, please go to <https://www.hvdiagnostics.com/cable-diagnostics>.




## 4 Setup & operating the smartVLF® series

### 4.1 Device interface

#### 4.1.1 Front panel

All HVA control and connection components are located on the front panel and/or the side panel. There are three device variants in the smartVLF® series. Below is the table with the features of their front panels (and one side panel) followed on the next side by the depiction of the panels.


Nr.	Name	Description
1	<b>Grounding connector</b>	Serves as connection point from the HVA to ground.
10	<b>HV output connector</b>	Serves as connection point from the HVA to the HV test lead. To connect: Unscrew the black protection cap, screw the HV test lead into the HV output connector (until a click can be heard) and tighten.
30	<b>Power supply socket</b>	Serves as connection point from the HVA to a power source. The specification is given on the corresponding type plate.
31	<b>Communication port</b>	Serves as connection point from the HVA to a USB flash drive.
40	<b>HV switch [I/O] button</b>	Activates and deactivates high voltage. To activate HV output: Press within 10 seconds after "Start". To deactivate HV output: Press during HV is activated.
41	<b>Navigation knob</b>	Enables user to select and confirm options and functions shown on the display. To scroll the selection up or down / left or right: Rotate. To enter the selection: Click (push in).
42	<b>Emergency OFF button</b>	Activates emergency shut-down. HV operation is only possible, if this button is deactivated. To activate "Emergency OFF": Press in. To deactivate "Emergency OFF": Release latch and rotate.
43	<b>Key switch [ON/OFF]</b>	Locks the unit to prevent unauthorized use. To disable unit: Remove key from the OFF Position. To reactivate unit: Insert key and turn to ON Position.
44	<b>Main switch [I/O]</b>	Activates the HVA. This switch is a fuse with integrated magnetic auto-reset 16 A. To reset: Turn the main switch off (O) and then on (I) again.
47	<b>Remote control interlock plug</b>	Provides interlock for the remote switch (i.e. door interlock), contains red and green signals. Can be connected to a remote "Emergency OFF" switch, a gate, a foot pedal or a dead man switch.
48	<b>Air vent</b>	Provides cooling of electronic components.
70	<b>Display screen</b>	Displays menu, options and status information.
71	<b>Red LED</b>	Indicate HV status on the device. • Green LED on, red LED off: The device is ready, HV is not yet applied to the device.
72	<b>Green LED</b>	<b>Attention:</b> This is NO indication that DUT is fully discharged or safe. • Green LED on, red LED on: During switch-on process of the HVA to see if LEDs are working. • Green LED off, red LED on: HV is applied, the test starts / is running. • Green LED on, red LED flashing: a) The device is discharging or, b) backfeed voltage is present. HV is not applied but external voltage has been detected. Voltage at HV test lead sensed > 100 V.

**HVA28, HVA28TD - front panel**

**HVA34-1, HVA34TD-1, HVA45, HVA45TD - front panel**

**HVA68TD - front panel**


### 4.1.2 Screen

The display screen is the same for all smartVLF® test sets. The part between the black header and footer areas shows the current procedure. During the preparation of the measurement, the measurement itself and after the measurement, this field adapts to the procedure in progress.


The meaning of the separate elements is as follows:



### 4.1.3 Operating the keyboard

For some steps in the settings for sequences and reports, the operator is required to enter some information via the keyboard. Possible entries are:

- A B C D E F G H I J K L M N O P Q R S T U V W X Y Z (Remark: only the capital letters are available)
- + - "space" . ( ) # @ \* / \ ! ? = : , ; ' % ° ^ < > | & [ ]
- 0 1 2 3 4 5 6 7 8 9



### Information and Warning Messages

There will be some situations during the measurement procedures when the test set shows some kind of information or warning message. Below are four examples of such messages with their explanations.


#### INFORMATION

This screen gives an information. You have only one option here. Press **"OK"** to confirm.




#### QUESTION

This screen indicates a user interaction/question. Consider the information on the screen and make your choice by selecting **"Yes"** or **"No"**. In some cases, where applicable, an option **"Delete All"** appears, too.



#### WARNING


This screen shows a warning. You have only one option here. Press **"OK"** to confirm.



#### ERROR

This screen indicates an error. The operation in progress could not be finished successfully.

Please consider the information and decide, if further action is necessary. Press **"OK"** to confirm.




#### 4.1.4 Data transfer modes

The HVA's built-in memory can save up to 50 reports and 50 test sequences. Furthermore, an unlimited number of reports and sequences can be stored when the HVA is connected to the PC software or by using a USB flash drive.

##### USB configuration:

All reports saved in the HVA memory can be transferred to a USB flash drive. To see the data administration, please go to "Settings" / "Data Administration".



##### Bluetooth configuration:

If the HVA is connected to the HVD ControlCenter, reports and sequences can be downloaded from the HVA using the corresponding functions. See software manual for further information.

For information on how to access data transfer modes and apply them for Sequence and Report Management, please go to chapter 4.2.4 Data administration.

#### 4.1.5 External interlock

This connector is part of the test sets HVA34-1, HVA34TD-1, HVA45, HVA45TD and HVA68TD and allows to expand the HVA test set with a remote interlock and remote signal lamps for indicating the HV status.

If no external interlock is attached, the "xy" interlock bridge plug needs to be used for operation with HV.

**47**

Ext.  
Emergency OFF

**interlock  
plugged in**

Ext.  
Emergency OFF

**interlock  
open**

Depiction of the connector on the test set.

PIN1: Interlock	1	
PIN2: Interlock	2	
PIN3: Not in use	3	
PIN4: Not in use	4	
PIN5: Lamp HV ON	5	
PIN6: Lamp HV OFF	6	
PIN7: Ground (GND)	7	



#### NOTICE

Check the function of the remote of the switch for mechanical damage before each use!

##### Equipment not included:

Cables for remote control and external lamps are not in scope of delivery!

##### Cable requirements:

- Twisted pair; rating: 600 V
- Dimensions: 18 gauge or 1 mm<sup>2</sup>; recommended cable length: max. 50 m
- 2-pole to 5-pole cable

##### External lamp requirements:


- Specifications: 12 V, max. 1.2 W
- Recommended colors: red, green

## 4.2 Test set settings

We advise you to deal with the instrument setup prior to the HVA's first use. Although, settings can be modified anytime. You will find the selection option Instrument Setup in the main menu under "Settings".

### Initial display screen

The display screen is the same for all smartVLF® test sets.



### Test set settings

You will find the selection option "Instrument Setup" in the main menu under "Settings". Here you can set the instrument setup, get the information on the connected test set, choose a language and set up the data administration.


Each of these four categories has a separate sub-chapter on the following pages (4.2.1 thru 4.2.4). There, each feature is described in detail.



## 4.2.1 Instrument setup


### IS1: Settings

From the main menu, select "Settings"



### IS2: Instrument Setup



Select "Instrument Setup"



### IS3: Set Date and Time

Select "Set Date and Time". This information will be shown on the screen of the test set at all time.  
Hours range: 0 to 23  
Minutes range: 0 to 59

Remark:  
The months are only available by their names and not by the numbers 1 to 12.



#### IS4: TD Evaluation Criteria

A table where Tan Delta limits defined in IEEE400.2 guide are demonstrated. They are displayed via a traffic light labeling system, depending on the test results.

The data in this table depends on the last used sequence. They cannot be changed, but are rather informative.

Main Menu   Edit Sequences   Initial Limits			
No Standard		XLPE	
Condition Assessm.	TDTS 1.0U <sub>o</sub> [E-3]	DTD [E-3] (1.5U <sub>o</sub> - 0.5U <sub>o</sub> )	TD 1.0U <sub>o</sub> [E-3]
No Action Required	< 0.5	& < 2.5	& < 10.5
Further Study	0.5 .. 1.1	2.5 .. 5.5	10.5 .. 50.5
Action Required	> 1.1	> 5.5	> 50.5

Cancel

Thursday, January 11, 2024 11:35 AM

#### IS5: Reporting

Reporting types:

- Disabled
- Basic
- Extended

**Basic reporting** only states the DUT type and a title, whereas **extended reporting** provides detailed information on DUT. Go to chapter 7.2 Reporting parameters for further information.

Main Menu | Settings | Instrument Setup

Set Date and Time

TD Eval Criteria

Reporting Basic

Bluetooth Class 1

Units of Mea.. Metric

Update from USB

Set  
Cancel

Friday, January 01, 2016 12:01 AM

#### IS6: Bluetooth

Depending on the Bluetooth setting, the device selects the corresponding RF transmission speed.

Setting types:

- Class 1
- Disabled

Main Menu | Settings | Instrument Setup

Set Date and Time

TD Eval Criteria

Reporting Basic

Bluetooth Class 1

Units of Mea.. Metric

Update from USB

Set  
Cancel

Friday, January 01, 2016 12:01 AM

#### IS7: Units of measurement

The options are:

- Metric
- Imperial

When imperial units are selected, the temperature is automatically displayed in °F.

Main Menu | Settings | Instrument Setup

Set Date and Time

TD Eval Criteria

Reporting Basic

Bluetooth Class 1

Units of Mea.. Metric

Update from USB


Set  
Cancel

Friday, January 01, 2016 12:01 AM

**IS8: Update from USB**

This function is used when installing updates and for transferring information from the PC software to the unit via USB flash drive.

Remark:  
Insert the USB flash drive before selecting this function.



**4.2.2 System information**


**SI1: Settings**

From the main menu, select "Settings"



**SI2: System Information**


Select "System Info"



**SI3: System Information**

The following information regards the connected test set and cannot be modified by the operator:

- Firmware version
- Serial number
- Nickname (to alter via PC software)
- Bluetooth MAC address
- USB | APL version
- Date of last calibration
- Device temperature



## 4.2.3 Language and region


### L1: Settings

From the main menu, select "Settings"




### L2: Language and Region

Select "Language and Region"



### L3: Select a language


The list of available languages is based on the firmware version.



### L4: Select a region

The list of available regions is based on the firmware version.


Based on the region setting, the test set selects the corresponding date/time format. "International" region has the date/time format as depicted on the screen shots in this manual.



## 4.2.4 Data administration

### DA1: Settings

From the main menu, select "Settings"




### DA2: Data Administration

Select "Data Administration".

Remark:

In order to export or import data via an USB flash drive, you need to insert one into the device. If no USB flash drive is connected, this option is greyed out and not available.



### DA3: Sequence Management


In first line, the number of available sequences on the test set is given.

You have two options here:

- delete all sequences from the device
- import sequences from USB

Remark:

Accepted sequence format: \*.hse




### DA4: Report Management

In 4th line, number of available reports on the test set is given.

You have two options here:

- delete all reports in device
- export reports to USB

Reports can be exported in multiple file formats (HRE+HTML, HRE or HTML). The reports will remain on the device and may be deleted manually.



## 5 Application

### Setup and Installation:

Connect the device in accordance with the technical specifications. Specification of the electrical connection values is mentioned on the rating plate.



### NOTICE

If the device is connected to a voltage other than the rated voltage, the appliance may be destroyed:  
Fire hazard.

We strongly advise you to use only spare parts specified by the manufacturer.

Avoid using defective mains, high voltage test leads or grounding cables for the installation and operation of the appliance, this can lead to life-threatening situations.

Connect the appliance as specified in the operating instructions. Use the cable types and cable colors as depicted on the connection schemes. With the HVA68TD device, the HV test lead can be operated in two different directions. Depending on the intended use (VLF, TD configuration or PD configuration), the connection direction must therefore be changed. Make sure that the direction matches your test purpose. See chapter 5.1 on the next page for more information.

Check the HV test lead, grounding lead, as well as all other cables for mechanical damage before each use! Should there be any defective cables on the measurement site, replace them immediately with new, undamaged ones.

Ensure that the ventilation ducts are clear all around during installation and operation. Keep a distance of at least 0.5 m / 1.5 ft from walls.

### Switching on the device:

When switching on the device, observe the sequence in which the signal lamps (green, red) and the messages on the display light up. If one of the two lamps does not light up, the appliance must be switched off immediately via the "Emergency OFF" button  and the HV Diagnostics Technical Support team contacted.

Further information on the signal lamps can be found in chapter 4.4.1 Front panel in the last section of the table.


### While measuring:

If any unusual situation is suspected, the appliance must be:

- switched off immediately using the "Emergency OFF" button  as well as test set main switch
- disconnected from the mains.

## 5.1 HVA68TD test lead

For HVA68TD test set, the latest member of the smartVLF® series, we have a new design for connecting the test set to the device under test. The HV test lead for the HVA68TD test set consists of an HV test lead and two different DUT adapters. For **transport** the DUT adapters are used as protective caps. Depending on your test purpose, one or the other DUT adapter needs to be removed to screw that cable end into the HVA. The other adapter stays on the HV test lead and will be connected to DUT.



The different DUT adapters can be easily identified by the different materials and colors of the thread. The standard DUT adapter's thread is silver and made of metal and has a grounding clamp, the PD DUT adapter's thread is made of black plastic. Always consider that the HV test lead's knurled rotatable rings match the DUT adapter's material (metal – metal, plastic – plastic).


### Standard configuration

For non-PD operation (VLF, TD, DC, MWT, Sheath test, Vacuum Bottle test) the HV plug with the black thread needs to be tightened into the HVA.

The plug with the metal thread needs to be connected to the DUT adapter with the metal thread and the grounding clamp.

#### Attention!


The grounding clamp of the DUT adapter is for overvoltage protection only. It does not provide grounding of the cable shield.



### PD configuration

For PD operation the HV plug with the metal thread needs to be tightened into the HVA.

The plug with the black plastic thread needs to be connected to the DUT adapter with the black plastic thread.



### NOTICE

Use the standard configuration for all tests and applications described in this manual (on following pages).

The length of the standard HV test lead (7 m / 23 ft) is already considered in the result of the APL measurement.  
If a longer HV test lead is used, the additional length needs to be subtracted from the displayed APL result.

## 5.2 VLF Withstand Test & DC Test






### DANGER

#### Electric shock hazard

All procedures must comply with local safety regulations. Make sure you obey the five safety rules in the order listed in chapter 2.1 on page 8!

- Before operating the HVA test set, equipment set up procedure must be completed!
- Cables must be connected according to the sequence below!
- Before turning on the power supply and before activating the HVA test set, verify that all system elements are properly grounded!

Connection diagrams:



**Procedure steps:**

<b>S1</b>	<b>Connect all grounding cables.</b> Discharge and ground the DUT complying with local safety regulations. Connect the grounding cable to the HVA grounding connector <b>1</b> . Prepare grounding for measurement <b>3</b> <b>4</b> on both Near and Far End.
<b>S2</b>	<b>Connect power supply <b>30</b>.</b>
<b>S3</b>	<b>Connect all HV cable connections.</b> <ul style="list-style-type: none"><li>• Screw the HV test lead into the HVA HV output connector <b>10</b>.</li><li>• Connect the grounding clamp of the HV test lead <b>2</b> to protection ground.</li></ul> <b>Attention!</b> The grounding clamp of the DUT adapter is for over-voltage protection only and does not provide safe grounding of the cable shield. <ul style="list-style-type: none"><li>• Connect the other end of the HV test lead to the DUT <b>17</b> (HVA68TD: an example with corona shield <b>K1</b> applied).</li></ul>
<b>S4</b>	<b>Verify connections.</b> Check that all cables are attached securely on both Near End and Far End.
<b>S5</b>	<b>Configure interlock plug.</b> Verify that the HV emergency adapter is connected <b>47</b> . <b>If operating with remote controls (optional):</b> Connect external lamps or remote switches.
<b>S6</b>	Configure communication port. For USB data transfer mode, insert USB flash drive <b>31</b> .
<b>S7</b>	Turn "ON" the HVA main switch <b>44</b> (if applicable, e.g. HVA68TD).
<b>S8</b>	Turn key switch <b>43</b> to "ON" position.
<b>S9</b>	The HVA system automatically boots. Start-up default screen appears. Select appropriate option from default screen and proceed to appropriate section for further instructions.

## Remark:

Apply the same order of the phases on both Near and Far End.

### 5.3 TD Diagnostics & Monitored Withstand Test


DANGER

**Electric shock hazard**

All procedures must comply with local safety regulations. Make sure you obey the five safety rules in the order listed in chapter 2.1 on page 8!

- Before operating the HVA test set, equipment set up procedure must be completed!
- Cables must be connected according to the sequence below!
- Before turning on the power supply and before activating the HVA test set, verify that all system elements are properly grounded!

Connection diagrams for standard connection:



**NOTICE**

For voltages above 15 kV we recommend the use of corona shields for TD diagnostics.

**Procedure steps:**

<b>S1</b>	<b>Connect all grounding cables.</b> Discharge and ground the DUT complying with local safety regulations. Connect the grounding cable to the HVA grounding connector <b>1</b> . Prepare grounding for measurement <b>3</b> <b>4</b> on both Near and Far End.
<b>S2</b>	<b>Connect power supply</b> <b>30</b> .
<b>S3</b>	<b>Connect all HV cable connections.</b> <ul style="list-style-type: none"><li>• Screw the HV test lead into the HVA HV output connector <b>10</b>.</li><li>• Connect the grounding clamp of the HV test lead <b>2</b> to protection ground.</li></ul> <b>Attention!</b> The grounding clamp of the DUT adapter is for over-voltage protection only and does not provide safe grounding of the cable shield. <ul style="list-style-type: none"><li>• Connect the other end of the HV test lead to the DUT <b>17</b>. Optional: Mount corona shields (<b>K1</b> and <b>K2</b>) to DUT.</li></ul>
<b>S4</b>	<b>Verify connections.</b> Check that all cables are attached securely on both Near End and Far End.
<b>S5</b>	<b>Configure interlock plug.</b> Verify that the HV emergency adapter is connected <b>47</b> . <b>If operating with remote controls (optional):</b> Connect external lamps or remote switches.
<b>S6</b>	Configure communication port. For USB data transfer mode, insert USB flash drive <b>31</b> .
<b>S7</b>	Turn "ON" the HVA main switch <b>44</b> (if applicable, e.g. HVA68TD).
<b>S8</b>	Turn key switch <b>43</b> to "ON" position.
<b>S9</b>	The HVA system automatically boots. Start-up default screen appears. Select appropriate option from default screen and proceed to appropriate section for further instructions.

**Remark:**

Apply the same order of the phases on both Near and Far End.

## 5.4 TD Diagnostics & Monitored Withstand Test and Guard on Near End

### DANGER




#### Electric shock hazard


All procedures must comply with local safety regulations. Make sure you obey the five safety rules in the order listed in chapter 2.1 on page 8!

- Before operating the HVA test set, equipment set up procedure must be completed!
- Cables must be connected according to the sequence below!
- Before turning on the power supply and before activating the HVA test set, verify that all system elements are properly grounded!


#### Connection diagrams:



HVA28TD



HVA34TD-1  
HVA45TD



HVA68TD



### NOTICE

For voltages above 15 kV we recommend the use of corona shields for TD diagnostics.

Follow the introduction in chapter 5.3 TD Diagnostics & Monitored Withstand Test. After step S3, continue with steps OS1 to OS3, afterwards continue with steps S4 to S9.

#### Procedure steps:

##### Connections on Near End

**OS1** Fix the hook and loop fastener **27** at the termination. Place it as close as possible to the ground side of the DUT's termination, without touching the ground directly.

**OS2** Connect the guard connection cable **23**:

- Connect the cable at the 4 mm socket at the HV test lead.
- Connect the other end of the cable at the conducting hook and loop fastener **27**.

##### Connections on Far End

**OS3** Corona shield **K2** must be mounted on the DUT on the same phase at the Far End as on the Near End. As mentioned above, use of corona shields is highly recommended for voltages above 15 kV!

#### Remark:

Apply the same order of the phases on both Near and Far End.

## 5.5 TD Diagnostics & Monitored Withstand Test and Guard on Near and Far End


DANGER

**Electric shock hazard**

All procedures must comply with local safety regulations. Make sure you obey the five safety rules in the order listed in chapter 2.1 on page 8!

- Before operating the HVA test set, equipment set up procedure must be completed!
- Cables must be connected according to the sequence below!
- Before turning on the power supply and before activating the HVA test set, verify that all system elements are properly grounded!

Connection diagrams:



**NOTICE**

For very short cables with a cable length below 100 m / 330 ft we recommend use of the guard on the far end as well as on the near end. This is possible for three-phase systems or systems where you have a second connection from far end to near end.

Follow the introduction in chapter 5.3 TD Diagnostics & Monitored Withstand Test. After step S3, continue with steps OSG1 to OSG6, afterwards continue with steps S4 to S9.

**Procedure steps:****Connections on Near End**

- |             |  |
|-------------|--|
| <b>OSG1</b> | Fix the hook and loop fastener <b>27</b> at the termination. Place it as close as possible to the ground side of the DUT's termination, without touching the ground directly.  |
| <b>OSG2</b> | Connect the guard connection cable <b>23</b> : <ul style="list-style-type: none"><li>• Connect the cable at the 4 mm socket at the HV test lead.</li><li>• Connect the other end of the cable at the conducting hook and loop fastener <b>27</b>.</li></ul>  |
| <b>OSG3</b> | Connect the guard connection cable from the leakage current from the end: <ul style="list-style-type: none"><li>• Connect the guard connection cable <b>24</b> with a dolphin clip to a phase that is not being tested or in operation.</li><li>• Connect the other end of the guard connection cable at the 4mm socket at the HV test lead.</li></ul> |

**Connections on Far End**

- |             |  |
|-------------|--|
| <b>OSG4</b> | Corona shield <b>K2</b> must be mounted on the DUT on the same phase at the Far End as on the Near End.  |
| <b>OSG5</b> | Fix the conducting hook and loop fastener for leakage current detection: <ul style="list-style-type: none"><li>• Fix the hook and loop fastener at the termination to the phase which will be tested <b>27</b>. Place it as close as possible to the ground side of the DUT's termination, without touching the ground directly.</li></ul> |
| <b>OSG6</b> | Connect the guard connection cable <b>23</b> at the conducting hook and loop fastener <b>27</b> .<br>Connect the other end of the cable with a dolphin clip <b>26</b> to the same phase, as used on the near end.  |

**Remark:**

Apply the same order of the phases on both Near and Far End.

## 5.6 Jacket / Sheath Test

### DANGER






#### Electric shock hazard

All procedures must comply with local safety regulations. Make sure you obey the five safety rules in the order listed in chapter 2.1 on page 8!

- Before operating the HVA test set, equipment set up procedure must be completed!
- Cables must be connected according to the sequence below!
- Before turning on the power supply and before activating the HVA test set, verify that all system elements are properly grounded!

Connection diagrams:



<b>S1</b>	<b>Connect all grounding cables.</b> Discharge and ground the DUT complying with local safety regulations. Connect the grounding cable to the HVA grounding connector ①. Prepare grounding for measurement ③ ④ on both Near and Far End.  <b>Attention!</b> <b>Since there is HV applied to the shield of the DUT, the shield of the tested phase needs to be isolated from the ground potential on both ends of the cable!</b> <b>The shields of the other phases remain grounded.</b>
<b>S2</b>	<b>Connect power supply ③⑩.</b>
<b>S3</b>	<b>Connect all HV cable connections.</b> <ul style="list-style-type: none"><li>• Screw the HV test lead into the HVA HV output connector ⑩.</li><li>• Connect the grounding clamp of the HV test lead ② to protection ground.</li></ul> <b>Attention!</b> The grounding clamp of the DUT adapter is for over-voltage protection only and does not provide safe grounding of the cable shield. <ul style="list-style-type: none"><li>• Connect the other end of the HV test lead to the DUT ⑰.</li></ul>
<b>S4</b>	<b>Verify connections.</b> Check that all cables are attached securely on both Near End and Far End.
<b>S5</b>	<b>Configure interlock plug.</b> Verify that the HV emergency adapter is connected ④⑦.  <b>If operating with remote controls (optional):</b> Connect external lamps or remote switches
<b>S6</b>	Configure communication port. For USB data transfer mode, insert USB flash drive ③①.
<b>S7</b>	Turn "ON" the HVA main switch ④④ (if applicable, e.g. HVA68TD).
<b>S8</b>	Turn key switch ④③ to "ON" position.
<b>S9</b>	The HVA system automatically boots. Start-up default screen appears. Select appropriate option from default screen and proceed to appropriate section for further instructions.

**Remark:**

Apply the same order of the phases on both Near and Far End.

## 5.7 Vacuum Bottle Test

### DANGER




#### Electric shock hazard


All procedures must comply with local safety regulations. Make sure you obey the five safety rules in the order listed in chapter 2.1 on page 8!

- Before operating the HVA test set, equipment set up procedure must be completed!
- Cables must be connected according to the sequence below!
- Before turning on the power supply and before activating the HVA test set, verify that all system elements are properly grounded!


Connection diagrams:



HVA28, HVA28TD



HVA34-1, HVA34TD-1  
HVA45, HVA45TD



HVA68TD


**Procedure steps:**

<b>S1</b>	<b>Connect all grounding cables.</b> Discharge and ground the DUT complying with local safety regulations. Connect the grounding cable to the HVA grounding connector <b>1</b> . Prepare grounding for measurement <b>4</b> .
<b>S2</b>	<b>Connect power supply <b>30</b>.</b>
<b>S3</b>	<b>Connect all HV cable connections.</b> <ul style="list-style-type: none"><li>• Screw the HV test lead into the HVA HV output connector <b>10</b>.</li><li>• Connect the grounding clamp of the HV test lead <b>2</b> to protection ground.</li></ul> <b>Attention!</b> The grounding clamp of the DUT adapter is for over-voltage protection only and does not provide safe grounding of the cable shield. <ul style="list-style-type: none"><li>• Connect the other end of the HV test lead to the DUT <b>17</b>.</li></ul>
<b>S4</b>	<b>Verify connections.</b> Check that all cables are attached securely.
<b>S5</b>	<b>Configure interlock plug.</b> Verify that the HV emergency adapter is connected <b>47</b> . <b>If operating with remote controls (optional):</b> Connect external lamps or remote switches
<b>S6</b>	Configure communication port. For USB data transfer mode, insert USB flash drive <b>31</b> .
<b>S7</b>	Turn "ON" the HVA main switch <b>44</b> (if applicable, e.g. HVA68TD).
<b>S8</b>	Turn key switch <b>43</b> to "ON" position.
<b>S9</b>	The HVA system automatically boots. Start-up default screen appears. Select appropriate option from default screen and proceed to appropriate section for further instructions.

## 6 Test procedure

### 6.1 Test modes overview

At the smartVLF® series you can choose between a manual mode and an auto test mode. At the manual mode you set your test parameters at the beginning (or during) the test and the parameters will be not saved. At the auto test mode you use pre-programmed test sequences. The HVA test set will drive the parameters from the test sequence. The test sequences can be created on the device or the PC. Details are discussed in chapter 6.4 Creating an auto test sequence.



Use the previously used test sequence. This saves your time if you plan to repeat the measurement.

Use the manual mode to define your test parameters individually.

Select a pre-defined test sequence from the list.

## 6.2 Manual mode overview





## 6.2.1 Setting report parameters for a manual test mode

When starting a manual test, the first step is to state the parameters for reporting. As depicted on the previous page, you can decide among **basic reporting**, **extended reporting** or **disabled reporting**. To set your reporting choice, go to **Settings / Instrument Setup / Reporting** or go to 4.2.1 Instrument setup, step IS5: Reporting for further information. For information on each reporting parameter, please go to Chapter 7.2: Reporting parameters.

### Basic Report

If under **Settings / Instrument Setup / Reporting** you select "Basic" option, these are the parameters you are asked to fill in.

Remark:  
 Propag. velocity (v) appears for test sets with APL functionality only.

Confirm with the "Next" button.

### Extended Report

If under **Settings / Instrument Setup / Reporting** you select "Extended" option, there are more parameters you are asked to fill in. However, you do not have to fill in every field.

Remark:  
 Propag. velocity (v) appears for test sets with APL functionality only. It will be used if an arc occurs. Specifying a line length also helps the APL to determine more precise results.


Confirm with the "Next" button.

## 6.2.2 Characteristics of different output modes

When you complete the report details, you are ready to set up your measurement. Press the “Setup” button on the screen that appears on your test set next and select an output mode to carry out the HV testing:


### Manual Test Mode Setup

Press the “Setup” button (on the right) to be able to set up the test parameters for your test.




### VLF Withstand Test

- Suitable for testing of extruded cables (e.g. XLPE) and other DUTs.
- Waveform: sine or square.
- Measured values are shown as RMS.




### VLF Tan Delta Test

- Measures TD value of DUT according to selected standards and/or custom limits.
- “Burn on Arc” arc management mode: available only for test sets with APL functionality.
- Waveform: sine.
- Measured values are shown as RMS; TD in E-3.



### DC Test

- Single-polarity output. DUT is polarised (negative / positive) with respect to ground.
- NOT recommended for testing of extruded cables (e.g. XLPE).
- Measured value: dielectric loss of DUT (incl. leakage current across terminations).
- Most commonly used: DC-.




**Jacket / Sheath Test**

- Duration is user defined.
- Max. test voltage: 10 kV
- Trip current range: 0.1-5.0 mA




**Sheath Fault Location**

- Duration is user defined.
- Pulse is user defined.
- Available pulse ratios: 1:3 / 4s, 1:5 / 4s, 1:5 / 6s, 1:9 / 6s



**Vacuum Bottle Test**


- Available in both manual and automatic test modes.
- Rise rate and trip current are user defined.
- Measured values are shown as peak voltage.
- NOT suitable for testing with DC above DUT voltage rating (X-ray hazard).



After setting up your test details, you are ready to start with the measurement. However, if you need more help on setting up the parameters for specific test types mentioned in this section, please follow the instructions in chapter 6.2.3 on the next pages.

**Start the measurement**

Press the "Start" button to proceed with the measurement.



## 6.2.3 Manual test parameters

### Select the DUT

Set the device to be tested.

The options are:

- Cable
- Motor
- Generator
- Transformer
- Switchgear
- Vacuum Bottle

Remark:

If reporting was activated, DUT type was defined there and cannot be adapted at this setup.

Main Menu | Start a New Test | Manual Mode Setup HVA45TD

Device Under Test	Cable
Test Type	VLF Withstand Test
Arc Management Mode	Trip out on Arc
Timer	24h 00min
Waveform	Sine
Frequency	0.1 Hz

Friday, January 01, 2016 12:01 AM

### Set the arc management

Select one of the following:

- Trip out on arc
- Burn on arc

“Burn on Arc” arc management mode: make sure that the appropriate dwell time is selected (in the range 1 to 5 minutes).

Main Menu | Start a New Test | Manual Mode Setup HVA45TD

Device Under Test	Cable
Test Type	VLF Withstand Test
Arc Management Mode	Trip out on Arc
Timer	24h 00min
Waveform	Sine
Frequency	0.1 Hz

Friday, January 01, 2016 12:01 AM

### Set the test duration

Set the duration of the test.

There is a range to fit in.

- min. test duration: 1 minute
- max. test duration: 24 hours

Main Menu | Start a New Test | Manual Mode Setup HVA45TD

Device Under Test	Cable
Test Type	VLF Withstand Test
Arc Management Mode	Trip out on Arc
Timer	24h 00min
Waveform	Sine
Frequency	0.1 Hz

Friday, January 01, 2016 12:01 AM

### Set the waveform

Depending on the selected test type, the options are:

- Sine wave
- Square wave
- DC
- DC+
- DC-

Remark:

NOT applicable for VLF TD test, sheath test, sheath fault location and vacuum bottle test.

Main Menu | Start a New Test | Manual Mode Setup HVA45TD

Device Under Test	Cable
Test Type	VLF Withstand Test
Arc Management Mode	Trip out on Arc
Timer	24h 00min
Waveform	Sine
Frequency	0.1 Hz


Friday, January 01, 2016 12:01 AM

### Set the frequency

Choose between these options:

- 0.1 Hz/Auto: recommended setting that automatically maintains the frequency as close to 0.1 Hz as possible.
- fixed frequency can be set from 0.01 Hz to 0.1 Hz in steps of 0.01 Hz.

Remark:  
NOT applicable for DC test, sheath test, sheath fault location and vacuum bottle test.




### Set trip current

Set trip current and testing time:

- trip current: 0.1-5.0 mA
- test. time: 1 min-10 min

Remark:  
Applicable for jacket / sheath test and vacuum bottle test.




### Set pulse/period

Set pulse/period and testing time:


- 1:3 / 4 s
- 1:5 / 4 s
- 1:5 / 6 s
- 1:9 / 6 s

Remark:  
Applicable only for jacket / sheath fault location.



### Confirm your settings

To start a test, please confirm your settings with the "OK" button.




### Pre-set test voltage

Entering the test voltage before activating the manual mode test by pressing "Start" is optional.

In manual mode, the voltage can be set once the test has been initiated.


To set the test voltage, rotate the navigation knob until you reach the voltage value. The dot in upper right hand corner indicates that the test voltage is in pre-set mode. To accept the value, push in the knob. The dot in upper right hand disappears, indicating that the test voltage is set.



## 6.2.4 Running a manual test

### Start the test

In order to start the test, press the "Start" button (it turns orange).




### HV activation

Once the activation screen appears, press the HV switch  within 10 seconds.

Remark:

If the HV switch is not activated within 10 seconds, the "Manual Mode" screen will reappear.



### Test start-up

This is an indication that the HVA test set is initializing the test.




### Set the test voltage

If there is not already a test voltage pre-set or you want to modify the voltage value, rotate the navigation knob to set the voltage value.

The value will be updated, if the knob is not rotated for 2 sec.

The selection and the navigation knob will disappear at the voltage value and the new set voltage will be displayed in the left bottom corner.




### Test is running

Test begins automatically.

The timer value in the fourth line indicates the remaining testing time.

The bottom line of the screen (the black stripe) displays the pre-set values.




## 6.2.5 Test summary - test successful

This example depicts the VLF withstand test. Test summary for all other tests is depicted in the same manner.

### Test Successful summary

Display indicates successful end of manual test. Further options are displayed on the right side. You may:

- test the next phase
- start a new test
- view the corresponding report
- go back to the main menu



## 6.2.6 Test summary - test failed


These examples depict the VLF withstand test. Test summary for all other tests is depicted in the same manner.

**The line on arc location/APL appears only for test sets with APL functionality included.**

### Test failed summary 01

Display indicates that the test failed with a short test summary.


Information on arc location:  
Test failed, arc was located.  
Result written in green:  $SCF > 4$   
(See Glossary on p. 4.)



### Test failed summary 02

Display indicates that the test failed with a short test summary.


Information on arc location:  
Test failed, arc was located.  
Result written in orange:  $2 < SCF < 4$   
(See Glossary on p. 4.)




### Test failed summary 03

Display indicates that the test failed with a short test summary.

Information on arc location:  
Test failed, arc was not able to be located.  $SCF < 2$   
(See Glossary on p. 4.)



### 6.3 Running an auto test - overview




\*Check report settings:  
This screen appears only when reporting has been enabled.

### 6.3.1 Running an auto test - last used sequence

In order to run a test with a "Last Used Sequence" it is necessary that such a sequence has been added to the test set prior to this measurement. You either created it in a manual mode (see Chapter 6.2 for further information) or you imported it via USB flash drive (see Chapter 4.1.4 or 4.2.4 for further information).


#### Start New Test menu

Confirm that you plan to start a new test.



#### Select sequence menu


Choose this option to proceed with the same test sequence as was last used.



#### Check report settings

Report settings for the selected sequence appear here. You may modify the lines, if you would like to make some changes.


Remark:  
These are the report parameters for the extended report.  
Basic report settings: "Settings" / "Instrument Setup" / "Reporting"



#### Sequence summary

The summary of the sequence parameters appears.

Press the "Start" button to proceed with the measurement.




### HV activation

Once the activation screen appears, press the HV switch within 10 seconds.

Remark:

If the HV switch is not activated within 10 seconds, the "Manual Mode" screen will reappear.



### Test start-up

This is an indication that the HVA test set is initializing the test.



### Test is running

Test begins automatically. According to the test sequence the pre-set test voltage values and steps will be applied.

The timer value in the fourth line indicates the remaining testing time.


The information in the footer are the pre-set values.



### Test summary

Display indicates end of auto test. Further options are displayed on the right side. You may:

- test the next phase
- start a new test
- view the corresponding report (if reporting is enabled and test type is not jacket / sheath fault location)
- go back to the main menu




## 6.3.2 Running an auto test - select a sequence from the list

In order to “Select Sequence” to run a test it is necessary that such a sequence has been added to the test set prior to this measurement. You either created it in a manual mode (see Chapter 6.2 for further information) or you imported it via USB flash drive (see Chapter 4.1.4 or 4.2.4 for further information).

### Select sequence menu

In the “Start New Test” menu, choose this option to go to the selection of all available test sequences.




### Set the report details

First, check the parameters for the reporting.

Note:


These are the report parameters for the extended report.  
Basic report example: p. 40  
Basic report settings: “Settings” / “Instrument Setup” / “Reporting”

Confirm with the “Next” button at the bottom of the screen.



### Select the sequence


Dependent on the Device Under Test you can select the sequence from the list and press “Start” button.



### Sequence summary

The summary of the sequence parameters appears.

Press the “Start” button to proceed with the measurement.




### HV activation

Once the activation screen appears, press the HV switch within 10 seconds.


Remark:

If the HV switch is not activated within 10 seconds, the previous screen will reappear.



### Test start-up

This is an indication that the HVA test set is initializing the test.



### Test is running

Test begins automatically. According to the test sequence the pre-set test voltage values and steps will be applied.

The timer value in the fourth line indicates the remaining testing time.

The information in the footer are the pre-set values.




### Test summary

Display indicates end of automatic test.

Further options are displayed on the right side. You may:

- test the next phase
- start a new test
- view the corresponding report
- go back to the main menu



## 6.4 Creating an auto test sequence - overview


This HVA test mode facilitates satisfying specific requirements (e.g. IEEE, IEC standards) when testing and allows to program customizable test sequences that can be recalled at any time. The test sequence can be configured, modified and saved at any time before testing.



## 6.4.1 Configuring a new auto test sequence


### Edit Sequences menu

To configure a new sequence, we start at the "Edit Sequences" menu.




### Create a new sequence

Pick a sequence from the list, then press the "New" button on the right side.



### Sequence info: Title

The title you type in will appear in the list of available sequences later on.



**Sequence info: Work order**

Type in the work order.

Remark:  
This field is only optional but can be useful for the reporting.

To continue, press "Next" button.

Main Menu | Edit Sequences | new sequence HVA45TD  
Step: 1/4

**Sequence Information**

Auto Test Seq. Title 20KV SINE 10MIN  
Work Order

Cancel Back Next Store

Friday, January 01, 2016 12:01 AM

**DUT**

Set the device to be tested.  
The options are:

- Cable
- Motor
- Generator
- Transformer
- Switchgear
- Vacuum Bottle
- Other

Main Menu | Edit Sequences | new sequence HVA45TD  
Step: 2/4

**Device Under Test**

Device Under Test Cable  
Insulation XLPE  
Voltage Rating 10.0 kV

Cancel Back Next Store

Friday, January 01, 2016 12:01 AM

**DUT: Insulation**

Set the cable insulation type:

- XLPE
- TRXLPE
- PILC
- EPR
- EPR (black) / (pink) / (dis. res.)
- PE
- PVC
- HYBR
- Other

Main Menu | Edit Sequences | new sequence HVA45TD  
Step: 2/4

**Device Under Test**

Device Under Test Cable  
Insulation XLPE  
Voltage Rating 10.0 kV

Cancel Back Next Store

Friday, January 01, 2016 12:01 AM

**DUT: Voltage rating**

The possible range is 0 to 50 kV.

Remark:  
This is a characteristic of the DUT.  
Based on this value we can then calculate  $U_0$ .

To continue, press "Next" button.

Main Menu | Edit Sequences | new sequence HVA45TD  
Step: 2/4

**Device Under Test**

Device Under Test Cable  
Insulation XLPE  
Voltage Rating 10.0 kV

Cancel Back Next Store

Friday, January 01, 2016 12:01 AM

**Test specification: Test type**

Select an appropriate test.

- VLF Withstand test
- VLF Tan Delta test
- MWT
- DC test
- Sheath test

Remark:

Test type is dependent on DUT type or on test guide.

Main Menu | Edit Sequences | new sequence HVA45TD  
Step: 3/4

**Test Specification**

Test Type: VLF Withstand Test

Test Standard: No Standard

Test Purpose: Maintenance

Voltage Rating  $U_0$ :

Buttons: Cancel, Back, Next, Store

Friday, January 01, 2016 12:01 AM

**Test specification: Test standard**

Set the test standard, e.g.:

- HD620
- IEEE400.2 Int
- IEEE400.2
- Q GDW 11838
- No standard

Remark:

If you select a test standard / guide, some of the parameters are locked. E.g. IEEE 400.2 -> no DC test possible

Main Menu | Edit Sequences | new sequence HVA45TD  
Step: 3/4

**Test Specification**

Test Type: VLF Withstand Test

Test Standard: No Standard

Test Purpose: Maintenance

Voltage Rating  $U_0$ :

Buttons: Cancel, Back, Next, Store

Friday, January 01, 2016 12:01 AM

**Test specification: Test purpose**

Select appropriate test purpose:

- Maintenance
- Acceptance
- Installation

Main Menu | Edit Sequences | new sequence HVA45TD  
Step: 3/4

**Test Specification**

Test Type: VLF Withstand Test

Test Standard: No Standard

Test Purpose: Maintenance

Voltage Rating  $U_0$ :

Buttons: Cancel, Back, Next, Store

Friday, January 01, 2016 12:01 AM

**Test specification:  $U_0$**

Check this box, if you want to refer to the voltage rating  $U_0$  for definition of the test step voltage. Depending on the DUT type, determine whether to use a three-phase calculation or a one-phase calculation of  $U_0$ . Based on the  $U$  value, the device calculates a  $U_0$  value that can be edited here.

To continue, press "Next" button.

Main Menu | Edit Sequences | new sequence HVA45TD  
Step: 3/4

**Test Specification**

Test Type: VLF Withstand Test

Test Standard: No Standard

Test Purpose: Maintenance

Voltage Rating  $U_0$ :  5.8 kV

Buttons: Cancel, Back, Next, Store

Friday, January 01, 2016 12:01 AM

### Test limits: Arc Management

Select an arc management mode.

- Trip out on Arc
- Burn on Arc

#### For Burn on arc mode only

fix the dwell time:

- Min. dwell time: 1 min
- Max. dwell time: 5 min

Main Menu | Edit Sequences | new sequence HVA45TD

**Step: 4/4**

### Test Limits

Arc Management Mode	Burn on Arc	<input type="text" value="1 min"/>
Overload during test	<input type="text" value="No Action"/>	
Voltage not reached	<input type="text" value="No Action"/>	
Min. Insulation Resistance	<input type="text" value="No Action"/>	

Friday, January 01, 2016 12:01 AM

### Test limits: Overload

Set action to be taken in case of overload:

- No Action (default)
- Fail: Runs to end
- Fail: Immediate Stop

Main Menu | Edit Sequences | new sequence HVA45TD

**Step: 4/4**

### Test Limits

Arc Management Mode	Burn on Arc	<input type="text" value="1 min"/>
Overload during test	<input type="text" value="No Action"/>	
Voltage not reached	<input type="text" value="No Action"/>	
Min. Insulation Resistance	<input type="text" value="No Action"/>	

Friday, January 01, 2016 12:01 AM

### Test limits: Voltage not reached

Set action to be taken in case voltage is not reached:

- No Action (default)
- Fail: Runs to end
- Fail: Immediate Stop

Main Menu | Edit Sequences | new sequence HVA45TD

**Step: 4/4**

### Test Limits

Arc Management Mode	Burn on Arc	<input type="text" value="1 min"/>
Overload during test	<input type="text" value="No Action"/>	
Voltage not reached	<input type="text" value="Fail: Immed. Stop"/>	
Min. Insulation Resistance	<input type="text" value="No Action"/>	

Friday, January 01, 2016 12:01 AM

### Test limits: Min. insul. resistance

Set action to be taken in case minimum insulation resistance is reached:

- No Action (default)
- Fail: Runs to end
- Fail: Immediate Stop

The resistance value can be set in the box beside the action.

To store the sequence, press the "Store" button.

Main Menu | Edit Sequences | new sequence HVA45TD

**Step: 4/4**

### Test Limits

Arc Management Mode	Burn on Arc	<input type="text" value="1 min"/>
Overload during test	<input type="text" value="No Action"/>	
Voltage not reached	<input type="text" value="Fail: Immed. Stop"/>	
Min. Insulation Resistance	Fail: Runs to end	<input type="text" value="10 MΩ"/>

Friday, January 01, 2016 12:01 AM


The sequence which you have just configured is going to be added to the list with sequences, under a title you specified in step: 1/4. After you have stored the test sequence the HVA will show you an overview of the sequence where you can check and edit the settings. There you can also edit the test parameters for the different voltage steps. See 6.4.2 Modifying an existing auto test sequence on the next pages for further information.

## 6.4.2 Modifying an existing auto test sequence

In order to modify an existing sequence, there must already be a sequence available in the “Edit Sequences” menu. It can then be overwritten according to the following procedure:


### Edit Sequences menu

To modify an existing sequence, we start at the “Edit Sequences” menu.



### Edit an existing sequence



Pick a sequence from the list and on the right side, click on the “Edit” button.



### Sequence info: Title

Activate the keyboard and edit the title for your new sequence.

Later, the new sequence will appear in the list of available sequences under this title.



The next parameters are identical to the ones introduced in chapter 6.4.1 Configuring a new auto test sequence, steps 1 through 4.

Thus, below we continue with the parameters which were not discussed previously. The parameters we skip here are identical with the ones mentioned in the chapter 6.4.1 Configuring a new auto test sequence. These parameters are:

- DUT: Cable,
- Test type: VLF Withstand test,
- Test standard: No standard.

#### Test parameters: Period count

This parameter is dependent on selection of the standard.

- ... test duration in: [time]
- ... test duration in: [samples or periods]

In some standards, the test duration units are predetermined (i.e.: IEEE).

Main Menu | Edit Sequences | Edit Sequence HVA45TD

Min. Insulation Resistance Fail: Immed. Stop 10 MΩ

**Test Parameters**

Use period count

No of steps 2

#1 1.9 U<sub>0</sub> (11.0 kV) 10 min Sine 0.1 Hz(A)

#2 3.8 U<sub>0</sub> (22.0 kV) 15 min Sine 0.1 Hz(A)

Friday, January 01, 2016 12:01 AM

#### Test parameters: # of U steps

Specify the number of voltage steps to be applied to the DUT.

- Min. step count: 1 step
- Max. step count: 15 steps

Main Menu | Edit Sequences | Edit Sequence HVA45TD

Min. Insulation Resistance Fail: Immed. Stop 10 MΩ

**Test Parameters**

Use period count

No of steps 2

#1 1.9 U<sub>0</sub> (11.0 kV) 10 min Sine 0.1 Hz(A)

#2 3.8 U<sub>0</sub> (22.0 kV) 15 min Sine 0.1 Hz(A)

Friday, January 01, 2016 12:01 AM

#### Test parameters: Test voltage

For each step, specify the test voltage.

- Min. voltage level: 0.1 kV or 0.1 U<sub>0</sub>
- Max. voltage is dependent on the maximal test set voltage

Main Menu | Edit Sequences | Edit Sequence HVA45TD

Min. Insulation Resistance Fail: Immed. Stop 10 MΩ

**Test Parameters**

Use period count

No of steps 2

#1 1.9 U<sub>0</sub> (11.0 kV) 10 min Sine 0.1 Hz(A)

#2 3.8 U<sub>0</sub> (22.0 kV) 15 min Sine 0.1 Hz(A)

Friday, January 01, 2016 12:01 AM

**Test parameters: Test duration**



For each step, specify the test duration:

- For **non-Tan Delta** test types you continue with **periods**.
- For **Tan Delta** tests you continue with **samples**.

The testing time depends on the frequency chosen.

- Min. 1 min
- Max. 24h 0 min

Sampling range: 2 to 500



**Test parameters: Waveform**

For specific output modes following waveforms are available:

**VLF withstand test**


- Sine wave
- Square wave

**VLF Tan Delta test**

- Sine wave

**DC test**

- DC+
- DC-
- DC for a vacuum bottle test




**Test parameters: Frequency**

For each step, set the frequency value. Choose between these options:

- 0.1 Hz(A): recommended setting that automatically maintains the frequency as close to 0.1 Hz as possible.
- fixed frequency can be set from 0.01 Hz to 0.1 Hz in steps of 0.01 Hz.

To store the sequence, press the "Finish" button.



## 6.5 Interrupting a test

Once a test has started, it can be interrupted at any time. It is recommended to choose the appropriate interruption method for the situation.

### Routine stop - standard

Throughout the duration of the test, the "STOP" symbol is highlighted on the right-hand side of the screen footer.

If you wish to interrupt the test, push in the navigation knob **41**.

- HVA software deactivates HV.
- Test stops.



### Routine stop - alternative

While the test is in progress, you can deactivate high voltage by pressing the HV switch **40**.

- HVA hardware deactivates HV.
- Test stops.




### Emergency stop

In an emergency situation, at any time, press the "Emergency OFF" button **42** to shut-down the system.

- HVA hardware deactivates HV.
- Test stops.



## 6.6 Discharge status



\* Discharge time approximation:  $t_{\text{Discharge}} \text{ (sec.)} \approx 20 \frac{\text{s}}{\mu\text{F}} \times C_L \text{ (}\mu\text{F)}$

Example: Load capacitance  $C_L = 1.2 \mu\text{F}$ .  $t_{\text{Discharge}} \approx 20 \times 1.2 = 24 \text{ sec.}$

**This is an approximation only and does not replace the safety rules.**

## 7 Reporting

### 7.1 Report types

All HVA test sets from the smartVLF® series generate two report types: “Basic” or “Extended”. Reporting can also be disabled. Set your reporting choice under **Settings / Instrument Setup / Reporting** or go to 4.2.1 Instrument Setup, step IS5: Reporting for further information.

Following report information is available for each of the mentioned reporting options:


Report information	Basic reporting	Extended reporting	Disabled reporting
Report title	✓	✓	—
Device under test	✓	✓	—
Voltage rating [kV]	✓	✓	—
Insulation	✓	✓	—
Propagation velocity (v) *only for test sets with APL functionality	✓	✓	—
Phase	✓	✓	—
Company name	—	✓	—
Region name	—	✓	—
Station name	—	✓	—
Line length [m/ft]	—	✓	—
Size of DUT	—	✓	—
Manufacturer name	—	✓	—
Work order	—	✓	—
Operator name	—	✓	—

## 7.2 Reporting parameters

In the following pages, every report parameter from the previous page is described in further detail. Please note that line with propagation velocity ("Propag. velocity (v)") is depicted only on the test sets with APL functionality.

### Report title: Basic & Extended


Give your report a suitable title. For more information on how to type in the characters, please go to 4.1.3 Operating the keyboard section.



### DUT: Basic & Extended

Set the device to be tested. The options are:


- Cable
- Motor
- Generator
- Transformer
- Switchgear
- Vacuum Bottle
- Other



### Voltage rating: Basic & Extended

The possible range is 0 to 50 kV.

Remark:  
This is a characteristic of the DUT. Based on this value we can then calculate  $U_0$ .



### Insulation: Basic & Extended

Set the cable insulation type:

- XLPE
- TRXLPE
- PILC
- EPR
- EPR (black)
- EPR (pink)
- EPR (dis. res.)
- PE
- PVC
- HYBR

Main Menu | Start a New Test | Report Details HVA68TD

Report Title	TEST3
Device Under Test	Cable
Voltage Rating	1.0 kV
Insulation	XLPE
Propag. velocity (v)	300.0 ft/μs
Phase	A

Back Next

Monday, July 8, 2024 1:44 PM

### Propag. velocity: Basic & Ext.

This characteristics is available only for DUT: Cable and appears only on test sets with APL functionality.

Set propagation velocity of the DUT.  
Default value:  $v=160.0 \text{ m}/\mu\text{s}$  (524 ft/μs)

This value influences directly the accuracy of the Arc Pre-Location result. The more accurately the propagation velocity is entered, the more accurate the Arc Pre-Location will be.

Main Menu | Start a New Test | Report Details HVA68TD

Report Title	TEST3
Device Under Test	Cable
Voltage Rating	1.0 kV
Insulation	XLPE
Propag. velocity (v)	300.0 ft/μs
Phase	A

Back Next

Monday, July 8, 2024 1:49 PM

### Phase: Basic & Extended

Set the phase:

- A
- B
- C
- AB
- AC
- BC
- ABC

Main Menu | Start a New Test | Report Details HVA68TD

Report Title	TEST3
Device Under Test	Cable
Voltage Rating	1.0 kV
Insulation	XLPE
Propag. velocity (v)	300.0 ft/μs
Phase	ABC

Back Next

Monday, July 8, 2024 1:52 PM



## NOTICE

Further reporting information is available only for the extended reporting. If you wish to extend the report with more information, make sure you set the reporting choice under **Settings / Instrument Setup / Reporting** as "Extended".

**Company name: Extended**

Type in the company name.


Remark:  
This field is optional.



**Region name: Extended**

Type in the region name.


Remark:  
This field is optional.



**Station name: Extended**

Type in the station name.


Remark:  
This field is optional.



**Line length: Extended**

Set line length:  
Default value is set to 10 000 m /  
32 800 ft.

The entered value helps to narrow down the APL algorithm to identify the location of the arc. Specifying a line length also helps the APL to determine more precise results. Make sure the entered value is not smaller than the actual cable length.



**Size of DUT: Extended**

Type in the size of the DUT.

Remark:  
This field is optional.

Main Menu | Start a New Test | Report Details HVA68TD

Station Name	STATION A
Line Length	33000 Feet
Size of DUT	---
Manufacturer Name	---
Work Order	WO 124/23
Operator Name	PETE

Back Next

Monday, July 8, 2024 1:15 PM

**Manufacturer name: Extended**

Type in the manufacturer name.

Remark:  
This field is optional.

Main Menu | Start a New Test | Report Details HVA68TD

Station Name	STATION A
Line Length	33000 Feet
Size of DUT	---
Manufacturer Name	---
Work Order	WO 124/23
Operator Name	PETE

Back Next

Monday, July 8, 2024 1:15 PM

**Work order: Extended**

Type in the work order.

Remark:  
This field is optional.

Main Menu | Start a New Test | Report Details HVA68TD

Station Name	STATION A
Line Length	33000 Feet
Size of DUT	---
Manufacturer Name	---
Work Order	WO 124/23
Operator Name	PETE

Back Next

Monday, July 8, 2024 1:16 PM

**Operator name: Extended**

Type in the operator name.

Remark:  
This field is optional.

Main Menu | Start a New Test | Report Details HVA68TD

Station Name	STATION A
Line Length	33000 Feet
Size of DUT	---
Manufacturer Name	---
Work Order	WO 124/23
Operator Name	PETE

Back Next

Monday, July 8, 2024 2:05 PM

### 7.3 Test report examples

On these two examples we would like to demonstrate the difference between the information included in **the extended reporting** (left) and **the basic reporting** (right).

Remark:

The information written in red and green regards distance to arc measurement possibility and is available for test sets with APL functionality only. If the test did not finish successfully, the information on arc location is always red, regardless the SCF value.

**TD TEST 1**  
 VLF Diagnostic Report  
 Sine TD Seq 4 Steps - Maintenance Test  
 Auto Test  
 Test failed - Arc location: 3206 m

**Report Information**

Date	12/5/2023 8:53 AM
Company Name	B2 ELECTRONICS
Region	VORARLBERG
Station	STATION A
Operator Name	ALEX
Work Order	WO 123/23

**Device Under Test (Cable XLPE)**

Voltage Rating	10.0 kV
Insulation	XLPE
Propag. velocity (v)	160.0 m/μs
Line Length	10000 Meter
Size	---
Phase	ABC
Manufacturer Name	---

**Equipment:**

HVA68TD	GH5250.21Z012
---------	---------------

**Test Setup**

Test Purpose	Maintenance
Arc Management Mode	Trip out on Arc

#	Test Voltage	Waveform	Frequency	Samples
1	5.0 kV*	Sine	0.1 Hz (A)	6
2	10.0 kV*	Sine	0.1 Hz (A)	6
3	15.0 kV*	Sine	0.1 Hz (A)	6
4	25.3 kV*	Sine	0.1 Hz (A)	6

**Measurements:**  
 failed at step 4 after 0 Samples  
 interrupted by Arc at 24.3 kV

#	Voltage	Current	Cap.	Res.	Frequency
1	5.0 kV*	1.57 mA*	500 nF	1.8 GΩ	0.1 Hz
2	10.0 kV*	3.14 mA*	500 nF	1.8 GΩ	0.1 Hz
3	15.0 kV*	4.71 mA*	500 nF	1.8 GΩ	0.1 Hz
4	15.0 kV*	4.71 mA*	---	---	0.1 Hz

#	Voltage	TD [E-3]	Std.Dev. [E-3]
1	5.0 kV*	2.73	0.01
2	10.0 kV*	2.73	0.01
3	15.0 kV*	2.82	0.01
4	15.0 kV*	---	1000.0

\*RMS value

**Arc Pre-Location**

#	Distance	SCF
1	3206 m	7.6

**TD TEST 11**  
 VLF Diagnostic Report  
 Sine TD Seq 4 Steps - Maintenance Test  
 Auto Test  
 Test failed - Arc location: 3206 m

**Report Information**

Date	12/5/2023 9:59 AM
------	-------------------

**Device Under Test (Cable XLPE)**

Voltage Rating	10.0 kV
Insulation	XLPE
Propag. velocity (v)	160.0 m/μs
Phase	ABC

**Equipment:**

HVA68TD	GH5250.21Z012
---------	---------------

**Test Setup**

Test Purpose	Maintenance
Arc Management Mode	Trip out on Arc

#	Test Voltage	Waveform	Frequency	Samples
1	5.0 kV*	Sine	0.1 Hz (A)	6
2	10.0 kV*	Sine	0.1 Hz (A)	6
3	15.0 kV*	Sine	0.1 Hz (A)	6
4	25.3 kV*	Sine	0.1 Hz (A)	6

**Measurements:**  
 failed at step 4 after 0 Samples  
 interrupted by Arc at 24.0 kV

#	Voltage	Current	Cap.	Res.	Frequency
1	5.0 kV*	1.57 mA*	500 nF	1.8 GΩ	0.1 Hz
2	10.0 kV*	3.14 mA*	500 nF	1.8 GΩ	0.1 Hz
3	15.0 kV*	4.71 mA*	500 nF	1.8 GΩ	0.1 Hz
4	0.0 kV*	0.0 μA*	---	---	---

#	Voltage	TD [E-3]	Std.Dev. [E-3]
1	5.0 kV*	2.73	0.01
2	10.0 kV*	2.73	0.01
3	15.0 kV*	2.82	0.01
4	0.0 kV*	---	1000.0

\*RMS value

**Arc Pre-Location**

#	Distance	SCF
1	3206 m	7.6

On these two examples we would like to demonstrate the difference between the reports when **test finished successfully** (left) and when **test failed** (right).

Remark:

The information written in red and green regards distance to arc measurement possibility and is available for test sets with APL functionality only.

TEST5					
VLF Withstand Report					
Manual Test					
Test finished successfully					
Report Information					
Date	11/30/2023 2:35 PM				
Company Name	B2 ELECTRONICS				
Region	VORARLBERG				
Station	STATION A				
Operator Name	ALEX				
Work Order	WO 123/23				
Device Under Test (Cable XLPE)					
Voltage Rating	10.0 kV				
Insulation	XLPE				
Propag. velocity (v)	160.0 m/μs				
Line Length	10000 Meter				
Size	---				
Phase	ABC				
Manufacturer Name	---				
Equipment:					
HVA68TD	GH5250.21Z012				
Test Setup					
Arc Management Mode	Trip out on Arc				
#	first Voltage	Waveform	Frequency	Duration	
1	15.0 kV*	Sine	0.1 Hz (A)	1 min	
Manual max. Voltage 15.0 kV					
Measurements:					
Test finished successfully					
#	Voltage	Current	Cap.	Res.	Frequency
1	15.0 kV*	1.11 mA*	118 nF	966 MΩ	0.1 Hz
*RMS value					

TEST7					
VLF Withstand Report					
Manual Test					
Test failed - Arc location: 3206 m					
Report Information					
Date	11/30/2023 2:41 PM				
Company Name	B2 ELECTRONICS				
Region	VORARLBERG				
Station	STATION A				
Operator Name	ALEX				
Work Order	WO 123/23				
Device Under Test (Cable XLPE)					
Voltage Rating	10.0 kV				
Insulation	XLPE				
Propag. velocity (v)	160.0 m/μs				
Line Length	10000 Meter				
Size	---				
Phase	ABC				
Manufacturer Name	---				
Equipment:					
HVA68TD	GH5250.21Z012				
Test Setup					
Arc Management Mode	Trip out on Arc				
#	first Voltage	Waveform	Frequency	Duration	
1	0.0 kV*	Sine	0.1 Hz (A)	1 h	
Manual max. Voltage 20.8 kV					
Measurements:					
failed at step 1 after 0 min 13 sec interrupted by Arc at 24.6 kV					
#	Voltage	Current	Cap.	Res.	Frequency
1	0.0 kV*	0.0 μA*	---	---	0.1 Hz
*RMS value					
Arc Pre-Location					
#	Distance	SCF			
1	3206 m	7.6			

When the test fails on the HVA68TD test set, there are more options how the test report will be depicted:


- test failed, correlation factor for calculating a pre-location of the arc is high**  
 Test report to this situation is depicted on the right side; information on the result is written in red and the detected Arc Pre-Location in green.
- test failed, correlation factor is moderate**  
 Test report to this situation is very similar to the one on the right side; information on the result is written in red and the detected Arc Pre-Location is written in orange.
- test failed, arc was not able to locate**  
 Test report to this situation is very similar to the one on the right side; however, there is no information on Arc Pre-Location at the top and at the bottom of the report.

## 7.4 Report management

Reports can be viewed directly on the HVA display and can be exported on a USB flash drive (see 4.2.4 Data administration for more details) or downloaded to HVD ControlCenter via Bluetooth. Below are the options how you can manage the created reports:

### Reports main menu


From the main menu, select "Reports"



### Select a report


Here, all available reports are listed. On the right side are blue tabs with all the possibilities that come with the selected report.

Select a report and confirm your selection with the "Select" button. Only then can you with this particular report use further options from the bar on the right.



### View a report

Select "View" for viewing the report on the HVA screen. The whole report appears, as shown on examples on previous two pages.



**TEST3**  
VLF Withstand Report

Manual Test  
Test finished successfully

**Report Information**



---

Date	7/8/2024 12:49 PM
Company Name	HV DIAGNOSTICS
Region	WOODSTOCK
Station	STATION A

### View a graph

Select "Graph" for viewing the TD graph on the HVA screen. The name of the graph is the name of the report.

Remark:  
Only possible if you use a TD unit.



### Edit a report

Select "Edit" to edit

- the name of the report
- the phase of the report

The name of the report is edited via the keyboard. Go to chapter 4.1.3 Operating the keyboard, if you need more information on the use of the keyboard.



### Edit a report - Report title

The name of the report is edited via the keyboard. Go to chapter 4.1.3 Operating the keyboard, if you need more information on the use of the keyboard.



**Edit a report - Change phase**

To change a phase, select from the options available in the box next to "Phase" and confirm with OK.



An informative screen that the changes were stored successfully should appear next and confirm this operation.



**Continue with the measurement**


Select "Continue" to continue with the measurement. First, select the phase to be tested. The phase last measured is indicated.

This functionality allows you to start a measurement on a three-phase system at one time and finish it later.



### Delete a report



Select "Delete" for two delete options.



### Delete a report - Delete All

If you select "Del All", the system is about to delete all stored reports.


A second screen appears, asking you to confirm your action.



### Delete a report - Yes


If you select "Yes", this particular report will be deleted.

Remark:  
No further screen appears asking you to confirm your action.





**Delete a report - No**

If you select "No", this report remains unharmed and report list screen with all available reports and options on the right side appears.



**Main**

If you don't plan to proceed any action with the reports from the report list, press "Main" and return to the main menu.





*This page is intentionally left blank.*

## 8 Disconnection procedure

### DANGER




#### Electric shock hazard

Disconnection procedures must comply with local safety regulations. Make sure you obey the five safety rules in the order listed in chapter 2.1 on page 8!

- Cables must be connected according to the sequence below!
- Before disconnecting the test lead, DUT must be discharged and grounded!
- Ground connections must be removed last!

Disconnection diagrams:



### Discharge stick for the disconnection procedure



#### Procedure steps for disconnection:


<b>S1</b>	Stop the test according to instructions in chapter 6.5 Interrupting a test and press the Emergency OFF button <b>42</b> to lock against re-energizing.
<b>S2</b>	Verify the HV status. Wait until the red LED <b>71</b> deactivates. The red LED indicates HV status. Red LED on, green LED on: Start-up procedure, is a safety feature. Red LED on, green LED off: HV is applied, the test starts / is running. Red LED flashing, green LED on: a) The device is discharging. b) Or, backfeed voltage is present. HV is not applied but external voltage has been detected. The voltage at HV test lead sensed > 100 V.
<b>S3</b>	Discharge and ground the DUT complying with local safety regulations.
<b>S4</b>	<b>Disconnect the test lead:</b> <ul style="list-style-type: none"><li>• Disconnect test lead (and other accessories, if applicable) from DUT <b>17</b> according to the used connection scheme (all options are mentioned in Chapter 5 Application).</li><li>• Disconnect ground cable from the HV cable shield <b>2</b>.</li></ul> <b>Attention!</b> <p>The grounding clamp of the DUT adapter is for over-voltage protection only and does not provide safe grounding of the cable shield</p> <ul style="list-style-type: none"><li>• Unscrew HV test lead from HVA HV output connector <b>10</b>.</li></ul>
<b>S5</b>	Turn "OFF" the HVA main switch <b>44</b> (if applicable, e.g. HVA68TD). Disconnect power supply cable from power supply socket <b>30</b> .
<b>S6</b>	<b>Disconnect all grounding cables:</b> <ul style="list-style-type: none"><li>• Disconnect grounding cable from DUT ground <b>3</b>.</li><li>• Disconnect grounding cable from HVA grounding connector <b>1</b>.</li></ul>

Remark:

Apply the same order of the phases on both Near and Far End.

## 9 PC software

The HVA system is delivered with a set of Windows-based software tools in an integrated software package. The corresponding HVD ControlCenter software connects, records, analyses and reports the test results from the HVA testing instruments.



As was already discussed in chapter 4.1.4 Data transfer modes, if the HVA is connected to the HVD ControlCenter, reports and sequences can be downloaded from the HVA using the corresponding functions. See software manual for further information.

## 10 Additional information

### 10.1 Storage

Storage temperature: -25°C to +70°C / -13°F to 158°F  
Humidity: 5 - 85% non-condensing

If the appliance is not to be used for a longer period of time, always store it in the packaging supplied.  
If the appliance is stored in the open and is heavily soiled, this can lead to malfunctions.

### 10.2 Apparatus care



#### DANGER

##### Electric Shock Hazard!

NEVER assume that equipment is safe to handle without using the necessary safety equipment and grounding procedures.

When cleaning **the equipment**, avoid spraying the control electronics directly with a high-pressure jet. If a high-pressure jet is used to clean electrical system components, this can lead to electrical faults and malfunctions.  
If malfunctions are detected due to wet control electronics, operation must be stopped. Open the appliance and allow it to dry out completely. After resuming operation, check the function by running through the switch-on/switch-off procedure several times.

Clean the **HV cable / DUT adapters / test lead** connection points after use before storing.



#### NOTICE

##### Authorized personnel only!

Repairs and maintenance should only be performed by authorized HV Diagnostics personnel. It is strictly prohibited to open the device and make changes within the interior of the device.

Recommended inspection:  
Annual inspection by authorised HV Diagnostics staff is recommended.

### 10.3 Behavior at different unexpected conditions

#### In case of fire

If the appliance switches to a faulty state due to sparking and starts to burn, there is a risk of toxic gases being released by the burnt materials. In this case, the device has a software check that monitors the output voltage and switches it off.  
Press the "Emergency OFF" button  immediately (see chapter 6.5 Interrupting a Test for more information) and disconnect the appliance from the mains. Extinguish the resulting fire with extinguishing agents approved for high-voltage technology.

If you are working in "Burn on arc" mode and the device does not switch off automatically after the pre-programmed dwell period, or after a user stop, there is a risk of sparking and fire. If such a situation is suspected, the appliance must be switched off immediately using the "Emergency OFF" button  (see chapter 6.5 Interrupting a test for more information) and disconnected from the mains.

#### In case of wet environment

Position the device so that it does not get wet due to the environment.



#### DANGER

If the device is used in a wet environment or if the device is subjected to strong temperature changes in high humidity and becomes damp, this can lead to dangerous voltage flashovers.

**When reaching dew point**

Position the device so that it is not in humid environment.

**DANGER**

If the device is used in a humid environment or if the device is subjected to strong temperature changes in high humidity and becomes damp, this can lead to dangerous voltage flashovers. In the event of significant temperature changes with dew point formation, you must first allow the appliance to acclimatize until the moisture has completely dried out before you start testing.

**In case of power outage**

A power failure causes the visual display to go out and the test set to cease operating. However, the device automatically switches to a safe state.

If you are using a generator to supply power to the test set, working with overvoltage during generator operation will destroy the appliance. Ensure that a low-resistance ground connection is established.

**10.4 Disposal**

This test set, including all its accessories, is not intended for household use. At the end of its service life, do not dispose of the test set with household waste.

Contact the authorities in charge of the relevant environmental regulations in your country and dispose of the HVD electronics test set only in accordance with your local legal requirements.



**Technical Support contact:**  
service@hvdiagnostics.com

**HV Diagnostics Inc.**

[www.hvdiagnostics.com](http://www.hvdiagnostics.com)