

M5150

SFRA Performance Verification Cell

Quick Start Guide



Doble Engineering Company
85 Walnut Street
Watertown, Massachusetts 02472-4037
(USA)
www.doble.com

LEGAL NOTICE

Warranty

Equipment Limited Warranty

Doble Engineering Company (Doble) warrants the products that it manufactures to be free from defects in material and workmanship for a period of one year from the date shipped from the factory.

During the one-year warranty period, Doble will repair or replace, at its option, any defective products or components thereof at no additional charge, provided that the product or component is returned, shipping prepaid, to Doble. The Purchaser is responsible for insuring any product or component so returned and assumes the risk of loss during shipment. All replaced products and components become the property of Doble.

THIS LIMITED WARRANTY DOES NOT EXTEND TO ANY PRODUCTS WHICH HAVE BEEN DAMAGED AS A RESULT OF ACCIDENT, MISUSE, ABUSE, OR AS A RESULT OF MODIFICATION BY ANYONE OTHER THAN DOBLE OR AN AUTHORIZED DOBLE REPRESENTATIVE.

EXCEPT AS EXPRESSLY SET FORTH ABOVE, NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, ARE MADE WITH RESPECT TO THE PRODUCT INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN THE EVENT THE PRODUCT IS NOT FREE FROM DEFECTS AS WARRANTED HEREIN, THE PURCHASER'S SOLE REMEDY SHALL BE REPAIR OR REPLACEMENT AS PROVIDED ABOVE. UNDER NO CIRCUMSTANCES WILL DOBLE BE LIABLE TO THE PURCHASER OR ANY USER FOR ANY DAMAGES, CAUSED BY OR ARISING OUT OF THE USE OF OR INABILITY TO USE THIS PRODUCT, INCLUDING WITHOUT LIMITATION, PERSONAL INJURY OR PROPERTY DAMAGE, ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, EXPENSES, LOST PROFITS, LOST SAVINGS, OR OTHER DAMAGES.

Software Limited Warranty

Doble warrants the disks on which the software product is furnished to be free from defects in materials and workmanship under normal use for a period of one hundred and twenty (120) days from the date of shipment from Doble. Purchaser's exclusive remedy shall be the replacement of any disks not meeting Doble's Software Limited Warranty which have been returned to Doble within the warranty period.

This warranty gives the purchaser specific legal rights and the purchaser may also have other rights which vary from state to state.

EXCEPT AS DETAILED ABOVE AND TO THE EXTENT ALLOWED BY ANY APPLICABLE STATE AND FEDERAL LAWS: THIS SOFTWARE PRODUCT IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THIS SOFTWARE PRODUCT IS WITH PURCHASER SHOULD THE PRODUCT PROVE DEFECTIVE. PURCHASER (AND NOT DOBLE OR AN AUTHORIZED DEALER) ASSUMES ALL LIABILITY ASSOCIATED WITH THE SOFTWARE AND THE ENTIRE COST OF ALL NECESSARY SERVICING, REPAIR, OR CORRECTION.

Limitations of Remedies

If Doble notifies Purchaser that is unable to deliver replacement disks which are free from defects in materials and workmanship, Purchaser may terminate this agreement. By returning the software product and all copies thereof in any form and affirming compliance with this requirement in writing, Doble will refund the purchase price.

TO THE EXTENT ALLOWED BY ANY APPLICABLE STATE AND FEDERAL LAWS, DOBLE EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED HEREIN. IN NO EVENT WILL DOBLE BE LIABLE TO PURCHASER FOR ANY DAMAGES, INCLUDING ANY LOST PROFITS, LOST SAVINGS OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE ANY SOFTWARE OR PRODUCT, OR FOR ANY TECHNICAL OR EDITORIAL ERRORS OF COMMISSION OR OMISSION, EVEN IF DOBLE OR AN AUTHORIZED DEALER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY OTHER PARTY.

Maintenance

For equipment maintenance, contact:

Doble Engineering Company
85 Walnut Street
Watertown, MA02472 (USA)

Telephone: 617-926-4900
Email: customerservice@doble.com
Web: www.doble.com

**Government
Restricted Rights
Legend**

Use, Duplication, or Disclosure by the U.S. Government is subject to restrictions as set forth in subparagraphs (c)(1) and (c)(2) of the Commercial Computer Software - Restricted Rights Clause at FAR 52.227-19.

**Intellectual
Property Notice**

This Manual is solely the property of the Doble Engineering Company (Doble) and is provided for the exclusive use of Doble clients under contractual agreement for Doble test equipment and services.

This Manual is protected by copyright, all rights reserved. No part of this book shall be reproduced, stored in a retrieval system, or transmitted by any means, electronic, mechanical, photocopying, recording, or otherwise without written permission from the Doble Engineering Company.

Doble and the Doble logo are trademarks of Doble Engineering Company.

Microsoft, Windows, Windows 95, Windows 98, Windows 2000, Windows NT, XP, Vista, and Windows 7 are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Copyright ©2013

By Doble Engineering Company

All Rights Reserved

M5150

Description

The M5150 Performance Verification Cell allows field verification of test instruments and cables, assuring SFRA (Sweep Frequency Response Analyzer) test quality. It can be used either in the field or in the office.


It can be used in either of two modes, with or without SFRA measurement leads.



Figure 1 M5150 Case

Top Panel

The top panel contains BNC connectors and connection points for connecting cables. See descriptions with [Figure 2](#).



A	BNC connectors for instrument-only testing (Source/Reference side)	D	Connection points for connecting SFRA measurement cable clamps (Measurement side - Black)
B	BNC connectors for instrument-only testing (Measurement side)	E	Equipment grounding (earthing) jack
C	Connection points for connecting SFRA measurement cable clamps (Source/Reference side - Yellow/Red)	F	Jumpers for connecting desired response for testing with SFRA measurement cables

Figure 2 Top Panel

Kit Contents

The following hardware is provided:

Part Number	Model/Instrument	Quantity
03D-1551-01	M5150 PERFORMANCE VERIFICATION CELL	1
181-0118	CABLE,BNC, m/m, RG58C/U, 120"	3
401-0160	BNC T-Adapter Female-Male-Female	1
181-0706	Cable, test lead, alligator clip, M5150	1

Assumptions

A working SFRA test system consists of:

- a Doble M5100, M5200, M5300, or M5400 (M5x00) instrument
- controlled by Doble SFRA software
- running on a PC that is ready to run a test (Note: The M5100 and the M5300 have an internal PC.)
- using default settings

Instructions for basic operation of the SFRA software are beyond the scope of this document. Refer to your instrument user guide.

Test Procedure

Hardware Test Setup

M5400



NOTE: Connection is shown for the M5400. All M5x00 instruments are similar. Just connect to the Source, Reference, and Measure, using either the color code or the connection labeling.

Figure 3 shows a typical test setup for testing an M5400.




Figure 3 M5400 Typical Test Setup

Connection Procedure *Without* SFRA Measurement Leads

Testing M5x00 Instrument, Instrument-Only

Refer to [Figure 3 on page 4](#), as needed.

1. Connect one of the coax cables from the M5x00 “**Source**” connector to the BNC T-adapter.
2. Connect one of the coax cables from the M5x00 “**Reference**” connector to the BNC T-adapter.
3. Connect the BNC T-Adapter to the top “**10 kHz Response**” connector on the M5150.
4. Connect a coax cable from M5x00 “**Measure**” connector to the bottom “**10 kHz Response**” connector on the M5150.

To continue testing for other response values, move the Source/Reference (T-adapter) and Measurement leads to a different set of connectors (-60 dB, -40 dB, or 0 dB), then run the test.

Connection Procedure *With* SFRA Measurement Leads

Testing M5x00 Instrument and Measurement Cables as a System

1. Connect the Source/Reference jumper to the top 10 kHz BNC connector (Figure 4).
2. Connect the Measurement jumper to the bottom 10 kHz BNC connector (Figure 4).
3. Attach the Source/Reference cable clamp (Red) to the Source/Reference connection point, and connect the Ground clamp to the Ground connection point (Figure 4).



Figure 4 Attaching Cable Clamps to Connection Point

4. Attach the Measurement cable clamp (Black) to the Measurement connection point, and connect the Ground clamp to the Ground connection point.

To continue testing for other response values, move the Source/Reference (T-adaptor) and Measurement jumpers to a different set of connectors (-60 dB, -40 dB, or 0 dB), then run the test.

Running the Test

The M5x00 instrument must be powered up and communicating with the SFRA software.

Any apparatus template will work, but we recommend that you create new ones for M5150 testing. You also can download M5150 test templates from the Doble website, under *Support-->Download-->SFRA Accessories*.

Viewing Test Results

After performing a check, you will see magnitude traces similar to [Figure 5](#) in the Data Display area.




Figure 5 Magnitude Trace

If your results closely match the traces shown in [Figure 5](#), your test set (and cables, if used) are in proper working order.

Sample M5150 result files are available in the zip file download of this guide located on the Doble web site, under *Support-->Download-->SFRA Accessories*.

Comparison of Traces

A typical 10 kHz Response SFRA trace will have the following characteristics:

- Minima¹ resonance of 10 kHz with a tolerance of +/- 100 Hz (9.90 to 10.10 kHz)
- A first notch depth of -80 to -90 dB minimum

Depending upon amount of background noise in the area when the M5x00 is under test with the M5150 Performance Verification Cell, you may experience variations in resonant amplitude (dB) but it should not affect the Frequency portion of the measurement sample.

If a questionable result is obtained please try the following suggestions:

- Re-check all measurement connections.
- Confirm that both the M5x00 and M5150 are bonded to a solid ground connection.
- Verify that all cables/leads away from any localized noise source.

Suspected noise sources include motors, SCRs, battery chargers, and transmission lines.

Typical 0, -40 and -60 dB SFRA traces should be in a +/- 1.0 dB tolerance.

See [Figure 6 on page 9](#) for details.

It is recommended that a complete set of test traces are taken for each M5x00, by serial number, and saved for future comparison.

1. Minima Response: The least or smallest quantity of measurement required




Figure 6 Minima Response

