

EMT Fittings Kit



1/2" Swagelok Female QC to 1/4" Hanson Female



1/2" Swagelok Male QC to DN6 Female



1/2" Swagelok Male QC to 1/4" Hanson Female



1/2" Swagelok Male QC to DN8 Female



1/2" Swagelok Male QC to DN20 Female



DN7 Female (Rectus 22) to 1/4" BSP Female



1/2" Swagelok Male QC to 1/4" NPT Male



1/2" Swagelok Male QC to 3/4" BSP Male



1/2" Swagelok Male QC to 1/4" Hanson Male



1/2" Swagelok Male QC to 3/8" BSP Female