

# Breaker Timer Accessories *Transducers*

## *Transducer Adapters*



### **RESISTOR TRANSDUCER ADAPTER**

part no **9095-UC**

The Vanguard Resistor Transducer Adapter (RTA) can be used to connect any resistor type transducer to the digital transducer channel of a Vanguard circuit breaker analyzer. The RTA also features a 3-pin SwitchCraft connector that can directly interface with ABB resistor transducers.



Connected to an ABB AHMB resistor-type transducer



### **DOBLE TRANSDUCER ADAPTER**

part no **9084-UC**

The Doble Transducer Adapter can be used to interface any Doble travel transducer to a Vanguard circuit breaker analyzer.



Connected to a Doble rotary transducer